

GE
Measurement & Control Solutions

Pressure Automated Calibration Equipment

Safety Instructions and User Guide - K0467

PACE Pressure Indicators






Figure 1

- | | | |
|--|-----------------------------|--------------------------------|
| A) Single port instrument | B) Two port instrument | C) Three port instrument |
| D) Remote sensor instrument | | |
| 1) Power supply connector | 2) Electrical rating | 3) Pressure port |
| 4) Pressure port | 5) Maximum working pressure | 6) Pressure full-scale (range) |
| 7) Power supply adaptor (see packaging list) | | |

Introduction

The PACE Pressure Indicator measures both pneumatic and hydraulic pressures and displays, on a colour touch-screen, the measured pressure and instrument status. The touch-screen enables selections and settings in measuring modes. The instrument can be operated remotely through communication interfaces.

Safety

The manufacturer has designed this equipment to be safe when operated using the procedures detailed in this manual. Do not use this equipment for any other purpose than that stated, the protection provided by the equipment may be impaired.

This publication contains operating and safety instructions that must be followed to make sure of safe operation and to maintain the equipment in a safe condition. The safety instructions are either warnings or cautions issued to protect the user and the equipment from injury or damage.

Use qualified * technicians and good engineering practice for all procedures in this publication.

Pressure

Do not apply pressures greater than the maximum working pressure to the equipment.

Toxic Materials

There are no known toxic materials used in construction of this equipment.

Maintenance

The equipment must be maintained using the procedures in this publication. Further manufacturer's procedures should be done by an authorized service agents or the manufacturer's service departments.

Technical Advice

For technical advice contact the manufacturer.

* A qualified technician must have the necessary technical knowledge, documentation, special test equipment and tools to carry out the required work on this equipment.

General Specification

| | |
|-----------------------|--|
| Display | LCD: Colour display with touch-screen |
| Operating temperature | 10°C to 50°C (50° to 122°F) |
| Storage temperature | -20°C to 70°C (-4° to 158°F) |
| Ingress protection | IP20 (EN60529) |
| Operating humidity | 5% to 95% RH (non-condensing) |
| Vibration | MIL-PRF-28800 Type 2 class 5 style E/F |
| Operating altitude | Maximum 2000 metres (6560ft) |
| EMC | EN 61326 |
| Electrical safety | EN 61010-1, UL61010-1, CSA 22.2, No. 61010-1 and IEC61010-1 |
| Power adaptor | Input range: 100 - 240VAC, 50 to 60Hz, 700mA. Installation category II |
| Pressure safety | Pressure Equipment Directive - class: sound engineering practice (SEP) for group 2 fluids. |
| Pollution degree | 2 |
| Operating Environment | Indoor use only. Not rated for use in potential explosive atmospheres |

Symbols

The equipment contains the following symbols to identify hazards.



This equipment meets the requirements of all relevant European safety directives. The equipment carries the CE mark.



This symbol, on the instrument, indicates that the user should refer to the user manual. This symbol, in this manual, indicates a hazardous operation.

Ce symbole, sur l'instrument, indique que l'utilisateur doit consulter le manuel d'utilisation. Ce symbole, dans le manuel, indique une situation dangereuse.



This symbol, on the instrument, indicates do not throw-away in domestic bin, hazardous material, dispose correctly in accordance with local regulations.

WARNINGS

TURN OFF THE SOURCE PRESSURE(S) AND CAREFULLY VENT THE PRESSURE LINES BEFORE DISCONNECTING OR CONNECTING THE PRESSURE LINES. PROCEED WITH CARE.

ONLY USE EQUIPMENT WITH THE CORRECT PRESSURE RATING.

BEFORE APPLYING PRESSURE, EXAMINE ALL FITTINGS AND EQUIPMENT FOR DAMAGE. REPLACE ALL DAMAGED FITTINGS AND EQUIPMENT. DO NOT USE ANY DAMAGED FITTINGS AND EQUIPMENT.

ISOLATE THE POWER SUPPLY BEFORE MAKING ANY ELECTRICAL CONNECTIONS TO THE REAR PANEL.

Packaging

Check the contents of the PACE1000 packaging with the list that follows:

Packaging List - PACE1000

- i) PACE1000 Pressure Indicator.
- ii) Adaptor, power supply (GE part number 191-370).
- iii) User guide and safety instructions, and CD containing the full documentation suite.
- iv) Calibration certificate.

Packaging for Storage or Transportation

To store or return the instrument for calibration/repair do the procedures that follow:

1. Pack the instrument (Ref: K0470, user manual, Reference and Specification, Section 6.13).
2. Return the instrument for calibration/repair complete the return goods procedure (Ref: K0470, user manual, Reference and Specification, Section 6.12).

Preparation for Use

The instrument can be used as a:

- Free-standing instrument positioned on a horizontal surface
- Panel-mounted using the panel-mount option kit (Ref: K0470 User Manual, Section 2.5).
- Rack-mounted in a standard 19 inch rack using the rack-mount option kit (Ref: K0470 User Manual, Section 2.5).

For free-standing instruments, the feet on the front of the base can be used elevate the instrument to a better viewing angle.

Note: Allow a free flow of air around the instrument, especially at high ambient temperatures.

Connecting the Instrument

WARNINGS

TURN OFF THE SOURCE PRESSURE(S) AND CAREFULLY VENT THE PRESSURE LINES BEFORE DISCONNECTING OR CONNECTING THE PRESSURE LINES. PROCEED WITH CARE.

ONLY USE EQUIPMENT WITH THE CORRECT PRESSURE RATING.

BEFORE APPLYING PRESSURE, EXAMINE ALL FITTINGS AND EQUIPMENT FOR DAMAGE. REPLACE ALL DAMAGED FITTINGS AND EQUIPMENT. DO NOT USE ANY DAMAGED FITTINGS AND EQUIPMENT.

Pneumatic Pressure (Figure 2-1)

1. Refer to the SDS for the correct pressure mediums to be used.
2. Connect the Unit Under Test (UUT) to the required connection port.

Note: For instruments with NPT connections, use applicable pressure sealing.




Figure 2-1, Sealing Pneumatic Connections

Pneumatic connections

Connection


| | |
|-----------|-------|
| Input | G 1/8 |
| Reference | G 1/8 |

For examples of adaptors (Ref: page 2 - 4).

Input Pressure (Figure 2)

1. Make sure the user systems can be isolated and vented.
2. Connect the Unit Under Test (UUT) to the output connection port.

Note: For instruments with NPT connections, use applicable pressure sealing.



1) G 1/8 connector 2) Bonded seal

Figure 2-2, Pneumatic Connections

Installation

The instrument connects to the Unit Under Test.

Input Pressure and Equipment

The pressure should not exceed 1.25 x full-scale or MWP stated on the rear panel of the instrument.

To protect the instrument from over-pressure a suitable protection device (such as a relief valve or bursting disc) must be fitted to prevent over pressurization.

Pneumatic Connection

WARNING

PRESSURE RANGES >210 bar (3000 psi) ARE ONLY RATED FOR HYDRAULIC USE.

Cautions

Do not exceed the maximum pressures stated in the appropriate Component Manual for the unit under test.

Reduce pressure at a controlled rate when venting to atmosphere.


Carefully de-pressurize all pipes to atmospheric pressure before disconnecting and connecting to the unit under test.

Connections


1. Switch off the power supply before connecting or disconnecting the instrument.
2. Use the appropriate sealing method for all pressure connections.

Method of connection G1/8

recommended method



Adaptors



IO-SNUBBER-1



IO-DIFFUSER-1



IO-ADAPT- 1/8 AUTOCLAVE
G 1/8 Male to 1/8 Autoclave



IO-ADAPT- 7/16 UNF
G 1/8 Male to 7/16 UNF Female



IO-ADAPT-G 1/4
1/8 Male to G 1/4 Female



IO-ADAPT-AN4
G 1/8 Male to AN4



IO-ADAPT-1/8NPT
G 1/8 Male to 1/8NPT Female



IO-ADAPT-AN6
G 1/8 Male to AN6



IO-ADAPT-1/4NPT
G 1/8 Male to 1/4NPT Female



IO-ADAPT-BARB
G 1/8 Male to 1/4 Hose

Refer to the data sheet SDS0014 for the range of adaptors.

Hydraulic Pressure

WARNINGS

HYDRAULIC LIQUID IS INJURIOUS. OBSERVE RELEVANT HEALTH AND SAFETY PRECAUTIONS. USE APPROPRIATE PROTECTIVE BARRIERS AND EYE PROTECTION.

BEFORE APPLYING PRESSURE, EXAMINE ALL FITTINGS AND EQUIPMENT FOR DAMAGE AND ENSURE THAT ALL EQUIPMENT IS TO THE CORRECT PRESSURE RATING.

DO NOT EXCEED THE MAXIMUM WORKING PRESSURE OF THE INSTRUMENT.

PURGE ALL AIR FROM THE HYDRAULIC LIQUID.

PRESSURE RANGES >210 bar (3000 psi) ARE ONLY RATED FOR HYDRAULIC USE.

DO NOT USE A SENSOR FOR GAS THAT HAS BEEN USED WITH HYDRAULIC LIQUID.

Cautions

Do not exceed the maximum pressures stated in the appropriate component manual for the unit under test.

Reduce pressure at a controlled rate when venting to atmosphere.

Carefully de-pressurize all pipes to atmospheric pressure before disconnecting and connecting to the unit under test.

Observe absolute cleanliness when using the instrument.

Severe damage can be caused if equipment connected to this instrument is contaminated.

Connect only clean equipment to the instrument.

To avoid any contamination, an external filter is recommended.

Installation

The instrument connects to the Unit Under Test.

Input Pressure and Equipment

1. The pressure should not exceed 1.25 x full-scale or MWP stated on the rear panel of the instrument.
2. To protect the instrument from over-pressure a suitable protection device (such as a relief valve or bursting disc) must be fitted to limit the pressure to below the MWP.

Note: For instruments with NPT connections, use applicable pressure sealing.

recommended method




Figure 2-3, Sealing Hydraulic Connections

Hydraulic connections

Connection

| | |
|-----------|-------|
| Input | G 1/8 |
| Reference | G 1/8 |

Note: *Pressure connections >210 bar are 9/16" 18UNF Male Autoclave.*

1. Switch off the power supply before connecting or disconnecting the instrument.
2. Use the applicable sealing method for all pressure connections.
3. Isolate the hydraulic pressures and depressurise the pipes before connecting or disconnecting the instrument.

Pressure input (Figure 2)

1. Make sure the user systems can be isolated and vented.
2. Use the applicable sealing method for all pressure connections.
3. The hydraulic liquid must be clean, refer to specification given in the SDS.
4. Connect the Unit Under Test (UUT) to the appropriate connection port.
5. Fill and bleed the UUT and connecting pipes.

Mounting kits

Rack-mount option (Figure 2-5)

There must be enough space at the rear of the instrument for all the cables and pipes. The length of the cables and pipes must allow for the removal and fitment of the instrument. The cooling air of the instrument must not be obstructed. Allow a free flow of air through the equipment rack and around the instrument, especially at high ambient temperatures.




Figure 2-5 Rack-mounting

Procedure

1. Locate instrument in rack mount assembly ①.
2. Secure with the four M3 x 6 screws ②, (maximum length M3 x 8).
3. Support the instrument and connect the cables and pipes.
4. Refer to the electrical connections below before fitting the instrument into the equipment rack.
5. Temporarily locate the two spigots * to each side of the equipment rack.
6. Locate and slide the instrument into the rack.
7. Locate the instrument on the spigots*.
8. Secure the instrument in the equipment rack with two of the screws and washers (supplied).
9. Remove the two spigots* and replace with the remaining two screws and washers (supplied).

Panel-mount option (Figure 2-6)

There must be enough space at the rear of the instrument for all the cables and pipes.
The length of the cables and pipes must allow for the removal and fitment of the instrument.
The cooling air of the instrument must not be obstructed.
Allow a free flow of air through the equipment rack and around the instrument, especially at high ambient temperatures.




Figure 2-6 Panel-mounting

Procedure

1. Remove the four screws ① from the instrument.
2. Locate the instrument in panel mount assembly.
3. Secure with the four screws ①.
4. Support the instrument and connect the cables and pipes.
5. Refer to the electrical connections below before fitting the instrument into the panel.
6. Secure the instrument in the panel with four screws and washers ②.

Electrical connections

WARNING

ISOLATE THE POWER SUPPLY BEFORE MAKING ANY ELECTRICAL CONNECTIONS TO THE REAR PANEL.

Caution

Use the power adaptor supplied with the instrument (GE part no. 191-370). Using other power adaptors may cause over-heating, this can result in a fire.


Connecting (Figure 2-7)

1. Before use, make sure the SELV power adaptor supplied with the instrument is used (GE part number 191-370).
2. Install an accessible power isolator to use as the disconnecting device in the power adaptor supply circuit.
3. The power adaptor input power supply range: 100 - 240VAC, 50 to 60Hz 700mA, Installation Category II.

Note: The power adaptor must be supplied by a fused or overload-protected power supply.

4. Connect the power adaptor to the instrument.
5. Switch the power supply on.
6. Check that the front panel display shows the power-up sequence (Ref: K0470, User Manual, section 3.2).

Note: After the power-up sequence, the instrument shows the default display on the touch screen. The touch screen divides into a number of mimic keys.



Requirements for rack-mounted and panel-mounted instruments

1. Install an accessible power isolator to use as the disconnecting device in the power adaptor supply circuit.
2. Set the power supply isolator to OFF.
3. Connect the power adaptor before sliding the instrument into the rack.
4. Set the power supply isolator to ON.
5. Check that the front panel display shows the power-up sequence (Ref: K0470, User Manual, section 3.2).

Communication Connections

Connect the applicable connectors into the rear panel communications ports and, if appropriate, secure with the captive screws.

Note: The RS232 and IEEE 488 interfaces are both enabled at power-up. Set the required parameters in Supervisor Setup/communications menu, see Section 3.6.




Figure 2-7, Communication Connectors

- | | | | | | | | |
|---|----------------------|---|-------|---|-------------------|---|---------|
| 1 | Power supply adaptor | 2 | RS232 | 3 | Canbus (option) | 4 | IEEE488 |
| 5 | USB B | 6 | USB A | 7 | Ethernet (option) | | |

RS232 Interface

When using the RS232 interface, a cable must be connected directly from the instrument to a suitable port on the computer in a 'point to point' link.

The pin connections for the 9-pin D-type, RS232 connector and the relationship between the instrument and the RS232 control signals, together with device interconnection interface is shown in Table 2-1. The instrument is configured as Data Circuit Terminating Equipment (DCE).

| Instrument | | Control Line | | Computer/Printer | |
|------------------------|---|------------------|-------------------|----------------------------|-----------------------------|
| Instrument Function | Connector 9-way D-type Pin No. | Signal Direction | RS232 Terminology | Connector Type | |
| | | | | 9-way D-type Pin No. | 25-way D-type Pin No. |
| RxD (I/P) | 3 | ← | TxD | 3 | 2 |
| TxD (O/P) | 2 | → | RxD | 2 | 3 |
| GND | 5 | ↔ | GND | 5 | 7 |
| CTS (I/P) | 7 | ← | RTS | 7 | 4 |
| RTS (O/P) | 8 | → | CTS | 8 | 5 |
| Pulled high internally | 1 | → | RLSD (DCD) | 1 | 8 |
| Not connected | 4 | ← | DTR | 4 | 20 |
| Pulled high internally | 6 | → | DSR DCE Ready | 6 | 6 |
| Equipment Chassis | Connector Shell | ↔ | Cable Screen | - | 1 |

Table 2-1, RS232 Connections

Handshaking connections

Software handshaking use: TXD, RXD and GND.

Hardware handshaking use: TXD, RXD, GND, CTS, RTS and DTR.

IEEE 488 Interface

The interface complies with IEEE 488 standard.

The IEEE 488 parallel interface connects a computer/controller to one or more PACE1000 instruments and other instruments.

Up to 30 instruments can be connected through a high-speed data bus to the computer/controller.

Note: The length of each IEEE 488 cable must be less than 3 metres to comply with the EMC requirements (Ref: SDS).


Single Unit Installation (Figure 2-8)

1. Connect an IEEE 488 connector/cable assembly to the rear panel of the instrument.
2. Connect the other end of the connector/cable assembly to the IEEE 488 connector on the controller/computer.
3. Change the IEEE 488 communication parameters (Ref: K0470, User manual, Supervisor set-up, Section 6.7).

Multiple Unit Installation (Figure 2-8)

To install multiple units use stacking plugs to link the first instrument and second instrument as follows.

1. Connector to rear panel of first instrument (Ref Illustration).
2. Connector from controller/computer (Ref Illustration).
3. Connector to rear panel of second instrument (Ref Illustration).
4. Connect the IEEE 488 connector on the controller/computer and the other connector into the next instrument.
5. Repeat this procedure for all the instruments in the system.
6. Use the Supervisor set-up (communications) menu on each instrument to set-up the required communication parameters (Ref: K0470, User manual, Section 3.8).






Figure 2-8 - IEEE 488 Connection

Return Goods/Material Procedure

If the unit requires calibration or is unserviceable return it to the nearest GE Service Centre listed at gesensinginspection.com.

Contact the Service Department, by 'phone, fax or E-mail to obtain a Return Goods Authorisation (RGA) (Worldwide excluding USA).

In the USA obtain a Return Material Authorization [RMA],

Providing the following information on either a RGA or RMA:

- Product (i.e. PACE1000)
- Serial number
- Details of defect/work to be undertaken
- Calibration traceability requirements
- Operating conditions

Safety Precautions

You must inform GE if the product has been in contact with any hazardous or toxic substance.

The relevant COSHH or in the USA, MSDS, references and precautions to be taken when handling.

Important notice

Service or calibration by unauthorized sources will affect the warranty and may not guarantee further performance.

Approved Service Agents

For the list of service centres: www.gesensinginspection.com

Trademarks

All product names are trademarks of their respective company.

© The General Electric Company all rights reserved.