

User Manual

ECOCONTROL 2000 USB

All rights reserved. No part of this manual may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, for any purpose without the prior written permission of **SIKORA AG**.

This manual has been produced with the appropriate care. No warranty or representation, either expressed or implied, is made with respect to the quality, accuracy, or fitness for any particular purpose of this document. In no event will **SIKORA AG** be liable for direct, indirect, incidental, consequential or other damages resulting from the use or inability to use this document and the associated product(s). The manufacturer shall not be liable for the costs of repairing, replacing, or recovering any hardware, software, or data stored or used with this product.

Information in this document is subject to change without notice and does not represent a commitment on the part of **SIKORA AG**.

SIKORA AG is not liable for damages or problems resulting from the use of options which are no original **SIKORA** products.

Product names appearing in this document are mentioned for identification purposes only. All trademarks, product names, or brand names appearing in this document are registered property of their respective owners.

Edition April 2006
V3.04 USB

Device Number

Contents

Introduction	1
Chapter 1 Installation and Start-Up	1
1.1 Requirements for Device Installation	1
1.2 Mounting	2
1.3 Configuration	5
Chapter 2 Operation	19
2.1 General	19
2.2 Setting the Automatic Control	20
2.3 Determination of Nominal Values	21
2.4 Sector Conductor Measurement	22
2.5 Monitor Operation	23
2.6 Maintenance and Trouble Shooting	58
Chapter 3 Technical Information	61
3.1 Specification	61
3.2 Serial Interface for Communication with External Computer/PC	63
3.3 Profibus DP - Option -	64
Index	74

Figures

X	:	drawing included
Fig. 1	X	ECOCONTROL 2000 General View Ext. Connections
Fig. 2	X	ECOCONTROL 2000 Display Unit Rear View
Fig. 3	X	ECOCONTROL 2000 Dimensions
Fig. 6	X	LASER Measuring Head Stand for Sector Measurement
Fig. 7	X	External wiring/ Connection plan
Fig. 8	X	Camera cable/ Extension cord measuring head
Fig. 9	X	Connection rotary pulse generator
Fig. 10	X	Specifications rotary pulse generator
Fig. 11	X	Example metering wheel
Fig. 12	X	Automatic
Fig. 13	X	Jumper Location Controller Board PCCON
Fig. 50	O	Listing parameter of device
Fig. 51	O	Listing parameter of line
Fig. 52	X	Description Serial Interface

Introduction

The ECOCONTROL 2000 is a precision measuring and controlling device made by

SIKORA AG

Bruchweide 2
28307 Bremen

Telephone:	+49 (0)4 21 / 48 90 00
Fax:	+49 (0)4 21 / 48 90 0 - 90
e-mail	sales@sikora.net
Internet	www.sikora.com

Service Department:	+49 (0)4 21 / 48 90 0 - 50
e-mail	service@sikora.net

Contents of delivery:

- 1 Display Unit ECOCONTROL 2000 with TFT Color Monitor and Touch Panel, desk-top version (optionally for 19" rack assembly)
 - Measuring Head(s) / Measuring Device(s):
 - Measuring Head CENTERVIEW 2000
 - Measuring Head LASER 2000 XY with / without stand (Option)
 - Measuring Head LUMP 2000 XY with / without stand (Option)
 - Measuring Device CAPACITANCE 2000
 - Testing Device SPARK 2000 with / without stand (Option)
 - 1 Rotary Pulse Generator
 - 1 Set of Plugs
 - 1 Connection Cable, ready made, _____ m
 - Technical Documentation

Options:

- o Analog Output : Deviation
- o Multifunction Control Unit Hot/Cold
- o Serial Interface/s
- o Report Printer
- o Remote Display
- o Extreme Value Detection
- o Correction for Straight Sector Conductors
- o Profibus DP
- o FFT / SRL Analysis Functions

The ECOCONTROL 2000 is a processor-based measuring and control system for the exact measurement and control of the wall thickness/diameter of cables in extrusion lines, offering a varied number of applications in combination with other **SIKORA** measuring devices like CENTERVIEW 2000, LASER 2000 XY etc. Its TFT color monitor with touch screen offers a brilliant display together with easy operation.

The cables produced may be one of the following types:

- round conductor cable
- prespiralled sector cable
- straight sector cable.

Up to six measuring and / or testing devices can be used, so the object to be measured can be supervised on a non-contact base before and behind the extrusion and at the end of the line.

The measuring data are evaluated by an integrated industrial PC and displayed on the TFT monitor, which is also used for system operation.



Desk Version of ECOCONTROL 2000


The device has several interfaces for transferring measuring and operational data to and from the ECOCONTROL 2000. Its serial interfaces can be used to connect the ECOCONTROL 2000 to one or more of the **SIKORA** measuring heads like the CENTERVIEW 2000, LASER 2000 XY etc. or **SIKORA** devices like the CAPACITANCE 2000 or the SPARK 2000, or to an external computer. Its parallel interface can be used to connect a printer (Option).

Also, there is a digital input which is used to connect the Rotary Pulse Generator.

The ECOCONTROL relay contacts can be used to supply customer line equipment like for instance external signalling devices.

There are up to two controller output for either line or extruder automatic control.

Valuable information for production control and optimization can be gained by applying the analysis functions offering Fast-Fourier-Transformation and prediction of Structural Return Loss, which are included optionally.



ECOCONTROL 2000 / External Connections Overview

1. Installation and Start-Up

1.1 Requirements for Device Installation

1.1.1 Place of Installation

At the installation site, temperature should be kept in a range from +5°C - +50°C (+40 °F - +125 °F), maximum air humidity for the ECOCONTROL 2000 is 95% (without condensation).

1.1.2 Voltage Supply and Grounding

The ECOCONTROL 2000 can be supplied with either 230 or 115 V AC \pm 15%, 50...60 Hz. The power consumption amounts to approximately 200 VA.

When designing the device, special attention has been laid on preventing power-line interferences. Additionally, when installing the device we recommend that you use only those power lines which correspond to radio interference regulations.

If in doubt, you better provide a separate power line from your main distributes directly to the device and do not connect any other loads to it. Only the additional grounding of the cabinet of the device can prevent disturbances on the non-fused earthed conductor of your power line. Use at least 10 mm² copper wire and connect them as short as possible with your collecting ground bar. The ground is considered good when the resistance is less than 1 Ω .

1.1.3 Signal Lines

When installing the signal lines, please note they can pick up interferences that can influence device performance. A separate installation away from power lines and at sufficient distance to magnetic stray fields will guarantee reliable device performance.

Please note that the reference potential of the electronics (GND*) is insulated from the protective earthing (earth, grounding, housing) and is connected to it in the right place.

1.2 Mounting

1.2.1 Ecocontrol Display Unit

Check carefully after unpacking. Install the display unit at its place as delivered, i.e. complete with housing.

Make sure the device is placed correctly and cannot tilt over when its door is being opened !


There is a special mounting frame available (Option) if you want to install the display unit in a 19" rack, see Fig. 3. Mounting in a desk or cabinet is only recommended, when there are units without radiation interferences (e.g. printer, lump detector). Interferences may arise from Spark testers, as well as from motors, relais, contactors or magnetic valves.

1.2.2 Mounting the Measuring Head(s) / Testing Devices

Check carefully all parts after unpacking them. Refer to the manuals of the respective devices.

Please observe that a measuring head to be used for measuring the core diameter or hot diameter should be mounted just behind the extruder (about 300 mm). Measuring heads used for measuring the wall thickness should be placed about one to two meters apart from each other. For measuring heads at the end of the line, please take care that the cable is dry, because water drops may lead to faulty values.

For correct installation of LASER 2000 measuring heads, see separate manual *LASER 2000 XY*. However, for those lines with sector measurement, the measuring heads have to be placed differently at a 45° angle as illustrated below using the measuring head stand shown in Fig. 6.



LASER 2100 XY Measuring Head Alignment for Sector Measurement

1.2.3 Connection of Cables and Signal Lines

We deliver ready made connecting cables, standard length 6 m. These are used for connecting the display unit to up to six measuring heads, measuring devices and / or testers.


These cables carry data at a high transmission rate. Therefore the camera cables can be laid next to each other but should not be laid parallel to other cables which for instance are used for power supply. If however you decide upon a common path, keep a distance of at least 20 cm to other cables and avoid placing them near switched inductive loads (relay coils, motors, transformers, spark testers etc.) as far as their stray magnetic field is of importance.

Other signal and measuring conductors which carry no inductive loads are not dangerous.

Note that with a longer cable the effect of the interference which affects the connection cable will increase.



The outer sheath of these cables should be connected to the cabinet (earth, safety earth) at one end. Inner shields, which serve as signal return lines must be connected according to our guide lines, usually with the reference potential of the electronic (GND*).

Clamp the shielding under the cable grip and always take care to connect the cable shielding completely as shown in the sketch below.



Do not

- cut the shielding
- connect it only partly
- extend it.



Install the connections as required for your application. Refer also to Fig. 7 *External Wiring* for pin assignment and Fig. 2 where to find the respective connectors.

The digital inputs computer control mode (15 V*^Δ only computer active), and the external start/stop signals (for functions TREND/STATISTICS) has to be connected to St5.

The automatic control is connected to plug St6 and plug St12 (also refer to Fig. 12 *Automatic Control*). The nominal value voltage U1 at the slider of the drive potentiometer must not exceed ± 10 V with maximum pull-off speed.

1.2.4 Rotary Pulse Generator

The speed information of the rotary pulse generator is used for the display of page TREND, the delay time memory and if the control is to work with consideration of line speed (very slow lines refer also to Chapter 2.2.2 *Automatic Control*).

Install the rotary pulse generator at a meter wheel or a separate measuring wheel, which may be mounted on the caterpillar-ribbon. As the mechanical connection is critical we recommend to use a flexible coupling for perfect and permanent hold.

The output of the delivered rotary pulse generator is 25 pulses per revolution.

Refer to Fig. 7 *External Wiring* for pin assignment.

1.3 Configuration


1.3.1 General

Before starting ECOCONTROL 2000 operation the application has to be configured as described below to adapt it to your production line. This should be done by an experienced **SIKORA** technician.


Use the configuration section of your ECOCONTROL 2000 software to set the specific parameters of your line. This is usually done once during the initial set-up and does not have to be changed later on. If however this becomes necessary, please contact our Service Department first.

Proceed as follows:

Switch on the device. On the monitor screen, the measuring software presents the Standard Monitor Page.




First, on the Standard Monitor Page, touch **MORE**.





The buttons offered change, touch **Setup** to access the ECOCONTROL configuration program.

Then the configuration program main menu will appear.




Choose from the menu and set your configuration parameters accordingly (see description and examples below).

Setting is done by touching the respective parameter text box and either selecting from the alternatives being offered or entering a value via a numeric keypad being presented.



Leave the configuration program with **SAVE ... AND EXIT** when you want the entries to become valid, otherwise use **QUIT WITHOUT SAVE**.



ECOCONTROL Configuration Program Structure

1.3.2 Configuration Menu HARDWARE SETTINGS

The three sections of this page define

- the interfaces used for communication between the ECOCONTROL and the devices connected, such as LASER, CENTERVIEW, CAPACITANCE etc.
- the PC-CON address
- parameters used for data processing, such as measuring unit used and limit values.

The values for all parameters have been set at our factory and should not be changed. Please contact our Service Department first if modifications become necessary.

Example:

HARDWARE SETTINGS

Device interfaces:		Controller:		Data Processing:
Device No:	COM Port:	Address:	Function:	
Device 1	COM 3	PC-CON 0X308	<input checked="" type="checkbox"/> Speed	Data Request Intervall 200 ms
Device 2	COM 5		<input checked="" type="checkbox"/> CH 0	Measuring Unit mm
Device 3	COM 6		<input type="checkbox"/> CH 1	Diameter Display Precision 3
Device 4	COM 7			Test Display Disabled
Device 5	Not used			Max Spark Voltage 35 kV
Device 6	Not used			Average HC-Shrinkage
Device 7	Not used			Average Diameter 1 s
Device 8	Not used			Average Wallthickness 1 values
				DM-Error Message after 1 errors

Here, COM-Ports 3, 5, 6 and 7 are used to connect the four devices LASER, CENTERVIEW, CAPACITANCE and LASER to the ECOCONTROL. Compare with Configuration Menu Measuring Devices Configuration shown on page 12 and see Fig. 1 and 2 as well.

See explanation below.

OK

HARDWARE SETTINGS				
Device interfaces:		Controller:		Data Processing:
Device No:	COM Port:	Address:	Function:	
Device			<i>Measuring Head Request Rate</i>	Data Request Intervall <input style="width: 50px;" type="text" value="200 ms"/>
Device			mm / inch / mil , default setting is mm	Measuring Unit <input style="width: 50px;" type="text" value="mm"/>
Device			<i>Number of digits following decimal point</i>	Diameter Display Precision <input style="width: 50px;" type="text" value="3"/>
Device			<i>Additional measuring value display to be shown on request (for service only)</i>	Test Display <input style="width: 50px;" type="text" value="Disabled"/>
Device			15 kV / 25 kV / 30 kV , specify according to device installed	Max Spark Voltage <input style="width: 50px;" type="text" value="15 kV"/>
Device			<i>Length interval for calculating the shrinkage average value</i>	Average HC-Shrinkage <input style="width: 50px;" type="text" value="20 m"/>
Device			<i>Time interval for displaying the diameter average value</i>	Average Diameter <input style="width: 50px;" type="text" value="1 s"/>
Device			<i>Time interval for calculating the wall thickness average value</i>	Average Wallthickness <input style="width: 50px;" type="text" value="1 values"/>
Device			<i>Number of errors to be tolerated before displaying the next average value</i>	DM-Error Message after <input style="width: 50px;" type="text" value="1 errors"/>
<input style="border: 1px solid black; padding: 5px 10px;" type="button" value="OK"/>				

1.3.3 Configuration Menu APPLICATION PARAMETERS

This menu defines certain application parameter. Return to the main menu page with button **EXIT**. The values for all parameters have been set at our factory and should not be changed. Please contact our Service Department if necessary.

Example:

APPLICATION PARAMETERS		
Machine Number	0	Machine Number for Printer Protocol
Measuring Values' Color		Color which is used to display the measuring values
General Network Drive	H	Used if connected to customer network
General Network Directory	DATA	Used if connected to customer network
Motor Stop (CenterView)	No access	For the CENTERVIEW automatical motor stop at line stand-still
HV Sparktester OFF	No access	For switching off the SPARK automatically at line stand-still
Control Diameter with wallthickness	Yes	Control Mode: Diameter or Diameter with Wall Thickness
Line direction	Right	Line Display shown with line running to the right or to the left
Product table	Yes	Enable / Disable Product Table
Color Printer	No	Used by function FFT for diagram printing
Maximal measuring value	10.000	Set limit for maximum diameter measuring value possible
Print Screen orientation	No Print Screen	Enable / Disable Button Print Screen and choose screen orientation (Portrait / Landscape)
Max lines per printer page	70	Define max. number of lines per page (only with Option Printer)
Reset lump/Spark with Start Trend	Yes	Lump / Spark Counter reset at Start Trend
Display Controller Influence	Display / Button	Can be shown as Button, Icon or both
Actual Production Format	No setting	For the printer report headline
Auto LOG ON	Yes : Sam	User named Sam is logged in automatically at application start-up
Time Display	24h / Europe	00:00 - 24:00 or 00:00 - 12:00 a.m. / p.m.

OK

Example:

Parameter **Machine Number**

Touch the respective text box and enter the machine number via the numeric keypad appearing to the right of the page. This number is used for the printer report.

APPLICATION PARAMETERS		
Machine Number	0	Customer logs
Measuring Values' Color		Recipe selecting
General Network Drive	H	
General Network Directory	DATA	
Motor Stop (CenterView)	No access	
HV Sparktester OFF	No access	
Control Diameter with wallthickness	Yes	
Line direction	Right	
Product table	Yes	
Color Printer	No	
Maximal measuring value	10.000	
Print Screen orientation	No Print Screen	
Max lines per printer page	70	
Reset lump/Spark with Start Trend	Yes	
Display Controller Influence	Display / Button	
Actual Production Format	No setting	
Auto LOG ON	Yes : is	
Time Display	24h / Europe	

Machine Number

1 2 3 OFF

4 5 6 CE

7 8 9 <--

0 - OK

1.3.4 Configuration Menu MEASURING DEVICES CONFIGURATION

This menu is used for specifying which devices are being used in your application and at which position in your line they are to be found.

Please note: For your specific application, **all** measuring device configuration **parameters have been set at our factory and should not be changed**. However, if there are any changes to be made in your configuration, for example if a device is to be replaced or a new device is to be integrated into your line, always contact our Service Department first.

Example:

MEASURING DEVICE CONFIGURATION

Port	Device Type	Measuring Position	Standard Display	Diameter Correction	Distance to 0-setting (short)	Distance to 0-setting (long)
Device 1	Laser (USSC)	Before main extruder (D 1)	1. LED	No	21.00 m	21.00 m
Device 2	Laser (USSC)	After main extruder (D hot)	2. LED	No	20.00 m	20.00 m
Device 3	CenterView(USSC)	After cooling through (D cold)	3. LED	No	5.00 m	5.00 m
Device 4	Lump Detector				3.00 m	3.00 m
	Wallthickness	Before/after main extruder				


Defines in which text box on the main monitor page the respective measuring values are to be displayed:

1. LED 2. LED 3. LED

*In this example there are four devices: 2 LASER, 1 CENTERVIEW, 1 LUMP. Compare with Configuration Menu **Hardware Setting** and see Fig. 1 and 2 as well. The Line Display looks like this:*


Example:
Parameter **Device Type**

Select the device to be defined by touching the appropriate text box. In the submenu appearing, assign the device type as desired.



Example:
Parameter **Standard Display**

Touch the appropriate text box. In the submenu appearing, assign the main monitor page text box as desired. BIG LED means the measuring value display in the middle of the main monitor page, which is usually reserved for displaying the controlled value (wall thickness or diameter).



1.3.5 Configuration Menu SERIAL COMMUNICATION

This menu defines the communication interface parameter specific for your application. The values for all parameters have been set at our factory and should not be changed. Please contact our Service Department if necessary.

Example:

The screenshot displays the 'ECOCONTROL V4.05 CONFIGURATION' window with the copyright notice '© SIKORA AG'. A list of menu items is shown on the left: 'HARDWARE SETTINGS', 'APPLICATION PARAMETERS', 'MEASURING DEVICE CONFIGURATION', and 'SERIAL COMMUNICATION SETTINGS'. The 'SERIAL COMMUNICATION SETTINGS' dialog box is open, showing the following parameters:

COMMUNICATION PARAMETER SETTING	
Baud Rate	2400
Data Bits	7
Stop Bits	1
Parity	ODD

Buttons for 'Print SCI Info' and 'OK' are located to the right of the dialog box. A yellow callout box points to the 'Print SCI Info' button with the text: 'Print Serial Communication Interface Information, including the interface telegrams and their contents (Nominal Values/Actual Values)'.

1.3.6 Configuration Menu PCCON CARD SETTINGS

This menu defines the input and output signals as well as the control parameter specific for your application. The values for all parameters have been set at our factory and should not be changed. Please contact our Service Department if necessary.

Example:

PCCON CARD SETTINGS

Analog Output 1

Kind of output	CON
Control Value	Wallthickness / Diameter
Distance Extruder -- Measuring Head	0.5 m
Minimal control time [sec]	20.00
Fall time AUTO to MANUAL [sec]	20.00
Consider line speed	No
Control mode	Extruder
Extruder mark / term	

Digital Output

Digital output 0	active
Digital output 1	active
Digital output 2	not active
Digital output 3	not active

Digital Input

Digital input 0	Remote control
Digital input 1	Start Printer / Trend
Digital input 2	Stop Printer / Trend
Digital input 3	None

Analog Output 2

Speed Measuring

Pulses per rotation	25
Circumference measuring wheel	0.500 m

Kind of Digital Output Contact

Status contact	Alarm
----------------	-------

OK

Input is done by selecting the respective text box and choosing from the drop down menu unfolding or entering a value via the keypad appearing.

PCCON CARD SETTINGS

Analog Output 1

Kind of output	CON
Control Value	Wallthickness / Diameter
Distance Extruder -- Measuring Head	0.5 m
Minimal control time [sec]	20.00
Fall time AUTO to MANUAL [sec]	20.00
Consider line speed	No
Control mode	Extruder
Extruder mark / term	

Analog Output 2

*Output value: **CON** Controller, **ACT** absolute value or **DEVI** deviation*
Controlled value, can be Diameter or Capacitance (Option)
Used for dead-time correction
Default value is 20.0 seconds.
Time needed by control to return from operation mode AUTO to operation mode MANUAL.
Tells if line speed is to be taken into consideration for control.
Extruder: control of extruder screw speed
Line: control of line speed
Defines a name for the extruder shown in the line display

Digital Output

Digital output 0	active
Digital output 1	active
Digital output 2	not active
Digital output 3	not active

Defines output contact signals

Speed Measuring

Pulses per rotation	25
Circumference measuring wheel	0.500 m

Digital Input

Digital input 0	Remote control
Digital input 1	Start Printer / Trend
Digital input 2	Stop Printer / Trend
Digital input 3	None

Defines input contact signals

Kind of Digital Output Contact

Status contact	Alarm
----------------	-------

Defines output contact function
READY: opening contact
ALARM: closing contact


Example:
Parameter **Distance Extruder - Measuring Head**

The distance between the extruder and the measuring head is one of the control parameters. Select the parameter by touching its text box and enter the value of distance via the numeric keypad appearing.

The screenshot shows the 'PCCON CARD SETTINGS' screen. In the 'Analog Output 1' section, the 'Distance Extruder -- Measuring Head' parameter is selected. A yellow callout box points to this parameter with the text 'Select the parameter to be set ...'. Below the settings, a numeric keypad is displayed with a blue border. A yellow callout box points to the keypad with the text '... and enter its value. Confirm and exit with OK.'.


Example:
Parameter **Digital Output**

Select the output to be defined by touching the appropriate text box. In the submenu appearing, assign the digital output signal as desired.



Example:
Parameter **Digital Input**

Select the input to be defined by touching the appropriate text box. In the submenu appearing, assign the digital input signal as desired.



1.3.7 Configuration Menu USER LEVEL & PASSWORD

Among the three existing user levels Operator / System Configurator / Administrator, the access to this table is limited to users registered with level **Administrator**. The table is preset at our factory as shown below.

Example: The illustration shows the default setting. Passwords have been omitted, which means you just confirm the according request during your logon procedure by striking the **ENTER** key.

USER & PASSWORD SETTINGS

User	Password	Level
Sam		Administrator
Mitch		System Configurator
Joe		Operator
	No Password	No access
	No Password	No access
	No Password	No access
	No Password	No access
	No Password	No access
	No Password	No access
	No Password	No access
	No Password	No access
	No Password	No access
	No Password	No access
	No Password	No access
	No Password	No access
	No Password	No access
	No Password	No access
	No Password	No access
	No Password	No access
	No Password	No access
	No Password	No access
	No Password	No access
	No Password	No access
	No Password	No access
	No Password	No access
	No Password	No access
	No Password	No access

OK

Access authorization is as follows:

Level	Access to ... Operating Functions with Recipe Selecting and Manual Setting	System Configuration Recipe Setting and Modification	System Configuration including User & Password Setting
Administrator	✓	✓	✓
System Configurator	✓	✓	-
Operator	✓	-	-

If however your Administrator Access Entry has accidentally got lost and you are no longer able to log in to your ECOCONTROL measuring software please proceed as described below.

Repairing Administrator Access Registration

First, terminate the measuring software:

Connect a keyboard and close down the ECOCONTROL application with keys **ALT F4**.

Start the ECOCONTROL application as follows:

Open **Start** Menu and select **Run...**. In the **Run** submenu opening next, select **Browse**. Open the folder called \ECOCONTROL, and select the file named Ecocontrol.exe. In the **Run** submenu, complete the instruction by adding [blank]-Administrator and confirm with **OK**.


Check the User and Password Settings:

Access the configuration program with buttons **MORE** and **Setup**, and select **USER & PASSWORD SETTINGS**. Check the table and, if necessary, restore your settings.

1.3.8 Configuration Menu SAVE AND EXIT

Use **SAVE AND EXIT** to terminate the configuration program. In certain cases (e.g. modification of device configuration), the ECOCONTROL application must be restarted and the message shown below will appear.

Example:



2. Operation

2.1 General

Switch the device on by connecting the supply voltage.

All operator input is done directly on the touch screen. The elements used for operation are Windows-like components like buttons, text boxes, drop-down menus etc. Input is done by slightly touching the monitor glass surface with the finger at the position where the appropriate input element is shown.

Before starting ECOCONTROL 2000 operation the device has to be configured using the Configuration Software described in Chapter 1.3 (page 5 ff.) of this manual to adapt it to your production line. This should be done by an experienced **SIKORA** technician.

ECOCONTROL Operation Mode:

The ECOCONTROL 2000 can be operated

- using the monitor touch screen
- via a communication link by an external line computer

The ECOCONTROL operation mode can be as follows:

- **external control only :**
Variables can only be changed via the communication link, i.e. display input is disabled.

- **external/internal control :**
Variables can be changed via touch panel or communication link, both have the same priority

The operation mode is set by the external computer with an according telegram, default setting is external/internal control.

Monitor Operation:

Different pages are presented. The standard monitor page displays the diameter measuring values and the wall thickness, together with nominal value and deviation, as well as information about automatic control influence. Additional pages show the measuring value in graphical display, with a diagram of the measuring value, in relation to the nominal value, vs. length, or statistical information about the measuring values after the end of production.

The operator can set or modify the nominal values, tolerance limits etc. Additionally, the operator can create and manage a Recipe Table containing the settings for various types of cables in production.

All operator input is done using the Touch Panel.

Operation by External Computer:

An external computer communicates with the ECOCONTROL 2000 by sending telegrams which are used to request or set values like nominal values, tolerance limits, control mode etc. For a description of the telegrams and their meanings refer to Chapter 3.2 and Fig. 52 *Serial Interface*.

Wall Thickness Measuring:

The insulation wall thickness is calculated by subtraction of the diameter values under consideration of the measured shrinkage and then displayed digitally. The values of the measured diameters are displayed as well. The calculated wall thickness is compared with the pre-set nominal value. Deviations of the wall thickness are sent to the analog output.

Tolerance limits can be set, separately for positive and negative deviations, any exceeding will be indicated by dry contacts switching over.

Each device is equipped with an internal validity check of measured values. It signalizes invalid values, which arise from a wrong position of the object to be measured or faulty exposure.

Diameter Measuring:

The diameters are measured optically. A light source (laser diode) serves as light background in relation to the dark cable. The cable covers the light beam partially, thus producing a shadow proportional to the diameter. Light and shadow are projected to the photodiode array of an electronic CCD-camera.

A delay time memory guarantees the evaluation of measured values at the same place. Then the wall thickness is calculated by subtraction, and under consideration of the shrinkage.

This actual value is compared with the pre-set nominal value. The difference between actual and nominal value is changed by a D/A-converter to an analog value from ± 10 V DC and sent to the analog output.

The actual value of wall thickness is compared with the tolerance limits. An exceeding causes a failure message by means of dry contacts.

2.2 Setting the Automatic Control

The multifunction control unit is a component for precise, automatic control of wall thickness. Either line speed or extruder screw r.p.m. can be controlled. The module is switched into the line of the drive (refer to Figure *Automatic*).

The control works with both diameter values, the warm and the cold one to calculate and consider the shrinkage. If a deviation occurs, the control changes infinitely variable the nominal value for the line speed or screw r.p.m. until the actual value is in accordance with the nominal value, the control display indicates the influence of the control signal.

The core diameter and filler diameter can also be controlled.

If the automatic control is switched off, the nominal value of the line is connected through, thus enabling manual control.

The control module allows a continuous control of the line speed or of the extruder screw speed (rpm). In case of a deviation between the measuring value and the selected nominal value, the controller continuously increases or decreases the line speed or extruder rpm, till the deviation is zero.

To optimize the control, the line should run with the most common cable type and line speed. Start the line and set the nominal value of the wall thickness and the shrinkage. At first the control works with the warm value, the cold value is used when the cable ran the line once completely, then the shrinkage is calculated.

The operator should now run the line with 3% oversize, before going in automatic mode. Switch the automatic "ON", within 20 seconds the control module reduces the oversize down to 1%, and within 1 minute down to zero. The control influence is shown on the monitor.

Select in the configuration program a shorter time for more control influence, i.e. the deviation is levelled out faster. Watch the display, if the influence is too fast the line starts to oscillate.

A longer time causes a slower influence, the time for levelling out is lengthen.

Very slow lines (speed less 10 times distance extruder - measuring head) or lines where the measuring head is mounted behind the cooling-trough require the additional SPEED influence function, the control works under consideration of line speed.

The speed of the line is automatically calculated using the pulses of the rotary pulse generator.

Run the line with a speed 10 times distance.

Example: Distance extruder - measuring head = 15 m
 line speed = 150 m/min

The minimal control time constant must be adjusted to 20 seconds as done at delivery.

When the line runs with a speed higher 10 times distance, the control time constant is 20 seconds, as pre-adjusted. With a lower speed the control time constant is enlarged proportional to prevent an oscillation.

The signal "control deviation" shows the difference between pre-set nominal value and displayed actual value.

±10 V DC voltage correspond to ±0.250 mm deviation.

After connection of a line recorder you can observe and recognize the effects of the AUTOMATIC mode upon your line under different speeds (e.g. start-up, acceleration, production, delay) and which deviations arise, particularly during acceleration and delay. Analyze the recorded values and check if everything functions as expected.

2.3 Determination of Nominal Values

After adjusting the control you should take some samples. While production runs and AUTOMATIC is switched ON you mark the cable as soon as it leaves the measuring head. At the same time you mark the deviation which was written by the line printer and note the pre-set nominal value.

You need:

- | | |
|---|------------------|
| - for cables up to 8 mm Ø resp. line speed faster than 300 m/min: | 5 samples à 20 m |
| - for cables from 8 up to 15 mm Ø resp. speed from 150 - 300 m/min: | 4 samples à 10 m |
| - for cables bigger than 15 mm Ø resp. speed slower than 150 m/min: | 3 samples à 5 m |

Measure the diameter / wall thickness of the samples at regular intervals so that you will obtain at least 20 values. Enter the measured values in a diagram. Now you can make out which deviations depending on the system occur with the different types of cable.


These deviations may not and cannot be controlled by the AUTOMATIC of the measuring device. The average value of the samples (shrinkage added) shall correspond with the displayed values.

The diagram shows you, how to set the nominal value to obtain the smallest permissible diameter/wall thickness value under consideration of line system deviations.

2.4 Sector Conductor Measurement

- to be implemented yet -

When performing sector measurement, observe the following parameter definitions for entering your recipe table data (see description **Monitor Page RECIPE TABLE** ff.)



Sector Conductor

Parameter	Name of Recipe Table Element
α	Angle
b	Thickness (b)
d	Height (d)
r_1	Radius (r_1)
r_2	Radius (r_2)

2.5 Monitor Operation


Switch the device on by connecting the supply voltage. First, the standard monitor display page appears, other pages can be accessed by touching the respective button. Remember that you have to log in first by entering your user name and -if specified- your password, as defined by the USER LEVEL & PASSWORD SETTINGS table described on page 17, unless your application has been configured to execute an automatic log in for a specified user (see description of configuration menu **APPLICATION PARAMETERS** on page 10).

Make sure all application settings are correct, see page 45 ff. for a description of monitor page **APPLICATION SETTINGS** and its functions.

User Log In / Log Off

At the bottom left of the monitor page appearing after starting the system, there is a button which is used for logging in to the ECOCONTROL Measuring Program resp. logging off from it.


Example:



Enter your password in the same way.

If your log in is successful, you will be able to access the application according to your user level. The inscription on the log in button changes to LOG OFF.

If your log in procedure fails, contact your administrator.




ECOCONTROL 2000 Application Structure

Structure of Standard Monitor Page

This page is split into several areas containing various elements like text boxes, text buttons, function buttons, toggle bars and a diagram viewport.

Example:



Operation is done by touching the buttons and bars presented as well as by touching the short-time diagram area.

When striking the toggle bar **LINE DISPLAY**, the text boxes containing the diameter values **Diameter 1** etc. will be replaced by the line diagram and vice versa.

When striking the toggle bar **ECCENTRICITY**, the text box in the middle and the short-time trend diagram will be replaced by the cable eccentricity display and vice versa.

The parameters being displayed in the text bars can be selected and their nominal values can be set by striking the respective bar and choosing from the submenu unfolding. To enter a nominal value, use the numerical keyboard appearing accordingly. See the examples given below.


Standard Monitor Page / Measuring Value Display

This is the standard measuring value display, which may vary in certain aspects according to your line configuration.


Example: Explanation of Measuring Values Displayed

Here, the line is equipped with two LASER 2000 XY diameter measuring heads, one CAPACITANCE 2000 capacitance measuring device and one CENTERVIEW 2000 gauge head for measurement of eccentricity, diameter and ovality. Various values concerning the parameter wall thickness, diameters 1, 2 and 3 and the short-time trend diagram are shown.

Information coming from lump and spark detectors (if installed) is displayed in a separate window.



Example: General Operation



Explanation concerning **Recipe** function:


For different cables in production, their production parameters like nominal values of diameters and wall thickness and cable type can be kept as a set of data in a so-called recipe table. Each set of data is identified by its name, the recipe code. The desired recipe code is called by entering the appropriate name. If a recipe code has been selected, its parameters become valid for the production running immediately. They cannot be modified by operator entries on the standard monitor page, i.e. by manual input. This remains disabled until you leave the recipe mode by entering MANUAL instead of a recipe code.

Standard Monitor Page / Measuring Value Display / Text Bar Operation

Upon touching one of the measuring value text bars, a submenu will unfold offering a selection of various functions, such as

- choosing the parameter whose value is to be shown in the text bar besides the nominal value
- setting the nominal value and tolerance values for the measuring value selected
- call device information
- start the calculation for functions FFT / RL Prediction (Option)
- switching the automatic mode

Depending on which measuring value has been chosen, and which options are contained in your application, the range of functions offered will be different. The following illustrations show some examples.



Example: Using the text bar contained in the **DIAMETER 1** text box to set the nominal value

Strike the **DIAMETER 1** text bar...

and select **NOMINAL** from the submenu unfolding

Via the numerical keypad appearing next, enter the value as described below and confirm with **OK**. The new value becomes valid immediately for the production running.

Use the keypad to enter your value: touch the according numbers and confirm with **OK**.

NOMINAL DIAMETER 1 [mm]

Quit without changing the existing value

Clear entry


Backspace

Confirm entry and close

Explanation of submenu concerning the **Diameter 1** text bar:


DEVICE INFORMATION	Display Diameter 1 Measuring Device Information, see example below.
NOMINAL	Set Diameter 1 Nominal Value, enter via numerical keypad appearing. The actual nominal value is always displayed in upper half of text bar.
TOLERANCE	Set upper and lower tolerance limit for Diameter 1, enter values via numerical keypad appearing. Parameter is selected for display in text bar.
DEVIATION	Select this parameter for display in text bar.
STD Deviation	Select Standard Deviation Diameter 1 for display in bar (for this function, recording of production data must have been started, see pages 43ff).
OVALITY	Select Ovality Diameter 1 for display in text bar.
XY	Select Diameter 1 Value X / Diameter 1 Value Y for display in text bar.
POSITION	Select Horizontal/Vertical Pos. (only with sector measurement) Diameter 1 for display in text bar.
FFT / RL PREDICTION	Call functions FFT / RL Prediction (Option), see p. 61ff.

Example
of Measuring Device Information shown:



Example: Using the text bars contained in the big measuring value text box

Use the text bars to choose the parameter to be displayed in the right bar and / or to set various nominal values for certain parameters. The left text bar will always display the nominal value, however this can be used for selecting and setting as well.



Explanation of submenu:

DEVICE INFORMATION	Display Diameter 2 Measuring Device Information, see example below.
NOMINAL	Set Diameter 2 Nominal Value, enter via numerical keypad appearing. The actual nominal value is always displayed in upper half of text bar.
TOLERANCE	Set upper and lower tolerance limit for Diameter 2, enter values via numerical keypad appearing. Parameter is selected for display in text bar.
DEVIATION	Select this parameter for display in text bar.
STD DEVIATION	Select Standard Deviation Diameter 2 for display in bar (for this function, recording of production data must have been started, see pages 43ff).
OVALITY	Select Ovality Diameter 2 for display in text bar.
X Y	Select Diameter 2 Value X / Diameter 2 Value Y for display in text bar.
POSITION	Select Horizontal/Vertical Pos. (only with sector measurement) Diameter 2 for display in text bar.
FFT / RL PREDICTION	Call functions FFT/RL (Option)
AUTOMATIC	Access additional dialog box for switching the automatic mode <div> <div> ON Switch AUTOMATIC on OFF Switch AUTOMATIC off HOLD AUTOMATIC mode is "frozen", i.e. the control operates using the last valid value. Prompt accordingly. </div> <div> </div> </div>

Explanation concerning switching the AUTOMATIC mode:

Check set nominal value wall thickness, the shrinkage for the cable type and the control mode. Touch

button **AUTOMATIC**, and confirm switching **AUTOMATIC** **ON** or **OFF**. At first the control works with the warm value, the cold value is used when the cable has run the line once completely, then the shrinkage is calculated and shown above the wall thickness value.

The deviation between automatic control and manual adjustment (in percent) can be seen in the respective text bar, if selected (see description of text bar operation above). When the value becomes negative, the manual adjustment of wall thickness has been too big. When the value becomes positive, a switch-over to manual operation would lead to a wall thickness which is too thin. Note : control influence is limited ($\pm 50\%$), the drive should be corrected before the value of deviation increases too much.

When the device or the automatic is switched off the nominal value of the line is connected through to the output. (CAUTION, if the device is switched off during automatic control, there might be an undefined state during switch-over which may lead to lumps.)

If the camera supervision finds a fault, the automatic is "frozen", i.e. the control works with the last valid value.

Standard Monitor Page / Measuring Value Display / Diagram Viewport Operation

Example: Choosing of Short-Time Trend Parameter

Open the respective submenu by touching the short-time trend diagram area

From the submenu, choose the parameter which is to be shown in the short-time trend diagram.


DIAMETER 1	Show short-time trend diagram of parameter Diameter 1.
DIAMETER 2	Show short-time trend diagram of parameter Diameter 2.
DIAMETER 3	Show short-time trend diagram of parameter Diameter 3.
WALL THICKNESS	Show short-time trend diagram of parameter Wall Thickness.
ECCENTRICITY	Show short-time trend diagram of parameter Eccentricity.
CONCENTRICITY	Show short-time trend diagram of parameter Concentricity.
SHRINKAGE	Show short-time trend diagram of parameter Shrinkage.
Log file	Select log file (only if Test Display Enabled , see p. 8)

Standard Monitor Page / Using the Toggle Bars


There are two toggle bars. Use the

- left one to toggle between the display of diameter measuring values (**DIAMETER 1** etc.) and the line diagram in the upper part of the standard monitor page and the
- right one to toggle between the measuring value display with trend window and the eccentricity display.

Example: Calling the Line Display
(Line Display is explained on page 37)




Example: Calling the Eccentricity Display
(Eccentricity Display is explained on page 36)



You may also use the left toggle bar to call the line representation.


Switching the display:



Standard Monitor Page / Eccentricity Display

This page shows the cable eccentricity in graphical representation and as numerical value.

Example: Explanation of Eccentricity Display




Standard Monitor Page / Line Display


Please remember, the line configuration shown here serves as an example. As each line is configured individually, this may look different according to your line equipment.

Above the illustrations representing the line equipment their respective measuring or test result or status information is displayed.

Example: Line Display



Explanation:



Standard Monitor Page / Button **RECIPE CODE**

A recipe code is a name for a set of data containing specific values like nominal and tolerance values as well as other specific cable parameters used for the production of a certain cable. You can keep several of these in a recipe table (this is described on pages 47ff). If you want to apply a certain recipe during production, enter its name using button **RECIPE**.

Example: Calling a recipe code

As indicated by the text string shown, at this moment there is no recipe being used but manual settings. To call a recipe, strike button **RECIPE** to open the alphanumeric keypad for entering its code.

Enter recipe code and confirm with **OK**. The data of the recipe code chosen will become valid immediately for the production running. Of course, there must exist an entry corresponding to the code entered in your recipe table. If not, an error message will appear.

Standard Monitor Page / Button REPORT

With button **REPORT**, open the submenu to


- start and terminate the recording of production data which are evaluated and displayed by functions TREND, STATISTICS and the printer report, and
- call the monitor pages for functions TREND and STATISTICS.

The inscription shown on button **REPORT** indicates if recording is ON or OFF.






The data of one production can be saved to observe the trend of certain selectable parameters and to evaluate them statistically. However, production data can only be recorded if this activity has been started with **REPORT / START**, which is usually done at the beginning of a production.

As long as recording is **ON**, functions TREND and ONLINE STATISTICS can be called using the respective buttons. At the end of a production, data recording is stopped with **REPORT / STOP**. Now, the production data recorded are evaluated statistically and you can call function STATISTICS with **REPORT / STATISTICS**. In case a new production is to follow immediately, you can also proceed with **REPORT / START** which will be interpreted as **REPORT / STOP** followed directly by **REPORT / START**.

Example: At the beginning of production, start data recording with **REPORT** and **START**





As long as **REPORT** is **ON**, the submenu bar contains these buttons .

	Set additional parameters for data recording (see below).
	Strike button to call monitor page TREND (see p. 43). Only enabled if recording of production data has been started.
	Use at beginning of production to start data recording for functions TREND / STATISTICS and to start the printer report (Option). Button REPORT indicates ON .
	Show online statistical diagram on monitor page STATISTICS. Only enabled if recording of production data has been started.
	Use at production stop to close production data recording. These are evaluated, see p. 45. The printer report (Option) is terminated. Button REPORT indicates OFF .

Once a production has been completed and data recording has been stopped (**REPORT** / **STOP**), the button for calling the production statistics appears as well.

Explanation concerning button **Statistic/Printer Setting**

Touching this button opens a page used for setting data recording parameters. Choose if you want to store the trend data or the statistical data in a file or on hard disk.


For instance, if you decide to store the trend data, you can select the file format.

Monitor Page TREND


Access this page with buttons **REPORT**, **TREND** on the main monitor page. It shows the process of various measuring values according to the length.

Please note that for this function data recording must have been started before by using buttons **REPORT** and **START** (button REPORT indicates ON), see page 39.

Example:




Example: Selecting a parameter for the Trend Diagram




Example: Trend Display Buttons

Use the buttons below each trend display for modifying the axis resolution, for scrolling and to mark the upper and lower tolerance limit. Also, you may save the data displayed on diskette.

In the example shown here, the trend display has been set to show the two parameter **Diameter 3** and **Wall Thickness**. For each parameter, the upper and lower tolerance limit are displayed as well.



Example: Scaling the Trend Display



Monitor Page STATISTICS


After a production has been closed or also during production (ONLINE STATISTICS) use this function for statistical evaluation and display of the production data recorded. The parameter to be shown here can be selected by the operator.

A bar diagram shows the deviation classified in up to 12 percentual parts, e.g. 97% of all values differed between -0.45 and 0.45 mm from the nominal value, or 3% of all values exceeded the tolerance.

Please note that for this function data recording must have been started with buttons **REPORT / START** (refer to description of button **REPORT** on page 39).

Example:


Below the diagram, the evaluated data of the last production are listed, e.g. mean value, smallest value, the indices CP, CPK, etc.



Abbreviations:

LSL lower specification limit
 USL upper specification limit
 CP process capability
 CPK critical process capability

Example: Setting the number of diagrams to be shown



Additional Application Settings

Access with button **MORE** on the standard monitor page.

Use the additional buttons to set the control mode, select the cable type and to access the recipe table (see page 38ff.). The actual settings are displayed in the according text boxes.

Please note that the monitor pages shown here are merely examples used for explanation. They may vary according to your line configuration and the setting chosen.

DIAMETER 1 [mm]
8.753
NOM : 8.700 mm
TOL : + 0.500 mm / - 0.500 mm

WALL THICKNESS [mm]
0.530
NOM : 0.500 mm
SHRINKAGE = 0.0 %

DIAMETER 3 [mm]
9.558
NOM : 9.500 mm
TOL : + 0.500 mm / - 0.500 mm

LINE DISPLAY
SIKORA ECOCONTROL 2000
Recipe: MANUAL
Lumps: 0
Neckdowns: 0
PRESET RESET RECALL

DIAMETER 2 [mm]
9.760
NOM : 9.700 mm
AUTOMATIC: 0 %
Hot/Cold OFF, Diff. Diameter 0.189 mm
+2 %

ECCENTRICITY
DIAMETER 2
10.700
9.700
10.55 10.56 10.57 10.58

DIAMETER 1 [mm]
8.753
NOM : 8.700 mm
TOL : + 0.500 mm / - 0.500 mm

DIAMETER 2 [mm]
9.753
NOM : 9.700 mm
AUTOMATIC: 2 %
Hot/Cold OFF, Diff. Diameter 0.221 mm
+1 %

ECCENTRICITY
DIAMETER 2
10.700
9.700
10.39 10.40 10.41 10.42 10.43

Setup **SHUT DOWN** **Statistic/Printer Setting** **Error Listing** **MORE**

Touch to switch to additional buttons for access...

Switch back

Terminate ECOCONTROL application and close down PC

Call Configuration Program (see page 5 ff.)

Show application log files, such as error log file or pre-printout (Option Printer)

Set additional parameter for trend/statistics data recording (see description on p. 39 ff.)

Example: Checking the Log File

The screenshot displays the SIKORA ECOCONTROL 2000 interface. At the top, three measurement boxes show: DIAMETER 1 [mm] 8.765, WALL THICKNESS [mm] 0.466, and DIAMETER 3 [mm] 9.561. Below these, a large central display shows DIAMETER 2 [mm] 9.753. To the left of the central display, there are buttons for 'Recipe: MANUAL', 'Lumps', 'Neckdowns', 'PRESET', 'RESET', and 'RECALL'. To the right, there is a 'Fail.log' window showing a list of application events. A yellow callout box points to the 'Fail.log' window with the text 'Touch to open Fail Report...'. Another yellow callout box points to the 'Fail.log' window with the text 'The file named Fail.log contains application messages like the ones shown in this example. You can store this file on diskette, print it out or discard it, see icons on bottom of page.' A third yellow callout box points to the bottom of the 'Fail.log' window with the text 'Touch to exit from this page.'

DIAMETER 1 [mm] 8.765
NOM: 8.750 mm
TOL: + 0.500 mm / - 0.500 mm

WALL THICKNESS [mm] 0.466
NOM: 0.500 mm
SHRINKAGE: - 0.0 %

DIAMETER 3 [mm] 9.561
NOM: 9.500 mm
TOL: + 0.500 mm / - 0.500 mm

LINE DISPLAY

DIAMETER 2 [mm] 9.753
NOM: 9.750 mm
AUTOMATIC: 2 %

Hot/Cold OFF, Diff. Diameter 0.221 mm

Recipe: MANUAL

Lumps 0
Neckdowns 0

PRESET RESET RECALL

Fail.log

09 11 10:33:41 Application ends
09 11 10:33:52 Application starts
09 11 10:33:52 LOG IN - 9
09 11 10:33:53 Reset Com Error - 6
09 11 10:33:53 Reset Com Error - 6

Touch to open Fail Report...

The file named Fail.log contains application messages like the ones shown in this example. You can store this file on diskette, print it out or discard it, see icons on bottom of page.

Touch to exit from this page.

Monitor Page RECIPE TABLE

Access this page with button **RECIPE TABLE** on the bottom of monitor page **Application Settings**.

The recipe table is a list containing data sets of the nominal and tolerance values as well as other specific cable parameters for various cable products. Each data set is identified by its **RECIPE CODE**. You may define new recipe codes by entering their specific data, search for existing recipe codes or delete them. A **LIST** function shows a table of all existing recipe codes.

The recipe code being used in production is indicated on the standard monitor page on button **RECIPE**.

Example:

See explanation below

RECIPE CODE	type 12			
	NOMINAL	CHANGE FACTOR	+ TOLERANCE	- TOLERANCE
DIAMETER 1	4.000 mm			
DIAMETER 2	9.700 mm	0 %	0.100 mm	0.100 mm
DIAMETER 3	9.600 mm	0 %	0.100 mm	0.100 mm

Lump tolerance	0.50 mm		ECCENTRICITY	0.010 mm
Neckdown tol.	0.50 mm		CONCENTRICITY	95.0 %
Length tolerance	0.0 mm		Spark Tester	12.0 kV

Call additional table containing FFT/RL settings (Option FFT/RL Analysis)

FFT/RL ⬆ ⬇ ⬆ NEW FIND DELETE PRINT LIST EXIT

Scroll through existing recipes

Define new recipe code

Search for recipe code. Enter code via keyboard appearing.

Delete recipe shown

Print list of existing recipe codes

Show list of existing recipe codes

Explanation concerning parameter **CHANGE FACTOR**:


This factor defines to which amount the diameter nominal settings given here can be varied manually when this recipe is used for the production running.

For instance, in the example given above, a **CHANGE FACTOR** set to 10 % for parameter **DIAMETER 2** allows the nominal settings for **DIAMETER 2** to be modified manually during production in a range of 8.730 mm to 10.670 mm. A value of 0 % means that no changes are allowed.

Monitor Page RECIPE TABLE / Button NEW

A keyboard is presented for entering the new recipe code.

Example: A new recipe with code **type 101** is to be created



Enter the new recipe code and confirm with ENTER. The keyboard disappears. Then, define the new set of data for this code: select the respective parameter by touching one of the text boxes shown white and enter its value via the keyboard appearing. Characters shown in red mark mandatory values.

Example: Parameter Setting for the new recipe code named **type 101**

RECIPE CODE	type 101			
	NOMINAL	CHANGE FACTOR	+ TOLERANCE	- TOLERANCE
DIAMETER 1	0.000 mm			
DIAMETER 2	0.000 mm	0 %	0.000 mm	0.000 mm
DIAMETER 3	0.000 mm	0 %	0.000 mm	0.000 mm
Lump tolerance	0.00 mm			
Neckdown tol.	0.00 mm			
Length tolerance	0.0 mm			

ECCENTRICITY	0.000 mm
CONCENTRICITY	0.0 %
Spark Tester	0.0 kV

Touch text box,
in this example the one
representing the setting for
ECCENTRICITY. A numerical
keypad appears for input.

Enter the nominal value of
ECCENTRICITY for the data
set of new recipe code **type**
101 via the numerical
keyboard. Confirm with **OK**.

ECCENTRICITY
=

1	2	3	OFF
4	5	6	CE
7	8	9	<--
.	0	-	OK

FFT/RL
⬆
⬇
NEW
FIND
DELETE
PRINT

Example: Parameter Setting for new recipe code, button **FFT/RL**

RECIPE CODE type 101

	NOMINAL	CHANGE FACTOR	+ TOLERANCE	- TOLERANCE
DIAMETER 1	0.000 mm			
DIAMETER 2	0.000 mm	0 %	0.000 mm	0.000 mm
DIAMETER 3	0.000 mm	0 %	0.000 mm	0.000 mm
Lump tolerance	0.00 mm			
Neckdown tol.	0.00 mm			
Length tolerance	0.0 mm			
ECCENTRICITY	0.000 mm			
CONCENTRICITY	0.0 %			
Spark Tester	0.0 kV			

Touch button **FFT/RL** to open the setting page for the **FFT/RL** parameter...

... and enter the values.

RECIPE CODE type

FFT Frequency Range [Hz] 0.24

Operating Freq Range [MHz] 0 ... 0.0

Nominal Line Speed [m/min] 0.0

Conductor Attenuation [dB/100m] 0.0

Dielectric Attenuation [dB/100m] 0.0

Cable Construction Coax Solid/Dual Conductor

Nom. DM Insul Core [mm] 0.000

Expected Sampling Time 4.1 min

FFT Length 512

Rel. Propagation Velocity [%] 0

Cable Length [m] 0.00

at Frequency [MHz] 0.0

at Frequency [MHz] 0.0

FFT Average 0

Nom. DM Conductor [mm] 0.000

Additionally, critical lines for the RL diagram can be set. Touch this button ...

...and open the page used for entering the values.

RECIPE CODE type

F [kHz]	0-200	200-400	400-600	600-800	800-1000	1000-1200	1200-1400	1400-1600	1600-1800	1800-2000	2000-2200	2200-2400	2400-2600
S[%]	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
SRL [dB]	-∞	-∞	-∞	-∞	-∞	-∞	-∞	-∞	-∞	-∞	-∞	-∞	-∞
[SRL] [dB]	+∞	+∞	+∞	+∞	+∞	+∞	+∞	+∞	+∞	+∞	+∞	+∞	+∞
VSWR	1	1	1	1	1	1	1	1	1	1	1	1	1

F [kHz]	2000-2800	2800-3000	3000-3200	3200-3400	3400-3600	3600-3800	3800-4000	4000-4200	4200-4400	4400-4600	4600-4800	4800-5000	5000-5200
S[%]	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00
SRL [dB]	-∞	-∞	-∞	-∞	-∞	-∞	-∞	-∞	-∞	-∞	-∞	-∞	-∞
[SRL] [dB]	+∞	+∞	+∞	+∞	+∞	+∞	+∞	+∞	+∞	+∞	+∞	+∞	+
VSWR	1	1	1	1	1	1	1	1	1	1	1	1	1

Monitor Page RECIPE TABLE / Button LIST

This function displays a list of the existing recipe codes and their parameters. The blue bar marks the recipe code which has been chosen for the production running.

Example:

RECIPE	D1	D2	D3	ECC	CONC	HV
type	0.000	0.000	0.000	0.000	0.0%	0.0
type 101	0.000	0.000	0.000	0.000	0.0%	0.0
type 12	4.000	9.700	9.600	0.010	95.0%	12.0

⬆
⬇
EXIT

Monitor Page FFT/SRL Parameter - Option -

Use this page to set the parameters used for executing the analysis functions FFT (FFT : Fast Fourier Transformation) and SRL (SRL : Structural Return Loss) . Access to this page is limited to user level **System Configurator**.

How to get there:

If your system includes the Option FFT / SRL Analysis Functions, the according button for accessing them will appear in the submenus described earlier in this manual, see page 19ff.

*Striking this button will open Monitor Page FFT Spectrum (see below). There, use button **FFT/RL Parameter** to open Monitor Page **FFT/SRL Parameter**.*

DEVICE INFORMATION
NOMINAL
TOLERANCE
DEVIATION
STD Deviation
QUALITY
XY
POSITION
FFT / RL PREDICTION

General Remarks

Concerning the Application of Analysis Functions FFT / SRL:

Use these functions to directly obtain information for optimizing your production process.

During the production of high quality cable production, continuous controlling of cable parameter in regard to periodic irregularities is mandatory. By analysing for instance the diameter measuring values from a LASER 2000 XY measuring head with the Fast-Fourier-Transformation (FFT), periodically occurring irregularities during cable extrusion can be detected early. Periodic variations of the cable diameter value may be caused for instance by such irregularities as the so-called extruder pumping, imbalances of rotating parts, cyclic fluctuations of line speed or degree of foaming and/or periodic preheat non-uniformities.

While periodic fluctuations are, in general, hard to observe from the course of measured diameter vs. time, an analysis of these data in the frequency domain allows for early detection of periodically reoccurring fluctuations. These influences will show in the spectrum as peaks, whose height indicates the periodic diameter fluctuations amplitude in $\mu\text{m/m}$ resp. mm/m . Moreover, the computed FFT spectrum provides helpful information for identifying the causes of cyclic irregularities during cable production, especially when changing any of the production parameter like for example line speed.

FFT spectrum analysis and structural return loss (SRL) predictions are helpful tools for detecting periodic cable diameter fluctuations and estimating their effects on the transmission quality of the finished cable.

Use this monitor page to set all parameter needed before executing the analysis functions. Parameter settings are done by touching the respective buttons, most of which are self-explanatory. As the button is touched, values are stepped up or down, if preset, or a numerical keypad is offered for entering the desired value. Acknowledge the entered value with **OK**. See the example below for explanation.

After all values have been set, transmit them using button **Send Data** to the measuring device.

Example: FFT Parameter Set-Up for CAPACITANCE

Frequency range for FFT spectrum calculation resp. SRL prediction.
 FFT and SRL range (see parameter Operating Freq. Range) setting is coupled, i.e. when setting a range the other one will be adapted automatically. Thus set only one range at a time. The number of ranges offered for selection may vary according to setting of parameter Line Speed and Rel. Propagation Velocity.
 The frequency range is limited -caused by the physical dimensions- by the electrode low pass characteristics, i.e. selectable frequency ranges are below the Cut-Off Frequency.

Number of capacitance measuring values to be used for FFT execution.
 Higher values : higher frequency resolution of FFT Spectrum resp. SRL Diagram, however also increasing time period needed for data collection.

Info Text Box, shows name of recipe currently being used in production if a code has been selected, else MANUAL.

SRL Prediction Range

Info Text: type of measuring device, ID number and version no. of measuring software

Capacitance: Type 2010
 Version: V4-03
 ID: 5568-17

Shows time needed for data collection, depending on parameter settings

Expected sampling time: 1.6 min

Send values displayed to measuring device specified above or to all measuring devices connected

Send Data to Caps

Send Data to All Devices

Exit

Save Data and Exit

Cable : MANUAL

FFT Range: 0..2.6 Hz

FFT Length: 512

Operating Freq. Range: 0..0.0 MHz

Line speed: 50.0 m/min

Cable length: 100.0 m

Rel. propagation vel.: 80 %

Cable Construction: Coax: Solid Cond.

Cond. Attenuation: 1.50 dB/100m

Dielectric Attenuation: 1.50 dB/100m

at Frequency: 600 MHz

at Frequency: 600 MHz

Cable length for which SRL is to be predicted

Cable Type (TP: Twisted Pair)


Signal propagation velocity at the produced cable type, relative to the speed of light. Typically 66% for solid PE insulation, higher values for foam-insulated cables.

Conductor Attenuation [dB/100m]
 That component of the forward attenuation of the cable produced, which is due to losses in the conductor. Its value rises with the square root of frequency.
 Dielectric Attenuation [dB/100m]
 That component of the forward attenuation of the cable produced, which is due to dielectric losses. Its value rises proportionally with frequency.
 Both parameter should be set for cable operating frequencies lying inside the SRL frequency range selected, preferably in the center of that range.

Monitor Page FFT Spectrum - Option -

Before executing this analysis function, the parameter needed must have been set accordingly on Monitor Page **FFT/SRL Parameter** . Please also note the explanations concerning the FFT analysis given on page 51 ff.

Example: Structure of Monitor Page, General



Note concerning button **Display Mode** :

Use this button to specify the Y-axis unit, i.e. the spectrum representation of the measured quantity. This may be shown as


- FFT Spectrum (Linear)
meaning the linear spectral amplitude of the measured quantity (diameter, capacitance etc.) is displayed, Y-axis scaling is linear in such units as μm or fF/m.
- FFT Spectrum (Log) in dB
meaning the FFT spectrum is displayed in logarithmic units, Y-axis scaling is logarithmic.

The according calculation formulas are as follows:

Display Title	FFT Diagram shows...	Calculation Formula
FFT (linear)	FFT Spectrum (linear)	Δs
FFT (log)	FFT Spectrum (Log) in dB	$20 \log \frac{\Delta s}{s}$

s : measured quantity (diameter, capacitance etc.)
 Δs : linear spectral amplitude (output of FFT algorithm)
 \bar{s} : mean value of measured quantity


Example: Spectrum Diagram, General View/Detail View



Example: Using the Marker, Diagram Area Scaling

By setting a so-called marker you can read out the exact values of diameter amplitude and fault length at a certain selectable frequency. You may also use the marker as an identifier within the frequency range, e.g. as a reference point when observing certain frequencies.

Position the marker on the frequency curve shown in either the detail view or the general view using the mouse or the respective positioning keys.



Note concerning Fault Length Axis: Values shown on this axis (= fault length on the cable) are calculated from the frequency axis values using the value of line speed as set on Monitor Page **FFT/SRL Parameter** under **Line Speed**. In the configuration menu, specify if Line Speed Information is to be used for FFT/SRL calculation.

Monitor Page SRL Diagram - Option -


The most common method used for checking the quality of data and RF cables is the measurement of structural return loss of a length of cable as a function of frequency within the range of operating frequencies the cable is specified for. Structural return loss (SRL) is the ratio - expressed in dB - between the fraction of input signal strength reflected by structural fluctuations along the entire cable length and the input signal strength.

In order to optimize cable quality and minimize the number of rejects, it is highly desirable to detect problems due to periodic irregularities as soon as possible in the manufacturing process. The online SRL prediction from short-time cable capacitance values supplies according information.

For the execution of this analysis function the respective parameter settings must have been done on Monitor Page **FFT/SRL Parameter** (page 51) . Please note the explanations given there concerning the FFT analysis as well.

Settings for the spectrum detail view are identical to those on Monitor Page **FFT Spectrum**. To avoid repeating please refer to page 53 .

Example: Structure of Monitor Page



Note concerning button **Display Mode** :

Use this button to specify the Y-axis unit, i.e. representation of the reflection coefficient R . There are different forms in use to represent this basic ratio. The different quantities and how to calculate them from R are given in the table below.

You can select one of these representations

- Reflection Coefficient R [%]
Y-axis scaling is linear, range is 0...100 %.
- SRL in dB
Y-axis scaling is logarithmic.
- $|SRL|$ in dB
Y-axis scaling is logarithmic.
- VSWR (Voltage Standing Wave Ratio)

The according calculation formulas are as follows:

Display Title	SRL Diagram shows...	Calculation Formula	Typical Range
Reflection Coefficient	Reflection Coefficient R	$R = 100[\%] \cdot R$	0 ... 100 %
SRL	SRL in dB	$SRL = 20 \cdot \log R$	-100 ... 0 dB
$ SRL $	SRL, absolute value, in dB	$ SRL = 20 \cdot \log R $	0 ... 100 dB
VSWR	Voltage Standing Wave Ratio	$VSWR = \frac{1 + R}{1 - R}$	1 ... ∞

2.6 Maintenance and Trouble Shooting

2.6.1 Maintenance

Ecocontrol Monitor:

Clean the outer glass screen of the monitor with a soft cloth and use a mild detergent as often as necessary. However, always switch OFF the device first to prevent faulty operation.

Measuring Head(s) LASER 2000 XY / LUMP 2000 XY:

The measuring head does not need any maintenance. What we recommend is that you take care the openings for the light are kept clean and free of any kind of dirt. To make sure, check the openings regularly, for instance after each production.

Refer to the respective manual supplied and proceed as described.

2.6.2 Trouble Shooting

If the self diagnostic system detects a malfunction, the display will indicate an information about the type of fault, the diameter display shows HELP and additionally the dry contact ALARM switches over (closes).

The following alarm messages may appear:

GLASS DIRTY

The device cannot clearly recognize a measuring object, because f.e. dirt or similar is interrupting the light beam and the device makes out several objects.

NOTE: Please contact our service if the cleaning of the glasses is not successful, i.e the message will not disappear.

CABLE TOO LOW

The wire leaves the measuring range towards the bottom.
Check the height adjustment.

CABLE TOO HIGH

The wire leaves the measuring range towards the top.
Check the height adjustment.

UNDEREXPOSED

The light is not sufficient for measurement, clean the lenses.

COMMUNICATION ERROR

A fault on the interface card to the measuring head or no measuring values, interface to measuring head interrupted, i.e. interface connection cable defect or pulled off.

Time Out

Device cannot be accessed. Check device interface, or check Program Version of LASER or ECOCONTROL application software, check error log file

Initialization


Communication to device is being started.

These messages are shown at the diameter display, the corresponding measuring head or device has to be checked. The wall thickness display always shows HELP when a fault is indicated.

Errors concerning the Profibus System Connection (Option) are indicated on the monitor page by a red flashing text box **Profibus ERROR** appearing at the bottom of the page (just over button SHUTDOWN). Check the connection cable or your bus system.


There is a three-coloured diode in the cover of most measuring heads (light source side, accessible without opening the measuring head!) which can be used for diagnosis:

Example: LASER 2010 XY Measuring Head LED signals




The monitor display shows HELP, when the validity check of the camera supervision detects a fault, text information is displayed in the corresponding diameter window, the contact ALARM switches.

Example: Message during Start-Up



Example: Error Messages




3. Technical Information

3.1 Specification

	ECOCONTROL 2000
Dimensions Display Unit	400 x 520 x 254 mm (16 x 20 7/8 x 10 2/8")
Dimensions Mounting Frame	355 x 483 mm (14 3/16 x 19 5/16") for 19" rack assembly
Voltage Supply	230 / 115 V AC \pm 15%, 50...60 Hz (selectable)
Power Consumption	200 VA
Temperature Range	+5...+50 °C (+40...+125 °F)
Air Humidity	max. 90 % (without condensation)
Weight	approximately 13.5 kg
Interfaces	2 Serial Interfaces RS485 (optionally up to 4 additional interfaces) Serial Interface RS232 Parallel Interface (Printer Connection) - Option - Digital Input Analog Output DEVIATION (max. load 5 mA) Relay Contacts ALARM, \pm TOL (max. load 24 V DC, 0.5A) 2 Extruder/Line Control Interfaces (1 standard, 2 optionally) Profibus DP Connection - Option - External VGA Connector*) External Keyboard Connector*)

*) for service only




^{*)} for service only

3.2 Serial Interface for Communication with External Computer/PC

Use the bidirectional serial interface RS232 (Plug / St. 8) to connect the ECOCONTROL 2000 to a computer / SPC. The computer can then set nominal values, tolerances, shrinkage, control mode etc, and read the actual values. For a description of the telegrams refer to Fig. 52 *Serial Interface*.

Transmission Mode	START-STOP asynchronous without Hardware-Handshake
Transmission Range	RS232 : max. 15 m
Connection Cable	DUE 4503 Li2Y(St)+CY or LIFYCY
Access	MASTER-SLAVE (ECOCONTROL acting as SLAVE)
Data Security	Parity Bit, Checksum Sign
Format	ASCII Code



1 = Start Bit
 2 = 1st Data Bit LSB
 n = last Data Bit MSB
 x = Parity Bit
 z = Stop Bit

Number of Data Bit	7
Parity Bit	ODD
Stop Bit	1
Transmission Speed	2400 Baud (bit/s)

Description of Telegrams see Fig. 52 *Serial Interface*.

3.3 Profibus DP - Option -

The device interface supplies the voltage needed for the profibus load resistance. The load resistance itself is not integrated. In order to keep a reliable system we recommend installing a terminating element, like for instance the Siemens "Abschlußelement für Profibus" Order No. 6ES7972-0DA00-AA0. If an *actor* or *sensor* is used as terminating element for the bus system, removing this element will not remain without consequences.

Transmission Mode	L2-Bus (RS485) according to EN 50170
Transmission Speed	up to 12 Mbaud with autodetection
Access	MASTER-SLAVE
Data Format	refer to PROFIBUS DIN 19245 Part 3

The measuring device acts as SLAVE. Its address is set to 5, this value can be changed using the program named COMPRO which is supplied together with the ECOCONTROL software. You can find COMPRO on your desktop or you may start the program with **Hilscher_Profibus/compro.exe /a:D0000**. However, before starting COMPRO, first terminate the application software with keys ALT, F4. For Ecocontrol devices with the operating system Windows 2000 the Com2 interface of the Ecocontrol will be connected with the Profibus diagnostic interface. For this connection the delivered Profibus diagnostic contact has to be used.

Setting the Profibus Address with Program COMPRO

- Terminate the application software with keys **ALT F4**.
- Start COMPRO, either from your desktop or by using the **Start** button and entering **Hilscher_Profibus/compro.exe /a:D0000**.
- Acknowledge the opening COMPRO Text Box ECO with key **ENTER**.
- From the COMPRO menu bar, choose as follows:
 - **DATENBANK**
 - **Editieren**
 - **Setup**
 - In the text box appearing, enter the new bus address and strike key **F10**.
 - Strike key **ENTER**.
 - Strike **Esc**.
 - **Speichern**
 - **In ECO**
 - Strike **Esc**.
 - Strike **Esc**.
 - Strike **Esc**.
- From the COMPRO menu bar, choose as follows:
 - **ONLINE**
 - **Datenbank**
 - **Download**
 - Strike key **ENTER**.
 - Strike **Esc**.
 - Strike **Esc**.
 - Strike **Esc**.
- From the COMPRO menu bar, choose **ENDE** to terminate COMPRO.
- Restart the device so the new bus address becomes valid.


LSAP's and DSAP's can be used from 0 ... 62.

A projecting file named HIL_7504.GSD is supplied together with your software.
Orientation of data with length > 1 byte is : MSB ... LSB.

Measuring Value Representation:

For the parameter listed below, data resolution and/or measuring unit are according to device configuration (see chapter 1.3 Configuration)! For all others, resolution and unit are listed in the table of telegrams below.

Parameter	Data Range	Resolution	Unit according to configuration
Nominal, Actual and Tolerance Values of Diameter, Eccentricity, Wall Thickness	0...65535	according to configuration xx.xxx xxx.xx	[mm] or [inch]
Nominal, Actual and Tolerance Values of Capacitance	0...65535	fixed xxx.xx	[pF/m] or [pF/ft]
Tolerance Values Lump/Neck	0...65535	fixed xxx.xx	[mm] or [inch]



Data to ECOCONTROL 2000 (Output to SLAVE)

Master to ECOCONTROL General Structure	DB0 Device Type Identifier	DB1.7...1.6 Void	DB1.5 Telegram Type Identifier	DB1 DB1.4 Data Type Identifier	DB1.3...1.0 Device Value Identifier	DB2 Data	DB3 ...	DB4 ...	DB5	DB11 Data
Explanation	00 Diameter 01 Capacitance 02 Eccentricity 03 Lump/Neck 04 Spark 05 Wall Thickness 06 Controller 07 General Settings 1		0 request 1 setting	0 Nominal Values DB2...DB11 con- tain nominal values 1 Actual Values ignore contents of DB2...DB11	0 Value 1 from device, numbers the value supplied by device specified in DB0 (see Fig. 1 Page 3) ... 15 Value 16	Nominal and Tolerance Values, Control Commands etc.						
Request to Send Nominal Values	00 ... 07	0 0	0 ... 15	-	-	-	-	-	-	-	-	-
Request to Send Actual Values	00 ... 07	0 1	0 ... 15	-	-	-	-	-	-	-	-	-
Setting of Nominal Values	00 ... 07	1 0	0 ... 15	Nominal Value	Nominal Value

Examples

Request to Send Nominal Values Diameter 0	00 Diam. Meas. Device	0 0	0 Value 1 from Dev.	-	-	-	-	-	-	-	-	-
	00		00	00	00	00	00	00	00	00	00	00
Request to Send Actual Values Diameter 0	00 Diam. Meas. Device	0 1	0 Value 1 from Dev.	-	-	-	-	-	-	-	-	-
	00		10	00	00	00	00	00	00	00	00	00
Setting of Nominal Values Diameter 0	00 Diam. Meas. Device	1 0	0 Value 1 from Dev.	Nominal Value e.g. 04.369	Diameter 0 [mm]	+ Tolerance Val. e.g. 00.100	Diameter 0 [mm]	- Tolerance Val. e.g. 00.099	Diameter 0 [mm]	-	-	-
	00		20	11	11	00	64	00	63	00	00	00

-continued-

Request to Send Nominal Values Diameter 1	00 Diam. Meas. Device	0 0	1 Value 2 from Dev.	-	-	-	-	-	-	-	-	-	-	-
	00		01	00	00	00	00	00	00	00	00	00	00	00
Request to Send Actual Values Diameter 1	00 Diam. Meas. Device	0 1	1 Value 2 from Dev.	-	-	-	-	-	-	-	-	-	-	-
	00		11	00	00	00	00	00	00	00	00	00	00	00
Setting of Nominal Values Diameter 1	00 Diam. Meas. Device	1 0	1 Value 2 from Dev.	Nominal Value e.g. 04.369	Diameter 1 [mm]	+ Tolerance Val. e.g. 00.100	Diameter 1 [mm]	- Tolerance Val. e.g. 00.099	Diameter 1 [mm]	-	-	-	-	-
	00		21	11	11	00	64	00	63	00	00	00	00	00
Request to Send Nominal Values Diameter 2 (hot)	00 Diam. Meas. Device	0 0	2 Value 3 from Dev.	-	-	-	-	-	-	-	-	-	-	-
	00		02	00	00	00	00	00	00	00	00	00	00	00
Request to Send Actual Values Diameter 2 (hot)	00 Diam. Meas. Device	0 1	2 Value 3 from Dev.	-	-	-	-	-	-	-	-	-	-	-
	00		12	00	00	00	00	00	00	00	00	00	00	00
Setting of Nominal Values Diameter 2 (hot)	00 Diam. Meas. Device	1 0	2 Value 3 from Dev.	Nominal Value e.g. 04.369	Diameter 2 [mm]	+ Tolerance Val. e.g. 00.100	Diameter 2 [mm]	- Tolerance Val. e.g. 00.099	Diameter 2 [mm]	-	-	-	-	-
	00		22	11	11	00	64	00	63	00	00	00	00	00
Request to Send Nominal Values Diameter 3 (cold)	00 Diam. Meas. Device	0 0	3 Value 4 from Dev.	-	-	-	-	-	-	-	-	-	-	-
	00		03	00	00	00	00	00	00	00	00	00	00	00
Request to Send Actual Values Diameter 3 (cold)	00 Diam. Meas. Device	0 1	3 Value 4 from Dev.	-	-	-	-	-	-	-	-	-	-	-
	00		13	00	00	00	00	00	00	00	00	00	00	00
Setting of Nominal Values Diameter 3 (cold)	00 Diam. Meas. Device	1 0	3 Value 4 from Dev.	Nominal Value e.g. 04.369	Diameter 3 [mm]	+ Tolerance Val. e.g. 00.100	Diameter 3 [mm]	- Tolerance Val. e.g. 00.099	Diameter 3 [mm]	-	-	-	-	-
	00		23	11	11	00	64	00	63	00	00	00	00	00
Request to Send Nominal Values Capacitance (hot)	01 Cap. Meas. Device	0 0	0 Value 1 from Cap. Meas. Dev.	-	-	-	-	-	-	-	-	-	-	-
	01		00	00	00	00	00	00	00	00	00	00	00	00
Request to Send Actual Values Capacitance (hot)	01 Cap. Meas. Device	0 1	0 Value 1 from Dev.	-	-	-	-	-	-	-	-	-	-	-
	01		10	00	00	00	00	00	00	00	00	00	00	00
Setting of Nominal Values Capacitance (hot)	01 Cap. Meas. Device	1 0	0 Value 1 from Dev.	Nominal Value e.g. 043.69	Capacitance hot [pF/m]	+ Tolerance Val. e.g. 001.00	Capacitance hot [pF/m]	- Tolerance Val. e.g. 000.99	Capacitance hot [pF/m]	-	-	-	-	-
	01		20	11	11	00	64	00	63	00	00	00	00	00

-continued-

Request to Send Nominal Values Capacitance (cold)	01 Cap. Meas. Device	0	0	1 Value 2 from Dev.	-	-	-	-	-	-	-	-	-	-
	01			01	00	00	00	00	00	00	00	00	00	00
Request to Send Actual Values Capacitance (cold)	01 Cap. Meas. Device	0	1	1 Value 2 from Dev.	-	-	-	-	-	-	-	-	-	-
	01			11	00	00	00	00	00	00	00	00	00	00
Setting of Nominal Values Capacitance (cold)	01 Cap. Meas. Device	1	0	1 Value 2 from Dev.	Nominal Value e.g. 043.69	Cap. cold [pF/m]	+ Tolerance Val. e.g. 001.00	Cap. cold [pF/m]	- Tolerance Val. e.g. 000.99	Cap. cold [pF/m]	-	-	-	-
	01			21	11	11	00	64	00	63	00	00	00	00
Request to Send Nominal Values Eccentricity	02 Ecc. Meas. Device	0	0	0 Value 1 from Dev.	-	-	-	-	-	-	-	-	-	-
	02			00	00	00	00	00	00	00	00	00	00	00
Request to Send Actual Values Eccentricity	02 Ecc. Meas. Device	0	1	0 Value 1 from Dev.	-	-	-	-	-	-	-	-	-	-
	02			10	00	00	00	00	00	00	00	00	00	00
Setting of Nominal Values Eccentricity	02 Ecc. Meas. Device	1	0	0 Value 1 from Dev.	Nominal Value e.g. ...	Eccentricity [mm]	Tolerance Val. e.g. 00.100	Eccentricity [mm]	Nominal Value e.g. 04.660	Core Diameter [mm]	Ecc/Conc Mode 0 Eccentricity 1 Concentricity	-	-	-
	02			20	00	00	00	64	12	34	00	00	00	00
Request to Send Nominal Values Lump	03 Lump Detector	0	0	0 Value 1 from Dev.	-	-	-	-	-	-	-	-	-	-
	03			00	00	00	00	00	00	00	00	00	00	00
Request to Send Actual Values Lump	03 Lump Detector	0	1	0 Value 1 from Dev.	-	-	-	-	-	-	-	-	-	-
	03			10	00	00	00	00	00	00	00	00	00	00
Setting of Nominal Values Lump	03 Lump Detector	1	0	0 Value 1 from Dev.	Tolerance Val. e.g. 001.85	Lump [mm]	Tolerance Val. e.g. 001.23	Neck [mm]	Tolerance Val. e.g. 011.5	Length [mm]	Fault Counter 0 no reset 1 reset	-	-	-
	03			20	00	B9	00	7B	00	73	00	00	00	00

-continued-

Request to Send Nominal Values Spark	04 Spark Tester	0	0	0 Value 1 from Dev.	-	-	-	-	-	-	-	-	-	-
	04			00	00	00	00	00	00	00	00	00	00	00
Request to Send Actual Values Spark	04 Spark Tester	0	1	0 Value 1 from Dev.	-	-	-	-	-	-	-	-	-	-
	04			10	00	00	00	00	00	00	00	00	00	00
Setting of Nominal Values Spark	04 Spark Tester	1	0	0 Value 1 from Dev.	Nominal Value e.g. 07.6	Test Voltage [kV]	Fault Counter 0 no reset 1 reset					-	-	-
	04			20	00	4C	00	7B	00	73	00	00	00	00
Request to Send Nominal Values Controller (Main)	06 Controller	0	0	2 Main Extruder	-	-	-	-	-	-	-	-	-	-
	06			02	00	00	00	00	00	00	00	00	00	00
Request to Send Actual Values Controller (Main)	06 Controller	0	1	2 Main Extruder	-	-	-	-	-	-	-	-	-	-
	06			12	00	00	00	00	00	00	00	00	00	00
Setting of Nominal Values Controller (Main)	06 Controller	1	0	2 Main Extruder	Control Comm. 0 OFF 1 ON 2 HOLD	Control Mode 0 Diameter 1 W.Thickness						-	-	-
	06			22	01	00	00	00	00	00	00	00	00	00
Request to Send Nominal Values Controller (J. Extr.)	06 Controller	0	0	1 Jacketing Extr.	-	-	-	-	-	-	-	-	-	-
	06			01	00	00	00	00	00	00	00	00	00	00
Request to Send Actual Values Controller (J. Extr.)	06 Controller	0	1	1 Jacketing Extr.	-	-	-	-	-	-	-	-	-	-
	06			11	00	00	00	00	00	00	00	00	00	00
Setting of Nominal Values Controller (Jacketing Extruder)	06 Controller	1	0	1 Jacketing Extr.	Control Comm. 0 OFF 1 ON 2 HOLD	Control Mode 0 Diameter 1 W.Thickness						-	-	-
	06			21	01	00	00	00	00	00	00	00	00	00

-continued-

Request to Send Nominal Values Controller (F. Extr.)	06 Controller	0	0	0 Filling Extruder	-	-	-	-	-	-	-	-	-	-
	06			00	00	00	00	00	00	00	00	00	00	00
Request to Send Actual Values Controller (F. Extr.)	06 Controller	0	1	0 Filling Extruder	-	-	-	-	-	-	-	-	-	-
	06			10	00	00	00	00	00	00	00	00	00	00
Setting of Nominal Values Controller (Filling Extruder)	06 Controller	1	0	0 Filling Extruder	Control Comm. 0 OFF 1 ON 2 HOLD	Control Mode 0 Diameter 1 W.Thickness								
	06			20	01	00	00	00	00	00	00	00	00	00
Request to Send Nominal Values Gen. Settings 1	07 General Settings	0	0	0	-	-	-	-	-	-	-	-	-	-
	07			00	00	00	00	00	00	00	00	00	00	00
Request to Send Actual Values Gen. Settings 1	07 General Settings	0	1	0	-	-	-	-	-	-	-	-	-	-
	07			10	00	00	00	00	00	00	00	00	00	00
Setting of Nominal Values Gen. Settings 1	07 General Settings	1	0	0	Product Code for Product Table Access						HC Ctrl Mode 0 HOT 1 HOT/COLD	Conductor Type 0 Round 1 Sector, pre- spiralled 2 Sector, straight		
	07			20	00	00	00	00	00	00	00	00	00	00

Data from ECOCONTROL 2000 (Input from SLAVE)

ECOCONTROL to Master General Structure	DB0 Device Type Identifier	DB1.7...1.6 Void	DB1.5	DB1 DB1.4 Data Type Identifier	DB1.3..1.0 Device Value Identifier	DB2	DB3	DB4	DB5	DB11
						Data	Data
Explanation	00 Diameter 01 Capacitance 02 Eccentricity 03 Lump/Neck 04 Spark 05 Wall Thickness 06 Controller 07 General Settings 1			0 Nominal Values DB2...DB11 contain nominal values 1 Actual Values DB2...DB11 contain actual values	0 Value 1 from device, numbers the value supplied by device specified in DB0 (see Fig. 1 Page 3) ... 15 Value 16	Nominal Values or Actual Values, according to DB1.4						
Reaction on Request to Send Nominal Values	00 ... 07	0 0	0 ... 15	Nominal Values	Nominal Values
Reaction on Request to Send Actual Values	00 ... 07	0 1	0 ... 15	Actual Values	Actual Values

Examples

Reaction on Request to Send Nominal Values Diameter 1	00 Diam. Meas. Device	0 0	1 Value 2 from Dev.	Nominal Value e.g. 04.369	Diameter 1 [mm]	+ Tolerance Val. e.g. 00.100	Diameter 1 [mm]	- Tolerance Val. e.g. 00.099	Diameter 1 [mm]	-	-	-	-
	00		01	11	11	00	64	00	63	00	00	00	00
Reaction on Request to Send Actual Values Diameter 1	00 Diam. Meas. Device	0 1	1 Value 2 from Dev.	Status Diam. X 0 valid ≠0 invalid	Status Diam. Y 0: valid ≠0 invalid	Act. Value e.g. 04.369	Diameter X [mm]	Act. Value e.g. 04.369	Diameter Y [mm]	-	-	-	-
	00		11	00	00	11	11	11	11	00	00	00	00

-continued-

Reaction on Request to Send Nominal Values Capacitance (hot)	01 Cap. Meas. Device	0	0	0 Value 1 from Dev.	Nominal Value e.g. 043.69	Capacitance hot [pF/m]	+ Tolerance Val. e.g. 001.00	Capacitance hot [pF/m]	- Tolerance Val. e.g. 000.99	Capacitance hot [pF/m]	-	-	-	-
	01			00	11	11	00	64	00	63	00	00	00	00
Reaction on Request to Send Actual Values Capacitance (hot)	01 Cap. Meas. Device	0	1	0 Value 1 from Dev.	Status Capacit. 0 valid ≠0 invalid	Void	Act. Value e.g. 043.69	Capacitance hot [pF/m]			-	-	-	-
	01			10	00	00	11	11	00	00	00	00	00	00
Reaction on Request to Send Nominal Values Eccentricity	02 Ecc. Meas. Device	0	0	0 Value 1 from Dev.	Void	Void	Tolerance Val. e.g. 00.100	Eccentricity [mm]	Nominal Value e.g. 04.660	Core Diameter [mm]	Ecc/Conc Mode 0 Eccentricity 1 Concentricity	-	-	-
	02			00	00	00	00	64	12	34	00	00	00	00
Reaction on Request to Send Actual Values Eccentricity	02 Ecc. Meas. Device	0	1	0 Value 1 from Dev.	Status Ecc. 0 valid ≠0 invalid	Ecc/Conc Mode 0 Eccentricity 1 Concentricity	Eccentricity, Absolute [unit as config.]	Eccentricity, 0...	Angle 360 [°]			-	-	-
	02			10	00	00	00	00	00	00	00	00	00	00
Reaction on Request to Send Nominal Values Lump	03 Lump Detector	0	0	0 Value 1 from Dev.	Tolerance Val. e.g. 001.85	Lump [mm]	Tolerance Val. e.g. 001.23	Neck [mm]	Tolerance Val. e.g. 011.50	Length [mm]		-	-	-
	03			00	00	B9	00	7B	00	73	00	00	00	00
Reaction on Request to Send Actual Values Lump	03 Lump Detector	0	1	0 Value 1 from Dev.	Status Lump/N. 0 valid ≠0 invalid	Void	Lump 0...	Counter 9999	Neck 0...	Counter 9999		-	-	-
	03			10	00	00	00	00	00	00	00	00	00	00
Reaction on Request to Send Nominal Values Spark	04 Spark Tester	0	0	0 Value 1 from Dev.	Nominal Value e.g. 07.6	Test Voltage [kV]						-	-	-
	04			00	00	4C	00	00	00	00	00	00	00	00
Reaction on Request to Send Actual Values Spark	04 Spark Tester	0	1	0 Value 1 from Dev.	Status Spark 0 valid ≠0 invalid	Void	Spark 0...	Counter 65535	Test Voltage [V]			-	-	-
	04			10	00	00	00	00	00	00	00	00	00	00

-continued-

Reaction on Request to Send Nominal Values	05 Wall Thickness	0	0	0 Value 1 from Dev.	Nominal Value	Wall Thickness [unit as configd.]	+ Tolerance Val.	Wall Thickness [unit as configd.]	- Tolerance Val.	Wall Thickness [unit as configd.]	Nominal Value	Shrinkage [%]	-	-
Wall Thickness	05			00	00	00	00	00	00	00	00	00	00	00
Reaction on Request to Send Actual Values	05 Wall Thickness	0	1	0 Value 1 from Dev.	Status WT 0 valid ≠0 invalid	Status Shrinkg. 0 valid 1 invalid	Wall Thickness [unit as configd.]		Shrinkage [%]		-	-	-	-
Wall Thickness	05			10	00	00	00	00	00	00	00	00	00	00
Reaction on Request to Send Nominal Values	06 Controller	0	0	2 Main Extruder	Control Comm. 0 OFF 1 ON 2 HOLD	Control Mode 0 Diameter 1 W.Thickness							-	-
Controller	06			02	01	00	00	00	00	00	00	00	00	00
Reaction on Request to Send Actual Values	06 Controller	0	1	2 Main Extruder	Status Contr. 0 OFF 1 ON 2 HOLD	Status IOCON 0 valid ≠0 invalid	Control Influence e.g. -12 [%]				-	-	-	-
Controller	06			12	01	00	FF	88	00	00	00	00	00	00
Reaction on Request to Send Nominal Values	07 General Settings	0	0	0 Value 1 from Dev.	Product Code							HC Ctrl Mode 0 HOT 1 HOT/COLD	Conductor Type 0 Round 1 Sector, pre-spiralled 2 Sector, straight	
General Settings 1	07			00	00	00	00	00	00	00	00	00	00	00
Reaction on Request to Send Actual Values	07 General Settings	0	1	0 Value 1 from Dev.	Product Code							HC Ctrl Mode 0 HOT 1 HOT/COLD	Conductor Type 0 Round 1 Sector, pre-spiralled 2 Sector, straight	
General Settings 1	07			10	00	00	00	00	00	00	00	00	00	00

Index

Access Authorization 17
Access denied for Administrator 18
Additional Application Settings 45
Alarm Messages 58
Application Termination 45
Automatic Control, General 20
Automatic Control, Optimizing 20
Automatic Mode, Switching On/Off 31
Automatic, Mode Switching 28

Button LOG OFF 23
Button LOG ON 23
Button MORE 5, 45
Button RECIPE TABLE 47
Button REPORT 39
Button SETUP 5
Button STATISTIC/PRINTER SETTING 40

Cable Shielding 3
Change Factor 47
COM Port Connections 8
Configuration Menu APPLICATION PARAMETERS 10
Configuration Menu HARDWARE SETTINGS 8
Configuration Menu MEASURING DEVICES CONFIGURATION 11
Configuration Menu PCCON CARD SETTINGS 14
Configuration Menu SAVE AND EXIT 18
Configuration Menu SERIAL COMMUNICATION 13
Configuration Menu USER LEVEL & PASSWORD 17
Configuration Parameter Input 6
Configuration Procedure 5
Configuration Program 6
Configuration Program Structure 7
Configuration Program, Calling 45
Contents of Delivery 1
Contents of Delivery, Options 1
Control Mode Setting 45
Control Parameter Configuration 14

Data Recording Parameter 40
Data Storage 40
Desk Mounting 2
Device Interfaces 62
Device Specification 61
Device Type Specification 12
Diagnosis Program 30
Diagram Viewport 25, 33
Diameter Measuring 20
Digital Input Specification 14, 16
Digital Output Specification 14, 16

Eccentricity Display 36
Eccentricity Display, Calling 34

ECOCONTROL Application Structure 24
ECOCONTROL Operation Mode 19
Error Message 59, 60
External Connections Overview / Introduction 3

Fail Report 46
FFT Analysis 51
FFT Diagram, Display Mode 54
FFT/RL, Calling 28
FFT/SRL Analysis Functions, General 51
Function Button 25

Interfaces 3, 61, 62
Interferences 1

Keypad 29

Line Display 37
Line Display, Calling 34
Log File 33, 46
Log File, Calling 45
Log In /Log Off 23
Logon 17
Loss of Administrator Access 18

Machine Number 10
Measuring Device Information 30
Measuring Head LED Signals 59
Measuring Unit 8
Measuring Value Display Specification 12
Measuring Values, Display of 26
Messages 58
Monitor Operation 23
Monitor Operation, General 19
Monitor Page FFT/SRL Parameter 51
Monitor Page RECIPE TABLE 47
Monitor Page SRL Diagram 56
Monitor Page STATISTICS 43
Monitor Page TREND 41
Monitor Page, Elements 25
Monitor Page, General 25

Nominal Value, Setting of 29
Nominal Values, Determination of 21

Operation by External Computer 19

Parameter Setting FFT/SRL Analysis Functions 51
Password 17, 23
PC-CON Address 8
Production Data Recording 39
Profibus 64
Profibus Address Setting 64
Profibus Input Data 71
Profibus Output Data 66

Recipe Code 27, 38, 47

Recipe Mode 27
Recipe Table Data 47
Recipe Table, Access 45
Recipe Table, Change Factor 47
Recipe Table, existing recipes 50
Recipe Table, new recipe 48
Rotary Pulse Generator 4, 20


Sector Measurement 22
Serial Interface RS232 63
Serial Interface Telegrams 1
Serial Interface Telegrams, data format 2
Short-Time Trend 33
Specification 61
SRL Diagram, Display Mode 56
SRL Diagram, Marker 56
Standard Monitor Page 25
Standard Monitor Page / Button RECIPE CODE 38
Standard Monitor Page / Button REPORT 39
Standard Monitor Page / Eccentricity Display 36
Standard Monitor Page / Line Display 37
Standard Monitor Page / Measuring Value Display 26
Standard Monitor Page / Measuring Value Display / Diagram Viewport Operation 33
Standard Monitor Page / Measuring Value Display / Text Bar Operation 28
Standard Monitor Page / Using the Toggle Bars 34
Standard Monitor Page, General Operation 27
Statistic Settings 40
STATISTICS function 39
Switching the Display 35

Temperature at Installation Site 1
Text Bar 25, 28
Text Box 25
Toggle Bar 25
Toggle Bars 34
TREND function 39
TREND, Display Buttons 42
TREND, Display Scaling 42
TREND, Parameter Selecting 41
Trend, Short-Time 33


User Level 17

Wall Thickness Measuring 19


Figures




SPARK 2000 UL to ECOCONTROL 2000 Connection




Measuring Source / Features	Device Number	Selected for this Application
Diameter 0 (Core Diameter)	0	
Diameter 1 (Filling Extruder)	1	
Diameter 2 (Hot Diameter)	2	
Diameter 3 (Cold Diameter)	3	
Capacitance	0	
Eccentricity	0	
Lump Detector	0	
Spark Tester	0	
Wall Thickness 0 (Filling Extruder)	0	
Wall Thickness 1 (Main Extruder)	1	
Controller 0 (at core)	0	
Controller 1 (at Filling Extruder)	1	
Controller 2 (at Main Extruder)	2	
Cable Type Round		
Cable Type Pre-Spiralled Sector		
Cable Type Stretched Sector		
Controller Mode Hot	2	
Controller Mode Hot-Cold	2	
Mode Eccentricity	0	
Mode Concentricity	0	






Für diese Zeichnung bestehen vor und nach Baubeginn, auch bei der Fertigstellung und der Elektrifizierung, keine weiteren genehmigten Änderungen, vor allem hinsichtlich der Verwendung, der Installation, der Herstellung und der Montage der Bauteile ist nicht gestattet, sie kann nur- und streckend sein.



Kartnummer		Allgemeintoleranz		Oberfläche		Maßstab		Position		Temperatur	



External Wiring ECOCONTROL 2000

Plug/St1 Serial Interface RS485	9-pol D-Sub Connector (Interface to Measuring Head / Measuring Device / Tester)
	not connected / connected to

Plug/St2 Serial Interface RS485	9-pol D-Sub Connector (Interface to Measuring Head / Measuring Device / Tester)
	not connected / connected to

Plug/St3 Serial Interface RS485 (Option)	9-pol D-Sub Connector (Interface to Measuring Head / Measuring Device / Tester)
	not connected / connected to

Plug/St4 Serial Interface RS485 (Option)	9-pol D-Sub Connector (Interface to Measuring Head / Measuring Device / Tester)
	not connected / connected to

Plug/St13 Serial Interface RS485 (Option)	9-pol D-Sub Connector (Interface to Measuring Head / Measuring Device / Tester / Profibus System)
	not connected / connected to

Plug/St14 Serial Interface RS485 (Option)	9-pol D-Sub Connector (Interface to Measuring Head / Measuring Device / Tester / Diagnostic Profibus System)
	not connected / connected to

Plug/St8 Serial Interface RS232		9-pol D-Sub Connector (COM2 to External Computer) Note: Clamp cable shield under cable grip!
	2	RxD
	3	TxD
	5	GND

Plug/St9 VGA Interface	15-pol D-Sub Connector (Interface to external VGA monitor)
----------------------------------	---

Plug/St10 Keyboard Interface	PS/2 Plug (Interface to external keyboard)
---	---

Plug/St11 Printer (Option)	25-pol Connector (Interface to parallel port printer EPSON LQ 590)
---	---

POWER SUPPLY	Device Connector (Mains Supply 230 / 115 V AC –selectable or automatic, can be set at the device power unit)
-------------------------	---

External Wiring SETUP - 05





Plug/St1 Power Supply	3 – pol. Screw terminal (Voltage feed)		
	1	AC – L	115 / 230 V Long-Range-Input
	2	AC – N	
	3	PE	

Plug/St2 External Power Supply (Option)	4 – pol. Screw terminal (external voltage feed)		
	1	} + 5 V	5 V external voltage feed
	2		
	3	} GND	External ground
	4		

Plug/St3 USB – Interface	USB (Interface to Ecocontrol / Panel PC)		
------------------------------------	---	--	--

Plug/St4 Ser. Interface RS 232 (Option)	9 –pol. D-Sub Connector (Programming Interface)		
	2	R x D	
	3	T x D	
	5	GND	

Plug/St5 Digital Output (Relay Contact)	8 – pol. Screw terminal (4 Digital outputs - programmable / potential-free contacts, max. contact load 24 V DC and 0,5 A)		
	1	} OUT 1	Digital Output 1 Preset e.g.: Contact closed: ALARM, error of the camera
	2		
	3	} OUT 2	Digital Output 2 Preset e.g.: Tolerance limit exceeded
	4		
	5	} OUT 3	Digital Output 3 Preset e.g.: Tolerance limit exceeded
	6		
	7	} OUT 4	Digital Output 4 Preset e.g.: Tolerance limit exceeded
	8		

Plug/St6 Digital Input	8 – pol. Screw terminal (4 Digital inputs - programmable)
	Digital Input 1 Preset e.g.: Contact closed: External computer control only Contact open: Internal and external computer control
	Digital Input 2 Preset e.g.: Contact closed for minimum 1 second: Start TREND diagram
	Digital Input 3 Preset e.g.: Contact closed for minimum 1 second: Stop TREND diagram
	Digital Input 4 Not preset


Plug/St7 SPEED	4 – pol. Screw terminal Potential-free Input for Pulses from the Rotary Pulse Generator Note: Clamp cable shield under cable grip!							
	<table> <tr> <td>1</td><td>+ 15 V Supply for Rotary Pulse Generator</td></tr> <tr> <td>2</td><td>Pulse from the Rotary Pulse Generator</td></tr> <tr> <td>3</td><td rowspan="2">} GND Ground Rotary Pulse Generator</td></tr> <tr> <td>4</td></tr> </table>	1	+ 15 V Supply for Rotary Pulse Generator	2	Pulse from the Rotary Pulse Generator	3	} GND Ground Rotary Pulse Generator	4
1	+ 15 V Supply for Rotary Pulse Generator							
2	Pulse from the Rotary Pulse Generator							
3	} GND Ground Rotary Pulse Generator							
4								

Plug/St8 Automatic Control Analog Output	4 – pol. Screw terminal (Automatic Control System 1)
	Automatic Control Influence: $\pm 50\%$ 2 Input Nominal Value max. $\pm 10\text{ V}$, $R_i \geq 100\text{ k}\Omega$ 3 GND Ground Input Nominal Value 1 Output Nominal Value max. $\pm 15\text{ V}$, max. 5 mA 4 GND Output Nominal Value

External Wiring CON – 05 (Option)

Plug/St1 Automatic Control System 2	3 – pol. Screw terminal (Automatic Control System 2)
	Automatic Control Influence: $\pm 50\%$ 2 Input Nominal Value max. $\pm 10\text{ V}$, $R_i \geq 100\text{ k}\Omega$ 3 GND Ground Input Nominal Value 1 Output Nominal Value max. $\pm 15\text{ V}$, max. 5 mA 4 GND Output Nominal Value

Plug/St2 Automatic Control System 3	3 – pol. Screw terminal (Automatic Control System 3)
	Automatic Control Influence: $\pm 50\%$ 2 Input Nominal Value max. $\pm 10\text{ V}$, $R_i \geq 100\text{ k}\Omega$ 3 GND Ground Input Nominal Value 1 Output Nominal Value max. $\pm 15\text{ V}$, max. 5 mA 4 GND Output Nominal Value




KSMOLA - _____

LASER 2000 XY
9 pol. D-Sub
Buchse / Socket

Kabeltyp / Cable Type:
LI2Y (St)+CY 1x2x0.08
Art.Nr. K3814001

ECOCONTROL/MOXA
9 pol. D-Sub
Buchse / Socket




KSMOMHD - _____

MHD 4000
25 pol. D-Sub
Buchse / Socket

Kabeltyp / Cable Type:
LI2Y (St)+CY 1x2x0.08
Art.Nr. K3814001

ECOCONTROL/MOXA
9 pol. D-Sub
Buchse / Socket




9 pol D-Sub Buchse/Socket
9 pol D-Sub Haube/Cap
25 pol D-Sub Buchse/Socket
25 pol D-Sub Haube/Cap
LI2Y (St) +CY 1x2x0.08


Art Nr. V76020
Art Nr. V76022
Art Nr. V7601
Art Nr. V7602
Art Nr. KS3814001

ECOCONTROL 2000
St. 5 / Plug 5

Drehimpulsgeber
Rotary Pulse Generator



TECHNISCHE INFORMATION



8.5810.21X5.0XXX

Spezifikation:

- preisgünstig
- kurzschlußfeste Ausgänge
- in vielen Varianten lieferbar
- robuste Ausführung nach Industriestandard
- hohe mechanische Schutzart
- niedriger Stromverbrauch
- Kunststoff- bzw. Metallteilung mit hoher Schockfestigkeit


Mechanische Kennwerte:

Drehzahl:	max. 6000 U/min.
Trägheitsmoment des Rotors:	$0,6 \times 10^{-6} \text{ kgm}^2$
Drehmoment:	$< 0,01 \text{ Nm}$
Wellenbelastbarkeit radial:	20 N (am Wellenende)
Wellenbelastbarkeit axial:	10 N
Gewicht:	ca. 0,4 kg
Schutzart nach DIN 40.050:	Welle IP 64, Deckel (IP 67 mit Kabel, IP 50 mit Stecker)
Arbeitstemperaturbereich:	0°C bis + 50°C
Welle:	nichtrostender Stahl


Elektrische Kennwerte:

Ausgangsschaltung:	Gegentaktschaltung	Kurzfristig Lieferbare Impulszahlen: 1, 2, 4, 5, 6, 10, 15, 20, 25, 30, 35, 36, 40, 50, 57, 60, 70, 80, 86, 90, 96, 100, 120, 125, 127, 142, 150, 180, 200, 216, 220, 240, 250, 254, 256, 280, 300, 314, 360, 377, 393, 400, 420, 450, 500, 512. Andere Impulszahlen auf Anfrage.
Versorgungsspannung U_B :	10 – 30 VDC	
Stromaufnahme:	max. 80 mA	
Zul. Last / Kanal:	max. $\pm 30 \text{ mA}$	
Impulsfrequenz:	max. 20 kHz	
Signalpegel high:	min. $U_B - 2,5 \text{ V}$	
Signalpegel low:	max. 1,5 V	
Anstiegszeit t_r :	max. 1 μs	
Abfallzeit t_f :	max. 1 μs	
Kurzschlußfeste Ausgänge bei korrekter Spannungsversorgung:	ja	
Verpolschutz der Spannungsversorgung:	ja	

Impulsbild:




Drehsinn:



Ausgangsschaltung:


Gegentakt




- Welle im Uhrzeigersinn drehend, mit Blick auf die Welle.
- Invertiertes Nullsignal optional erhältlich.
- Der 0-Impuls ist mit den Kanälen A und B UND-verknüpft.

Maßbilder:

Flansch 1: Klemmflansch



Flansch 2: Synchroflansch




Anschlußbelegung:

Signal:	0 V	+ U _B	A	B	0 bzw. \bar{O}	Schirm
Pin:	1	2	3	4	5	*
Farbe:	weiß	braun	grün	gelb	grau	schwarz

* Schirm liegt am Steckergehäuse an.

– Unbenutzte Ausgänge sind vor Inbetriebnahme zu isolieren

Bestellschlüssel:



Montageanleitung Drehgeber

Instructions for installing rotary transducer


Wichtig!

Vor Inbetriebnahme des Gebers unbedingt lesen.


Mit diesem Geber haben Sie ein Präzisionsmeßgerät erworben. Beachten Sie stets die Angaben und Hinweise des Datenblattes, um eine problemlose Funktion des Gebers zu gewährleisten und um die Garantieleistung aufrecht zu erhalten. Falls im Datenblatt nichts anderes angegeben ist, bitte folgendes unbedingt beachten:

Mechanisch:


- Der Drehgeber darf weder teilweise noch ganz zerlegt oder modifiziert werden.




- Die Welle nicht nachträglich bearbeiten (schleifen, sägen, bohren, usw.). Die Genauigkeit des Gebers und die Zuverlässigkeit von Lager und Dichtung nehmen sonst Schaden. Wir sind gerne bereit, auf Ihre Kundenwünsche einzugehen.



- Das Gerät niemals mit dem Hammer ausrichten.
- Schlagbelastungen unbedingt vermeiden.
- Drehgeberwelle nicht über die im Datenblatt angegebenen Werte belasten (weder axial noch radial).



- Drehgeber und Antriebsgerät nicht an Wellen und Flanschen starr miteinander verbinden. Benützen Sie grundsätzlich eine Kupplung (zwischen Antriebswelle und Geberwelle, bzw. zwischen Hohlwellen-Geber-Flansch und Antriebsflansch).



Für die Gebermontage empfehlen wir Ihnen den Einsatz unserer Montagehilfen und Kupplungen (siehe Zubehör-Datenblätter).

Bitte beachten Sie die umseitig stehenden Montagehinweise!

Important!

It is imperative that you read these instructions before putting the transducer into service.

The transducer is a precision measuring instrument. Always comply with the information and instructions on the data sheet to ensure trouble-free transducer function and to maintain the guarantee. Barring instructions to the contrary on the data sheet, compliance with the following is imperative:

Mechanical:

- It is not permissible to dismantle the transducer entirely or in part or to modify it.

- Do not alter the shaft (by grinding, sawing, drilling, etc.), otherwise the accuracy of the transducer and the dependability of bearing and gasket will suffer. We are always happy to take your wishes into account.

- Never align the instrument with a hammer.
- It is imperative to avoid impact loads.
- Never subject the shaft of the transducer to loads higher than those indicated on the data sheet (axially or radially).


- Do not connect transducer and drive rigidly to one another at shafts and flanges. Always use a coupling (between drive shaft and transducer shaft, or between hollow-shaft transducer flange and drive flange).

We recommend that you use our assembly aids and couplings to install the transducer (see accessory data sheets).


Please read the installation instructions on the back of this page.

Montagehinweise für Geber mit Welle:


- ① Wellen auf Versatz überprüfen.



Axialversatz / Axial offset



Radialversatz / Radial offset



Winkelfehler / Angle error

Entnehmen Sie die Werte x_1 , x_2 und x_3 dem Datenblatt der Kupplungen.

- ② Kupplung während der Montage vor zu starker Biegung sowie Beschädigung schützen.
- ③ Kupplung auf den Wellen ausrichten.
- ④ Spann- oder Klemmschrauben vorsichtig anziehen.


Installation instructions for transducer with shaft:

- ① Check shafts for offset.


Refer to the coupling data sheet for the values x_1 , x_2 and x_3 .

- ② During assembly, protect coupling against excessive bending or damage.
- ③ Align coupling on the shafts.
- ④ Carefully tighten pulling or clamping bolts.


Montagehinweise für Hohlwellengeber mit Kupplung:



Geber mit Kupplung auf Welle montieren.




Mount transducer with coupling on shaft.



Kupplung mit Antriebsflansch verschrauben.



Bolt coupling to drive flange.



Klemmnabe vorsichtig anziehen.
Carefully tighten clamping hub.

Instructions for installation of hollow-shaft transducer with coupling:

Elektrisch:

- Vor Inbetriebnahme sind alle benötigten Kabeladern laut Datenblatt anzuschließen! Isolieren Sie alle nicht benötigten Enden sauber, um Kurzschlüsse zu vermeiden.
- Bei der Konfektionierung des Gegensteckers ist eine, evtl. dem Stecker beigelegte, Anleitung zu beachten.
- Das Anschlußkabel des Gebers möglichst nicht parallel zu einem Netzkabel verlegen, um Störungen zu vermeiden.
- An Leitungslängen empfehlen wir:
 - bei asymmetrischer Übertragung, d.h. invertierte Signale werden nicht verwendet, max. 10 m Leitungslänge.
 - bei symmetrischer Übertragung (z.B. nach RS 422) max. 50 m Leitungslänge.
- Achten Sie auf eine gute Schirmung.
- Gegenstecker am Geber nur im spannungslosen Zustand ziehen oder stecken.
- Die richtige Betriebsspannung und den maximal zulässigen Ausgangsstrom berücksichtigen (siehe Datenblatt)!
- Ein- bzw. Ausschalten der Betriebsspannung für den Geber und das Folgegerät muß gemeinsam erfolgen.

Electrical:

- Before putting into service, connect all required strands as per data sheet. To prevent short-circuits, neatly insulate the ends of all strands which are not required.
- When preassembling the mating connector, comply with any instructions accompanying the connector.
- To avoid interference, do not lay the cable set for the transducer parallel to a mains cable if at all possible.
- Our recommendations regarding cable lengths:
 - in case of asymmetrical transmission, i.e. inverted signals are not used, cable length max. 10 m
 - in case of symmetrical transmission (e.g. to RS 422), cable length max. 50 m
- Make certain that shielding is good.
- Plug in or pull out mating connector on the transducer only when transducer is de-energized.
- Make certain that the operating voltage is correct and the max. permissible output current is not exceeded (see data sheet).
- The operating voltage for transducer and succeeding device must be turned on and off together.

Sicherheitshinweise:

1. Wenn anzunehmen ist, daß ein gefahrloser Betrieb nicht mehr gewährleistet ist, muß das Gerät außer Betrieb gesetzt und gegen unbeabsichtigtes Einschalten gesichert werden.
2. Wenn durch den Ausfall oder eine Fehlfunktion des Gebers eine Gefährdung von Menschen oder eine Beschädigung von Betriebseinrichtungen nicht auszuschließen ist, so muß dies durch geeignete Sicherheitsmaßnahmen wie Schutzvorrichtungen oder Endschalter usw. verhindert werden.

Safety precautions:

1. If operation without danger can no longer be assured at some point, the unit must be shut down and secured against accidental activation.
2. If personal injury or damage to equipment is possible should the transducer fail or malfunction, this must be prevented by suitable safety precautions such as protective devices or limit switches, etc.

Bei Mißachtung der obigen Richtlinien können wir keine Garantie gewähren. Wir bitten um Verständnis.

We can assume no guarantee if the above directives are disregarded. We ask for your understanding.


TECHNISCHE INFORMATION

Zubehör für Drehgeber Meßräder

11.91.2

Beschreibung und Anwendung

Meßräder dienen, in Verbindung mit Impulsgebern, zur Längenmessung von laufendem Meßgut in der Holz-, Papier-, Metall-, Textil- oder Kunststoffindustrie. Bei der Auswahl eines Meßrades ist zunächst die Art der zu messenden Ware zu berücksichtigen, um danach die Oberfläche bzw. den Belag des Meßrades zu bestimmen.



Ausführungen:

Meßräder für metrisches Maßsystem:

Meßrad Umfang	Profil-Nr.	Belag	Belaghärte Shore A	Standardbohrung mm ¹⁾	Meßbreite mm	Werkstoff Radkörper	Gewicht (ca.) g	Meßrad Nr.
0,2 Meter	1	Kreuzrändel		6	12	Aluminium	40	211
	3	flache Nut mit Querrändel		6	10	Aluminium	50	231
	3	flache Nut mit Querrändel		6	4	Aluminium	25	234
	4	Kunststoff (Hytrel) glatt	85...90	6	12	Kunststoff	35	241
	9	Kunststoff (Hytrel) geriffelt	85...90	6	12	Kunststoff	35	291
0,5 Meter	1	Kreuzrändel		10	25	Aluminium	350	512
	3	flache Nut mit Querrändel		10	16	Aluminium	350	536
	4	Kunststoff (Hytrel) glatt	85...90	10	25	Kunststoff	260	542
	5	Kunststoff (Vulkollan) glatt	90...95	10	25	Aluminium	320	552
	6	Noppengummi		10	25	Aluminium	320	562
	9	Kunststoff (Hytrel) geriffelt	85...90	10	25	Kunststoff	260	592
1 Meter	5	Gummi glatt	70...75	10	25	Aluminium	780	052
Meßräder für englisches Maßsystem								
1 Fuß	1	Kreuzrändel		6	13	Aluminium	110	711
	1	Gummi glatt	70...75	6	13	Aluminium	100	751

¹⁾ = Andere Bohrungsdurchmesser auf Anfrage

Bestellschlüssel:


8.0000.3 XXX.00XX
 └──────────┬──────────┘
 Bohrungsdurchmesser
 Meßrad-Nr.


Bitte beachten Sie:


Wird ein Meßrad direkt auf der Drehgeberwelle befestigt, darf die Andruckkraft zwischen Meßrad und Meßgut die im Datenblatt des Drehgebers angegebene, radiale Wellenbelastung nicht überschreiten.


Wir weisen außerdem darauf hin, daß die Meßräder nur für innerbetriebliche Zwecke verwendet werden können, die nicht den Bestimmungen des Eichgesetzes unterliegen.


- Änderungen vorbehalten -












*Platine PCCON Regelung Wanddicke / Kalt-Durchmesser
Controller Board PCCON Wall Thickness / Diameter-Cold Control*



*Platine PCCON Regelung Durchmesser 1 / Extruder
Controller Board PCCON Diameter 1 / Filling Extruder- Control*

Description of Serial Interface

An external device communicates with the ECOCONTROL using this protocol, the external device acts as master sending telegrams with requests to the ECOCONTROL. The ECOCONTROL sends telegrams to the master only as reaction on the requests. The contents of the telegrams may vary according to application.

Specifications


Operation:	full-duplex, asynchronous
Transmission range:	max. 15 m
Data cable:	[Li2Y(St)+CY] Typ DUE4503
Transmission Speed ¹⁾ :	115 kBaud (Bit/s) Default Setting
Data format ¹⁾ :	ASCII, 7 data bit, 1 stop bit, parity = ODD Default
¹⁾ can be set using the Configuration Program (Chapter 1.3)	

Description of Telegrams

The link operates like a record transmission. The format of all transmitted and received telegrams is :

ESC	DB1	...	DBn	CR	LF	BCC
<ESC>	ESCAPE			1BH		
<DBx>	data byte			≥ 20H		
<CR>	CARRIAGE RETURN			0DH		
<LF>	LINE FEED			0AH		
<BCC>	checksum byte			≥ 20H		

The checksum byte is calculated as follows :



with "xor" = exclusive or.

Transfer Time / Handshake

a.) Transmitting and receiving or exchanging telegrams does not happen synchronously. There is no handshake. The theoretical possible data transfer is only limited by the Baud rate.

b.) The data transfer is supervised by two time-out criteria.

1. maximum allowed time of delay between two characters within a telegram : 200 ms
2. maximum allowed time of delay between the arrival of the last character of the request telegram and the transmission of the first character of the answer telegram (only at bidirectional data communication) : 500 ms

If the first time-out criterion (1.) occurs, the receiver expects a new start of telegram (ESCAPE). In the

second case the transmitter reacts with a new request telegram.

The dead-time control can be switched off: Switch off the device and open the front panel. On print FPI, board place 20, is the 8-pol switch S3. Switch No. 2 (second from bottom) to position "ON" (refer to layout FPI). Close front panel and switch on the device.

Operation Mode

The variables (nominal values, tolerances) of the measuring device can be changed per telegram by the communication partner:

a.) Operation Mode "external control only" :

Variables can only be changed by the communication link. User-inputs at the display unit (keyboard) are disabled. Therefore the digital input signal (plug St4, Pin3) must be supplied with 15 V* DC. The display shows the state with an "E" = external.

b.) Operation Mode "external/internal control" :

Variables can be changed by means of the keyboard or by communication partner, both have the same priority. Therefore the digital input remains not connected.

Format of the actual and nominal values in the telegrams:

Value	Resolution	Unit	Range
Actual/Nominal Value Wall Thickness	1/RES	mm or inch or mil ¹⁾	00000 - 99999
Actual/Nominal Value Diameter	1/RES	mm or inch or mil ¹⁾	00000 - 99999
Tolerance Value Diameter	1/RES	mm or inch or mil ¹⁾	00000 - 99999
Tolerance Value Wall Thickness	1/RES	mm or inch or mil ¹⁾	00000 - 99999
Nominal Value Shrinkage	1/10	%	00000 - 00999
Nominal Value Spark HV	1/10	KV	00000 - 00150
Lump/Neck Tolerance Value	1/100	mm or mil ¹⁾	00000 - 65535
Length Tolerance Value	1/10	mm or mil ¹⁾	00000 - 65535
Actual Tolerance Value Eccentricity	1/RES	mm or inch or mil ¹⁾	00000 - 99999
Actual Tolerance Value Concentricity	1/10	%	00000 - 01000
Actual Value Angle of Eccentricity	1/10	°	00000 - 03600

¹⁾ according to application

RES value depending on display precision used in application. RES= 10 power precision.

The device concerned acts as master sending telegrams with requests to the ECOCONTROL. The ECOCONTROL sends telegrams to the master only as reaction on the requests.

Received telegrams ECOCONTROL 2000 (requests from the master) MASTER → SLAVE:

ESC	DB1	...	DBn	CR	LF	BCC
DB = Data (n byte)						

DB	Contents / Meaning:	Remark
DB1 = 0	Identifier: Send actual settings	
DB1 = 1	Identifier: Send actual values	
DB1 = 2	Identifier: Take over nominal value diameter 0	1)
DB2...DB6 = xxxxx	Nominal Value Diameter 0	
DB1 = 3	Identifier: Take over +tolerance value diameter 0	1)
DB2...DB6 = xxxxx	+Tolerance Value Diameter 0	
DB1 = 4	Identifier: Take over tolerance value diameter 0	1)
DB2...DB6 = xxxxx	-Tolerance Value Diameter 0	
DB1 = 5	Identifier: Take over nominal value diameter 1	1)
DB2...DB6 = xxxxx	Nominal Value Diameter 1	
DB1 = 6	Identifier: Take over +tolerance value diameter 1	1)
DB2...DB6 = xxxxx	+Tolerance Value Diameter 1	
DB1 = 7	Identifier: Take over tolerance value diameter 1	1)
DB2...DB6 = xxxxx	-Tolerance Value Diameter 1	
DB1 = 8	Identifier: Take over nominal value diameter 2	1)
DB2...DB6 = xxxxx	Nominal Value Diameter 2	
DB1 = 9	Identifier: Take over +tolerance value diameter 2	1)
DB2...DB6 = xxxxx	+Tolerance Value Diameter 2	
DB1 = A	Identifier: Take over tolerance value diameter 2	1)
DB2...DB6 = xxxxx	-Tolerance Value Diameter 2	
DB1 = B	Identifier: Take over nominal value diameter 3	1)
DB2...DB6 = xxxxx	Nominal Value Diameter 3	
DB1 = C	Identifier: Take over +tolerance value diameter 3	1)
DB2...DB6 = xxxxx	+Tolerance Value Diameter 3	
DB1 = D	Identifier: Take over tolerance value diameter 3	1)
DB2...DB6 = xxxxx	-Tolerance Value Diameter 3	
DB1 = E	Identifier: Take over nominal value WT	2)
DB2...DB6 = xxxxx	Nominal Value Wall Thickness	
DB1 = F	Identifier: Take over tolerance value WT	2)
DB2...DB6 = xxxxx	+Tolerance Value Wall Thickness	
DB1 = G	Identifier: Take over tolerance value WT	2)
DB2...DB6 = xxxxx	-Tolerance Value Wall Thickness	
DB1 = H	Identifier: Take over nominal value shrinkage	2)
DB2...DB6 = xxxxx	Nominal Value Shrinkage	
DB1 = I	Identifier: Take over control mode diameter/WT	
DB2...DB6 = xxxxx	0 : control mode diameter 1 : control mode wall thickness	
DB1 = J	Identifier: Take over control mode HOT/COLD or HOT	2)
DB2...DB6 = xxxxx	0 : control mode HOT 1 : control mode HOT/COLD	
DB1 = K	Identifier: Take over conductor type	2)
DB2...DB6 = xxxxx	0 : conductor type = ROUND 1 : conductor type = SECTOR, PRESPIRALLED 2 : conductor type = SECTOR, STRAIGHT	
DB1 = L	Identifier: Take over automatic mode select of diameter 0	1)
DB2...DB6 = xxxxx	0 : automatic mode OFF 1 : automatic mode ON 2 : automatic mode HOLD	

- continued -

- continued -

DB1 = M DB2...DB6 = xxxxx	Identifier: Take over automatic mode select of diameter 1 0 : automatic mode OFF 1 : automatic mode ON 2 : automatic mode HOLD	1)
DB1 = N DB2...DB6 = xxxxx	Identifier: Take over automatic mode select of outer diameter/ WT 0 : automatic mode OFF 1 : automatic mode ON 2 : automatic mode HOLD	
DB1 = O DB2...DB6 = xxxxx	Identifier: <i>RESERVED</i> Reserved, do not use	
DB1 = P DB2...DB6 = xxxxx	Identifier: Take over nominal value SPARK HV Nominal Value SPARK HV	1)
DB1 = Q DB2...DB6 = xxxxx	Identifier: Take over tolerance value lump Tolerance Value Lump	1)
DB1 = R DB2...DB6 = xxxxx	Identifier: Take over tolerance value neckdown Tolerance Value neckdown	1)
DB1 = S DB2...DB6 = xxxxx	Identifier: Take over tolerance value length Tolerance Value Length	1)
DB1 = T DB2...DB6 = xxxxx	Identifier: Take over sector R1 Sector R1	3)
DB1 = U DB2...DB6 = xxxxx	Identifier: Take over sector R2 Sector R2	3)
DB1 = V DB2...DB6 = xxxxx	Identifier: Take over tolerance value eccentricity Tolerance Value Eccentricity	4)
DB1 = W DB2...DB6 = xxxxx	Identifier: Take over tolerance value concentricity Tolerance Value Concentricity	4)
DB1 = a DB2...DB6 = xxxxx	Identifier: Take over nominal value capacitance (hot) Nominal Value Capacitance (Hot)	
DB1 = b DB2...DB6 = xxxxx	Identifier: Take over +tolerance value capacitance (hot) +Tolerance Value Capacitance (Hot)	
DB1 = c DB2...DB6 = xxxxx	Identifier: Take over -tolerance value capacitance (hot) -Tolerance Value Capacitance (Hot)	
DB1 = d DB2...DB6 = xxxxx	Identifier: Take over nominal value capacitance (cold) Nominal Value Capacitance (Cold)	
DB1 = e DB2...DB6 = xxxxx	Identifier: Take over +tolerance value capacitance (cold) +Tolerance Value Capacitance (Cold)	
DB1 = f DB2...DB6 = xxxxx	Identifier: Take over -tolerance value capacitance (cold) -Tolerance Value Capacitance (Cold)	

1) only if installed

2) only if enabled

3) only if conductor type = SECTOR

4) only if CENTERVIEW

Transmission telegrams ECOCONTROL 2000 (reactions on request) SLAVE → MASTER:

Reaction on incorrect received telegrams

ESC	DB1	CR	LF	BCC
-----	-----	----	----	-----

DB1 = 0	request is not understood (received telegram is invalid)
---------	---

Reaction on received telegrams, which are triggered (<ESC>... <CR>...) and include errors (number of <DBx> may be wrong, <LF> may be missing, <BCC> may be wrong). If <ESC> or <CR> is missing, the device recognizes time-out.

Reaction on MASTER telegram with identifier DB1 = 0

ESC	DB1	...	DBn	CR	LF	BCC
	DB = Data (n byte)					

DB	Contents:	Remark
DB... = xxxxx	Nominal Value Capacitance (Hot)	1)
DB... = xxxxx	+Tolerance Value Capacitance (Hot)	1)
DB... = xxxxx	-Tolerance Value Capacitance (Hot)	1)
DB... = xxxxx	Nominal Value Capacitance (Cold)	1)
DB... = xxxxx	+Tolerance Value Capacitance (Cold)	1)
DB... = xxxxx	-Tolerance Value Capacitance (Cold)	1)
DB... = xxxxx	Nominal Value Diameter 0	1)
DB... = xxxxx	+Tolerance Value Diameter 0	1)
DB... = xxxxx	-Tolerance Value Diameter 0	1)
DB... = xxxxx	Nominal Value Diameter 1	1)
DB... = xxxxx	+Tolerance Value Diameter 1	1)
DB... = xxxxx	-Tolerance Value Diameter 1	1)
DB... = xxxxx	Nominal Value Diameter 2	1)
DB... = xxxxx	+Tolerance Value Diameter 2	1)
DB... = xxxxx	-Tolerance Value Diameter 2	1)
DB... = xxxxx	Nominal Value Diameter 3	1)
DB... = xxxxx	+Tolerance Value Diameter 3	1)
DB... = xxxxx	-Tolerance Value Diameter 3	1)
DB... = xxxxx	Nominal Value Wall Thickness	2)
DB... = xxxxx	+Tolerance Value Wall Thickness	2)
DB... = xxxxx	-Tolerance Value Wall Thickness	2)
DB... = xxxxx	Nominal Value Shrinkage	2)
DB... = x	0 : control outer diameter 1 : control wall thickness	
DB... = x	0 : control mode HOT 1 : control mode HOT/COLD	
DB... = x	0 : automatic control (diameter 0) OFF 1 : automatic control (diameter 0) ON 2 : automatic control (diameter 0) HOLD	1)
DB... = x	0 : automatic control (diameter 1) OFF 1 : automatic control (diameter 1) ON 2 : automatic control (diameter 1) HOLD	1)
DB... = x	0 : automatic control (outer diam./wall thickness) OFF 1 : automatic control (outer diam./wall thickness) ON 2 : automatic control (outer diam./wall thickness) HOLD	
DB... = xxxx	Nominal Value SPARK HV	1)
DB... = xxxx	Tolerance Value Lump	1)
DB... = xxxx	Tolerance Value Neckdown	1)
DB... = xxxx	Tolerance Value Length	2)
DB... = x	Conductor Type 0 : conductor type = ROUND 1 : conductor type = SECTOR, PRESPIRALLED 2 : conductor type = SECTOR, STRAIGHT	
DB... = xxxxx	Sector R1	2)
DB... = xxxxx	Sector R2	2)
DB... = xxxxx	Tolerance Value Eccentricity	2)
DB... = xxxx	Tolerance Value Concentricity	2)

1) only if installed

2) only if enabled

Reaction on MASTER telegram with identifier DB1 = 1

ESC	DB1	...	DBn	CR	LF	BCC
DB = Data (n byte)						

DB	Contents:	Remark
DB... = xxxxx	Actual Value Capacitance (Hot)	1)
DB... = x	Status Capacitance (Hot)	1)
DB... = xxxxx	Actual Value Capacitance (Cold)	1)
DB... = x	Status Capacitance (Cold)	1)
DB... = xxxxx	Actual Value Diameter 0	1)
DB... = x	Status Diameter 0	1)
DB... = xxxxx	Actual Value Diameter 1	1)
DB... = x	Status Diameter 1	1)
DB... = xxxxx	Actual Value Diameter 2	1)
DB... = x	Status Diameter 2	1)
DB... = xxxxx	Actual Value Diameter 3	1)
DB... = x	Status Diameter 3	1)
DB... = xxxxx	Actual Value Wall Thickness	2)
DB... = x	Status Wall Thickness	2)
DB... = x	0 : device in internal/external mode 1 : device in external mode	
DB... = xxx	Actual Spark Fault Counter	1)
DB... = xxx	Actual Lump Counter	1)
DB... = xxx	Actual Neckdown Counter	1)
DB... = xxxxx	Actual Value Eccentricity	2)
DB... = x	Status Eccentricity	2)
DB... = xxxxx	Actual Value Angle	2)

1) only if installed

2) only if enabled

Reaction on MASTER telegrams with identifier DB1 = 2, 3 etc.

ESC	DB1	CR	LF	BCC
-----	-----	----	----	-----

DB1	= 1	request is understood (received telegram is valid)
-----	-----	--

Status Value	Status Diameter	Status Wall Thickness	Meaning Status Eccentricity / Concentricity	Status Capacitance
0	actual value is valid	actual value is valid	actual value is valid	actual value is valid
1	actual value is valid	actual value is valid +tol. limit exceeded	actual value is valid	actual value is valid +tol. limit exceeded
2	actual value is valid	actual value is valid -tol. limit exceeded	actual value is valid	actual value is valid -tol. limit exceeded
3	actual value is invalid, cable is missing	actual value is invalid	actual value is invalid, cable out of range	actual value is invalid, cable is missing
4	actual value is invalid, cable too low	-	-	actual value is invalid, generator voltage too low
5	actual value is invalid, cable too high	-	-	actual value is invalid, meas. range (upper limit) exceeded
6	actual value is invalid, glasses dirty	-	-	actual value is invalid, bare wire
7	actual value is invalid, camera underexposed	-	-	actual value is invalid, meas. electronics not OK
8	communication fault	-	-	communication fault
9	-	-	actual value is invalid, inductivity failure	-