

4. USING THE CONTROLLERS

Use the **CX10** or **CX40** Joystick Controllers with this Atari Game Program cartridge. Be sure that the controller cables are firmly plugged into the *Left Controller* and *Right Controller* jacks at the back of your Atari Video Computer System depending on the Game Variation selected. For single-player games, use the *Left Controller* jack. Twin stick or two-player games require a second joystick controller be plugged into the *Right Controller* jack.

Hold the controller with the red button to your upper left toward the television screen. See Section 3 of your Video Computer System Owner's Manual for further details.

The joystick controller plugged into the *Left Controller* jack will always control the vertical and horizontal movement of the player. In single-player games, the button on the joystick will fire a projectile in the direction that the player is facing when pressed.

The joystick controller plugged into the *Right Controller* jack will control the direction of and fire the projectile when engaged and playing in twin-stick or two-player games.

When in twin-stick or two-player games, the buttons on both joystick controllers are only used to progress through game screens.

