

## **CAMERA SETTINGS:**

- Rec. Programs: P (programmed AE)
- BLC Always On: OFF
- White Balance: manual white balancing (bottom symbol 1 or 2)
- AGC Limit: A
- Focus: AF (I.AF)
- Exposure: A
- Audio Scene: STD
- Mic Level: A
- Zoom: N/A
- Image Stabilizer: Middle selection (waving hand) standard
- Image Effects: ON
  - Color depth: 0
  - Sharpness: +1
  - Contrast: +1
  - Brightness: 0
- Wifi Remote: Off

### Movie Menu (graphic of video camera icon)

- Digital Zoom: Off
- Soft Zoom Control: Off
- Zoom Speed Level: >>
- High-Speed Zoom: On
- AF Mode: I.AF
- Focus Assistance: On
- Face Detection and Tracking: Off
- Auto Backlit Correction: ON
- Auto Slow Shutter: On
- ND Filter: A
- Conversion Lens: Off
- Onscreen Markers: G

### Movie Settings (graphic of film strip with settings gear icon)

- Movie Format: AVCHD
- Recording Mode: N/A
- Recording Media: N/A
- Dual/Relay Recording: N/A
- Video Snapshot Length: 4 sec
- Time Code Mode: PRESET
- Time Code Running Mode: REC RUN
- DF/NDF: DF
- Initial Time Code: N/A
- User Bit Output Mode: Fixed

- User Bit Type: Set
- Color Bars: Off
- 1 kHz Tone: Off
- File Numbering: → (continuous)

#### Settings (graphic with wrench icon)

- OLED Brightness: Norm
- OLED Mirror Image: Off
- OLED Color Balance: N/A
- VF Brightness: Norm
- Headphone Volume: 8
- Notification Sound: High
- Monitor Delay: Norm
- Wireless Remote Control: On
- CUSTOM Dial and Button: +/- (exposure)
- Assign Button 1: AF/MF
- Assign Button 2: Pre REC
- Assign Button 3: Powered IS
- Assign Button 4: Function, White Balance
- Assign Button 5: Rec Review
- Powered IS Button: On/Off
- Set WB Priority: AWB
- Focus/Zoom ring Direction: Norm
- Focus/Zoom Ring Response: >> normal
- Focus Speed: >> normal
- Auto Power Off: On
- Battery Info: N/A
- Rec Command: Off
- HDMI Output: N/A
- Output Onscreen Displays: On
- Distance Units: ft
- Backup Menu Settings B