

1.9

“HANDS-FREE” CARD: use (2/4)

If the card has been within the detection area 3 for approximately 15 minutes, remote locking is disabled. To lock the vehicle, press the 5 button on the card or, depending on the vehicle, the 2 button on the handle 1.

The vehicle cannot be remotely locked if the card is within the area 4.

Hands-free locking when moving away from the vehicle

With the card on you, doors and luggage compartment door closed, move away from the vehicle: it will lock automatically once you have left the access zone 3.

Note: the distance at which the vehicle locks depends on the surroundings.

To indicate that the vehicle has been locked, the hazard warning lights flash twice and then light up for approximately four seconds, and a beep sounds in confirmation.

4

5

Hands-free unlocking, when
approaching the vehicle;

With the card in access zone 3, the ve-
hicle will unlock. Unlocking is indicated
by one flash of the hazard warning
lights and the indicator lights.

Depending on the vehicle, the door
mirrors fold in/out automatically
when the vehicle is locked/unlocked

→ 1.90

