
H a n d b o o k

hydra

Firmware: 2.203000
GMT: Fri Apr 16 09:36:39 2010

Contents

About this documentation.....	4
Introduction to Venus-3.....	6
Venus-3 is an interpreter language and combines the languages Venus-1 and Venus-2.....	7
History.....	7
Command syntax.....	8
Data reply message to the host.....	10
Broadcast commands.....	11
Storing settings.....	11
Example of a typical program to control the hydra.....	11
Devices.....	13
Controller [Device 0]	14
Axis [Device 1..2]	15
Sensor [Device 3]	18
Datatypes.....	20
Controller.....	23
ControllerIO.....	39
Dynamics.....	44
InputOutput.....	51
Interpreter.....	60
Manual operation.....	75

Mechanic.....	83
Mechanic setup.....	86
Motion.....	110
Motor.....	126
Safety functions.....	144
Sensoric.....	146
Servo.....	158
Status and position.....	181
Switches and reference mark.....	193
Trigger.....	200
State Reference.....	239
Command Reference.....	242

About this documentation

The interpreter language Venus-3 of the controller hydra is described in this manual. Their function and syntax is explained.

The grouping of the commands in function groups improves the overview, an index table and alphabetical command list gives additional assistance.

The mechanisms of the command execution are commented in an introduction. To study this chapter is important as the way of procedure for the correct programming is explained there.

As far as it is necessary to comprehend the correlations, hardware specific peculiarities of the controller are also explained. These attributes are described in greater detail in the manual of the controller.

Introduction to Venus-3

Venus-3 is an interpreter language and combines the languages Venus-1 and Venus-2

Venus-3 commands consist of ASCII-characters which are interpreted in the controller and immediately executed.

A software development surrounding to produce the control programs is not needed.

The commands can be produced by any host and whatever programming language you are using, on condition that there is an access to the RS-232 interface or ethernet interface.

In the simplest way the commands are directly transmitted to the controller via an ASCII terminal.

History

Venus-3 has been developed on the basis of the interpreter language Venus-1 and Venus-2. The fundamental command construction is identical.

The expansion was necessary as the fundamental structures of Venus-1 are designed for controller with at most three linear interpolated axes; but the controller Pegasus supports any number of independent axes (n). Venus-1 commands which structure is designed for operating n-axes are taken over in Venus-2 without any syntax alteration. Venus-3 combines the two languages in most cases.

Special commands for a single axis are expanded with the addition "n" before the command name.

For example: The Venus-1 command cal which has at the same time an effect on three axes has become the device specific command ncal in Venus-2, move has become nmove etc. Some commands need not to be modified, they were already device dependent.

Command syntax

The commands are assembled following this scheme:

[parameter] _ {device index} _ **command** _

_ blank, (space) or (SP)

Parameter

The parameter transmits a value without any unit.

For positioning commands i.e. this value is the target coordinate or the relative movement.

If several parameters are needed for one command, they have to be separated by a blank character.

Device Index

The addressing of the device module is done by the device index. This index is always an integer and selects the device.

Command

The command names the real function. It consists of several ASCII characters, lower and upper case characters are distinguished.

The following letters are allowed for commands:

ASCII-Characters	a-z A-Z
Umlauts	not allowed
Numbers	not allowed

Command ending character while transmitting

In the host mode data lines which are transmitted have to be completed with a CR LF character combination.

[parameter] SP {device index} SP **command** SP

In the terminal mode is not supported by the hydra controller.

Command ending character while receiving

[1st parameter] SP [2nd parameter] SP [n-parameter] CR LF

Data which is delivered by the controller is always completed with ASCII (CR) and (LF).

Table of important ASCII signs for programming

ASCII Code	Sign	Dez	HEX
CR	Ctrl-M	13	0xD
LF	Ctrl-J	10	0xA
SP		32	0x20
ETX	Ctrl-C	3	0x3

Command execution

For the correct programming it is important to know the internal courses during the execution of the interpreter commands.

The ASCII data transmitted by a host run through the following areas of the controller:

- data input interfaces
- scanner / stack
- interpreter

Data converter

The data from several hardware interfaces are transferred line by line to the scanner input.

Scanner -> Interpreter -> Stack

The line data is read by the scanner and during this checked for parameters, commands and correct device index. The parameters are transmitted to a stack which can accept up to 99 values.

If the scanner separates the line into tokens. Parameter are pushed on the internal parameter stack and the interpreter looks for the command in the different command tables.

Valid commands are immediately executed and the needed parameter are taken from the parameter stack.

Blocking and non blocking commands

Hydra has no more blocking commands. All commands are executed immediately are not waiting that the previously executed command has finished.

Only a new command for asynchronously get the status is added. See command **ast** (p. 184)

Producing an automatic status reply message

With the following sequence of instructions an synchronously event can be generated (applies here to the 1. device) :

Command	
1:	10.2 1 nmove (p. 111)
2:	0 1 ast (p. 184)

Effect:

An automatic status feedback is produced, after the instruction 10.2 1 **nmove** has finished.

Data reply message to the host

The controller only delivers data if it was requested by the host.

Broadcast commands

The typical Venus-2 command needs the device index for the correct device assignment.

Storing settings

Most settings are storable. So they are not lost after power off. Use command ***nsave*** (p. 62) ***csave*** (p. 61) to store the configuration parameters of the specified devices.

Example of a typical program to control the hydra

Hydra device configuration

	Command	Description
1:	10 1 <i>snv</i> (p. 50)	Velocity setting, device-1
2:	5 2 <i>snv</i>	Velocity setting, device-2
3:		
4:	2 1 <i>setpitch</i> (p. 85)	Pitch setting, device-1
5:	2 2 <i>setpitch</i>	Pitch setting, device-2
6:	100 1 <i>sna</i> (p. 45)	Acceleration setting, device-1
7:		
8:	1 <i>nsave</i> (p. 62)	Save all parameters, device-1

	Command	Description
9:	2 nsave	Save all parameters, device-2
10:		
11:	1 ncal <small>(p. 87)</small>	Move to endswitches, device-1
12:	1 nrm <small>(p. 105)</small>	(find limits)
13:		
14:	2 ncal	Move to endswitches, device-2
15:		
16:		
17:	15 1 nm <small>(p. 111)</small>	Positioning absolute, device-1
18:		
19:	1 nst <small>(p. 183)</small>	Ask for status, device-1
20:	1 gne <small>(p. 66)</small>	Ask for command decoding error (venus error)
21:	1 np <small>(p. 190)</small>	Ask for the actual position of device 1
22:		
23:	2.003 2 nm	Positioning absolute, device-2
24:		
25:	2 nst	Ask for status, device-2
26:	2 np	Ask for actual position of device 2



Devices

Controller [Device 0]

This device is the controller itself. Communications state are found here, because these states have effect to all devices. This device has no device number and therefore all commands for the controller are not found at any other device.

Controller

Device count.....	29	Serial number.....	35
Device class.....	28	Supply voltage.....	36
Machine error.....	30	Controller identification.....	24
Controller version.....	26	CPU temperature.....	27
Reset.....	34	Parameter stack.....	32
Time of day.....	37		

ControllerIO

Serial communication.....	42	Network.....	40
---------------------------	----	--------------	----

InputOutput

Digital output level.....	55	Digital input event command.....	52
Emergency switch.....	58		

Interpreter

Configuration storage.....	61	User strings.....	73
Interpreter error.....	65	User doubles.....	69
Error decoder.....	63	User integers.....	71

Motion

Vector absolute move.....	120	Vector velocity.....	124
Vector acceleration.....	122	Controller reference move.....	112

Status and position

Controller status.....	186	Controller position.....	185
------------------------	-----	--------------------------	-----

Axis [Device 1..2]

Controller

Controller name.....	25	Version.....	38
----------------------	----	--------------	----

Dynamics

Acceleration.....	45	Stop deceleration.....	47
Velocity.....	49		

Interpreter

Configuration storage.....	62	Parameter stack.....	67
Interpreter error.....	66		

Manual operation

Manual device entry.....	76	Manual device parameters.....	79
Manual device parameters.....	79	Manual device parameters.....	79
Manual device parameters.....	79	Manual device parameters.....	79
Manual device parameters.....	79	Manual device parameters.....	79
Manual device parameters.....	79	Manual motion control.....	81

Mechanic

Pitch.....	84
------------	----

Mechanic setup

Hardware limits.....	92	Calibration velocity.....	90
Initial limits.....	94	Range measure velocity.....	106
Motion direction.....	96	Reference velocity.....	108
Calibration move.....	87	Position origin.....	100
Range measure move.....	105	Position origin configuration....	103
Calibration switch distance.....	88	Motion function.....	98

Motion

Absolute move.....	111	Random move.....	116
Parameterised absolute move.....	114	Move abortion.....	113
Parameterised relative move...	115	Reference move.....	117
Relative move.....	118		

Motor

Motor voltage minimum.....	142	Motor phase current.....	135
Motor voltage gradient.....	140	Absolute motor current.....	127
Motor current limit.....	133	Motor brake.....	130
Motor pole pairs.....	138	Auto commutation.....	128
Motor phase number.....	136		

Safety functions

Motor restart.....	145
--------------------	-----

Sensoric

Sensor dependency.....	155	Sensor amplitudes.....	153
Scale period.....	151	Sensor temperature.....	157

Servo

Servo control.....	173	Sensor status.....	171
Adaptive positioning control....	159	Target window.....	177
Positioning control mode.....	163	Time on target.....	179
Sensor assignment.....	165		

Status and position

Axis status.....	182	Device position.....	190
Position display selection.....	191		

Switches and reference mark

Switch status.....	199	Reference configuration.....	194
Switch configuration.....	197	Reference status.....	196

Trigger

Trigger event setup.....	221	Trigger pulse width.....	236
Trigger mode.....	223	Trigger capture mode.....	212
Trigger status.....	238	Trigger capture polarity.....	214
Trigger output delay.....	230	Trigger capture buffer size.....	209
Trigger output pulse width.....	234	Trigger capture index.....	211
Trigger output polarity.....	232	Trigger capture position.....	216
Trigger delay.....	219	Trigger capture position file.....	217

Sensor [Device 3]

This device has only measure features. No motor can be connected to this device.

Controller

Controller name.....	25	Version.....	38
----------------------	----	--------------	----

Interpreter

Configuration storage.....	62	Parameter stack.....	67
Interpreter error.....	66		

Sensoric

Sensor dependency.....	155	Sensor amplitudes.....	153
Device position.....	190	Sensor temperature.....	157
Scale period.....	151		

Datatypes

double

Description

A floating point value with double precision. Values given as integers are converted automatically.

Size: 64 Bit

Range: (+|-) 10^{-308} to 10^{308}

Syntax**Reg.Ex:**

-?[01234567890]+(.[1234567890]+)?

Examples :

100.5

231.321

5352

int

Description

An integer value.

Size: 32 Bit

Range: (+|-) 2147483647

Syntax**Reg.Ex:**

-?[01234567890]+

Examples :

1001

512

-3165

long long

Description

An integer value.

Size: 64 Bit

Range: (+|-)
9223372036854775807

Syntax**Reg.Ex:**

-?[01234567890]+

Examples :

9223372036854775807

512

-3165

machineerrorcodes

Description

The following machine error code are generated.

0 "no machine errors"

11 "emergency stop"

12 "motor overcurrent"

13 "following error"

23 "I²t overflows"

100 "EEPROM checksum error"

101 "no sensor available"

Size: 32 Bit

Syntax

Examples :

sensorstate

Description

state of the sensor

UNDEFINED=-1

isOK=0

SENSORERROR=1

LOWAMPLITUDE=2

LOWQUALITY=4

NOTMAPPED=8

NOTCONNECTED=16

NOMT=32

POSOUTOFRANGE=64

ILLSUBDEVICE=128

any combination of the above values are possible

Size: 32 Bit

Range: (+|-) 2147483647

Syntax

Reg.Ex:

-?[01234567890]+

Examples :

1001

512

-3165

sensortypes

Description

The following sensor types are supported.

Possible values are:

nanoStarType = 0

microStarPCSType = 1

betaStarType = 2

betaStarMultiTurnType = 3

sincosStarType = 4

MFStarType = 5

miniStarType = 6

needleStarType = 7

Size: 32 Bit

Range: 0..7

Syntax

Examples :

1 for nanoStarInterface

4 for sincosStarInterface

string

Description

A sequence of characters enclosed by double quotes

Size: variable

Syntax

Reg.Ex:

".+"

Examples :

"This is a test string"

"Hello world"

"ABCD"



Controller

Controller identification



read-only

Commands

identify..... 24

Properties

Type: [string](#)

identify

Returns the actual ***Controller identification***.

Syntax

identify

Reply

[identifystring]

Controller name



read-only

Commands

nidentify..... 25

Properties

Type: [string](#)

nidentify

Returns the actual ***Controller name***.

Syntax

{device} ***nidentify***

Reply

[identifystring]

Controller version



read-only

CPU firmware revision.

Commands

version (getversion)26

Properties

Type: [double](#)

version (getversion)

Returns the actual ***Controller version***.

Syntax

version

Reply

[version]

CPU temperature



read-only

CPU temperature.

Commands

getcputemp.....27

Properties

Type: double

Unit: °C

getcputemp

Returns the actual *CPU temperature*.

Syntax

getcputemp

Reply

[temperature]

Device class

Type of a device specified by device number.

Commands

getdeviceclass.....28

Properties

Name	Type	Description	
[devicenr]	int		
[class code]	int	value	description
		0	controller device
		1	axis device
		2	sensor device

getdeviceclass

Returns the *Device class*.

Syntax

[devicenr] ***getdeviceclass***

Reply

[class code]

Device count



read-only

Number of devices minus the controller device.

Commands

getaxc.....29

Properties

Type: [int](#)

getaxc

Returns the actual ***Device count***.

Syntax

getaxc

Reply

[axiscount]

Machine error



read-only

Commands

gme (getmerror) 30

Properties

Name	Type
[devicenr]	int
[machine error]	int

gme (getmerror)

This command pops the last machine error code from the machine error stack. If no errors on the stack then 0 is returned. The command **merrordecode** (p. 64) returns the error description of the code in a string.

Syntax

[devicenr] **gme**

Reply

[machine error]

Examples

	Command	Description
1:	1 <i>gme</i>	Returns the machine error code, 0 if no error messages pending

Parameter stack (Controller)



read-only

Stack for Venus parameters. Temporarily contains parameter values entered until further processing. Should be empty if no commands pending. The *stackpointer* indicates the number of parameter values currently pending.

Commands

gsp.....32
clear.....33

Properties

Type: [int](#)

gsp

Returns number of parameter values currently pending on ***Parameter stack***.

Syntax

gsp

Reply

[stackpointer]

Examples

Example

Preconditions: Parameter stack is empty.

	Command	Description
1:	<i>gsp</i> <small>(p. 32)</small>	Returns 0.
2:	0 2	Push 2 parameter values on stack without entering a command string.
3:	<i>gsp</i>	Returns 2.
4:	<i>clear</i> <small>(p. 33)</small>	Clears stack.
5:	<i>gsp</i>	Returns 0 again.

clear

Clears ***Parameter stack***, discarding its content.



Normally, no parameters are left on the stack, unless too many parameter values are entered with a certain command.

Syntax

clear

Reset

Controller hardware reset.

Commands

reset..... 34

reset

Initiates **Reset**.



Volatile data will be lost. Execute **save** or **csave** (p. 61) before execution if needed.

Syntax

reset

Serial number



read-only

Serial number of controller hardware.

Commands

getserialno..... 35

Properties

Type: [string](#)

getserialno

Returns ***Serial number***.

Syntax

getserialno

Reply

[number]

Supply voltage



read-only

Supply voltage of the motor power stage.

Commands

getusupply..... 36

Properties

Name	Type
[value]	double
[type]	string

getusupply

Returns the **Supply voltage**.

Syntax

getusupply

Reply

[value] [type]

Time of day



read-only

Commands

gettime.....37

Properties

Type: [string](#)

gettime

Returns the actual ***Time of day***.

Syntax

gettime

Reply

[time]

Version



read-only

Same as ***Controller version*** (p. 26). Needs a specified device index, but returns the same result. Compatibility purpose only.

Commands

nversion (getnversion) 38

Properties

Type: **double**

nversion (getnversion)

Returns the actual ***Version***.

Syntax

{device} ***nversion***

Reply

[versionnumber]

ControllerIO

Network



storable

TCP/IP network.

Commands

setnetpara.....	40
getnetpara.....	41

Properties

<i>i</i>	Name	Type
0	[TCP/IP adress]	string
1	[Subnet mask]	string
2	[gateway]	string
3	[nameserver]	string
4	[Timeserver]	string

setnetpara

Configures the **Network**.

Syntax

[*Value*] [*i*] **setnetpara**

Examples

Example

Note: Unlike in the table below, all commands have to be entered *in one line*.

	Command	Description
1:	"192.168.129.200" 0 <i>setnetpara</i>	Set IP address.
2:	<i>save</i> <small>(p. 61)</small>	Save all controller parameters.

Result: Controller can be accessed via IP address 192.168.129.200 after reset.

getnetpara

Returns the actual configuration of the **Network**.

Syntax

[*i*] *getnetpara*

Reply

[*Value*]

Serial communication



storable

RS232 communication interface.



Setting the baud rate to 0 will switch off the respective RS232 port.



With no USB option built in, port 2 must always be switched off.

Commands

getbaudrate.....	42
setbaudrate.....	43

Properties

<i>i</i>	Name	Type	Unit	Description
1	[baudrate port 1]	int	Bit/s	standard RS232 port baud rate
2	[baudrate port 2]	int	Bit/s	optional RS232/USB port baud rate

getbaudrate

Returns the current setting of the **Serial communication** baud rate.

Syntax

[*i*] **getbaudrate**

Reply

[Value]

setbaudrate

Defines **Serial communication** baud rate settings.

Syntax

[Value] [/] **setbaudrate**

Examples

Example

Note: Unlike in the table below, all commands have to be entered *in one line*.

	Command	Description
1:	115200 setbaudrate	1 Set baud rate at standard RS232 port to 115.2 kHz.
2:	0 2 setbaudrate	Switch off optional RS232/USB port.

Dynamics

Acceleration



This states defines how the next move ramps up. The acceleration is normally defined in mm/s². Minimum setting is 1 µm/s²; maximum setting is 500 m/s² (50G).

Commands

gna (getnaccel)	45
sna (setnaccel)	45

Properties

Type: double
Unit: mm/s²

gna (getnaccel)

Returns the current setting of the **Acceleration**.

Syntax

{device} **gna**

Reply

[acceleration]

sna (setnaccel)

Sets the **Acceleration**.

Syntax

[acceleration] {device} ***sna***

Stop deceleration



storable

Deceleration for immediate halt used upon

- touch of either end switch during any move
- **Move abortion** (p. 113)
- Ctrl+C shortcut

Commands

ssd (setstopdecel)	47
gsd (getstopdecel)	47

Properties

Type: double

Unit: mm/s²

ssd (setstopdecel)

Sets the **Stop deceleration**.

Syntax

[stop_deceleration] {device} **ssd**

gsd (getstopdecel)

Returns the current setting of the **Stop deceleration**.

Syntax

{device} ***gsd***

Reply

[stop_deceleration]

Velocity



storable

Velocity used by all programmed moves but

- **Calibration move** (p. 87)
- **Range measure move** (p. 105)
- **Reference move** (p. 117)
- **Vector reference move**

Must range between +10 nm/s and +10 m/s.

Commands

gnv (getnvel)	49
snv (setnvel)	50

Properties

Type: [double](#)

gnv (getnvel)

Returns the current setting of the **Velocity**.

Syntax

{device} **gnv**

Reply

[velocity]

snv (setnvel)

Sets the **Velocity**.

Syntax

[velocity] {device} **snv**

InputOutput

Digital input event command



storable

String containing a chain of commands executed upon occurrence of an event (positive level transition) at a specified digital input. String length is up to 255 characters.

To be used with inputs at external devices (such as joystick buttons) only. Input indexes 0 through 15 are reserved for onboard controller inputs which do not support this feature.

Commands

getdincmd.....	52
setdincmd.....	53

Properties

<i>i</i>	Name	Type
16	[joystick 1 button 1]	string
17	[joystick 1 button 2]	string
18	[joystick 1 button 3]	string
19	[joystick 1 button 4]	string
20	[joystick 1 button 5]	string
21	[joystick 1 button 6]	string

getdincmd

Returns currently set **Digital input event command** string.

Syntax

[*i*] ***getdincmd***

Reply

[*Value*]

setdincmd

Sets the ***Digital input event command***. Use the SPACE character in order to separate symbols from each other.



Query commands (commands that imply a Venus interpreter reply such as ***np*** or ***nst***) will be ignored.

Syntax

[*Value*] [*i*] ***setdincmd***

Examples

Example

Task: Configure buttons at a connected joystick.

Note: Unlike in the table below, all commands have to be entered *in one line*.

	Command	Description
1:	"1 1 setcloop 1 16 setdout" 16 setdincmd	Configure button 1 to close position control loop at axis 1 and turn on LED 1.
2:	"0 1 setcloop 0 16 setdout" 17 setdincmd	Configure button 2 to open position control loop at axis 1 and turn off LED 1.
3:	"1 2 setcloop 1 17 setdout" 18 setdincmd	Configure button 3 to close position control loop at axis 2 and turn on LED 2.
4:	"0 2 setcloop 0 17 setdout" 19 setdincmd	Configure button 4 to open position control loop at axis 2 and turn off LED 2.
5:	"1 ncal 2 ncal" 20 setdincmd	Configure button 5 to initiate calibration move at both axes.
6:	"reset" 21 setdincmd	Configure button 6 to reset controller.

Result: On button pressure, the controller will react as specified.

Digital output level



Level at specified digital output which can either be a controller output or a digital output at a connected device such as a joystick indicator LED. Outputs supported at the time:

output index	destination
0	controller TTL I/O 1 *
1	controller TTL I/O 2 *
2	controller open drain output
3...15	reserved
16...23	joystick LEDs 1...8

* hardware I/O, invariably configured as output

Commands

getdout.....	56
setdoutfreq.....	56
setdout.....	56

Properties

Name	Type	Description
[Index]	int	see table above
[Value]	int	0 = off, 1 = on

getdout

Returns currently set ***Digital output level***.

Syntax

[Index] **getdout**

Reply

[Value]

setdoutfreq

Sets digital output toggle rate. If set to 0, the output will be permanently set as long as the level is set to 1. A value different from 0 will cause the output to turn on and off alternatingly instead. Unit is 250 μ s ticks.



This feature is available for direct controller outputs (indexes 0..2) only.

Syntax

[Value] [Index] **setdoutfreq**

setdout

Sets ***Digital output level*** as specified.

Syntax

[Value] [Index] **setdout**

Examples

Example

	Command	Description
1:	1 18 <i>setdout</i>	Turn on joystick LED 3.
2:	0 16 <i>setdout</i>	Turn off joystick LED 1.

Emergency switch



On demand, the emergency shut-off switch can be disabled (masked). If there is no need for the shut-off switch function, this allows for running the controller without having to connect an external bridge dummy.



When disabled, a connected switch will have no effect. However, the setting does not affect any emergency-off feature based on error detection (overcurrent, following error etc.).

Commands

getemsw.....	58
setemsw.....	59

Properties

Type: `int`

value	enable state
0	disabled
1	enabled

getemsw

Returns the current setting of the *Emergency switch*.

Syntax

getemsw

Reply

[mask]

setemsw

Sets the ***Emergency switch*** configuration.

Syntax

[mask] ***setemsw***

Interpreter

Configuration storage (Controller)

Storage of the specified device's non-volatile parameters.

Commands

save.....	61
csave.....	61

save

Syntax

save

csave

With this command the configuration of the controller and all axes are saved in the flash filesystem.

Syntax

csave

Configuration storage (Axis)

Storage of the specified device's non-volatile parameters.

Commands

nsave..... 62

nsave

Executes *Configuration storage*.

Syntax

{device} *nsave*

Error decoder

Decoder which generates an error description string from a given error code.

Commands

errordecode.....	63
merrordecode.....	64

Properties

Name	Type
[errorcode]	int
[errorstring]	string

errordecode

Returns string generated by ***Error decoder*** from an interpreter error code.

Syntax

[errorcode] ***errordecode***

Reply

[errorstring]

merrordecode

Returns string generated by ***Error decoder*** from a machine error code.

Syntax

[errorcode] ***merrordecode***

Reply

[errorstring]

Interpreter error (Controller)



read-only

Commands

ge..... 65

Properties

Type: [int](#)

ge

Returns the actual ***Interpreter error***.

Syntax

ge

Reply

[errorregister]

Interpreter error (Axis)



read-only

Commands

gne..... 66

Properties

Type: [int](#)

gne

Returns the actual ***Interpreter error***.

Syntax

{device} ***gne***

Reply

[errorregister]

Parameter stack (Axis)



read-only

Stack for Venus parameters. Temporarily contains parameter values entered until further processing. Should be empty if no commands pending. The *stackpointer* indicates the number of parameter values currently pending.

Commands

<code>nclear</code>	67
<code>ngsp</code>	68

Properties

Type: [int](#)

nclear

Clears ***Parameter stack***, discarding its content. Although this command is axis specific, there is no axis specific parameter stack; therefore execution yields same result as ***clear***. Compatibility purpose only.



Normally, no parameters are left on the stack, unless too many parameter values are entered with a certain command.

Syntax

{device} ***nclear***

ngsp

Returns number of parameter values currently pending on ***Parameter stack***. Although this command is axis specific, there is no axis specific parameter stack; therefore execution yields same result as ***gsp***. Compatibility purpose only.

Syntax

{device} ***ngsp***

Reply

[stackpointer]

User doubles



storable

User memory, double type portion. Each single entry stores one floating point value.

Commands

setvardbl.....	69
getvardbl.....	70

Properties

<i>i</i>	Name	Type
0	[vardbl_0]	double
1	[vardbl_1]	double
2	[vardbl_2]	double
3	[vardbl_3]	double
4	[vardbl_4]	double
5	[vardbl_5]	double
6	[vardbl_6]	double
7	[vardbl_7]	double
8	[vardbl_8]	double
9	[vardbl_9]	double

setvardbl

Sets the the specified ***User doubles*** entry.

Syntax

[*Value*] [*i*] **setvardbl**

getvardbl

Returns the current setting of the the specified **User doubles** entry.

Syntax

[*i*] **getvardbl**

Reply

[*Value*]

User integers



storable

User memory, integer type portion. Each single entry stores one integer value.

Commands

setvarint.....	71
getvarint.....	72

Properties

<i>i</i>	Name	Type
0	[vardbl_0]	int
1	[vardbl_1]	int
2	[vardbl_2]	int
3	[vardbl_3]	int
4	[vardbl_4]	int
5	[vardbl_5]	int
6	[vardbl_6]	int
7	[vardbl_7]	int
8	[vardbl_8]	int
9	[vardbl_9]	int

setvarint

Sets the the specified *User integers* entry.

Syntax

[*Value*] [*i*] **setvarint**

getvarint

Returns the current setting of the the specified **User integers** entry.

Syntax

[*i*] **getvarint**

Reply

[*Value*]

User strings



storable

User memory, string type portion. Each single entry stores one string.

Commands

setvarstring.....	73
getvarstring.....	74

Properties

<i>i</i>	Name	Type
0	[varstring_0]	string
1	[varstring_1]	string
2	[varstring_2]	string
3	[varstring_3]	string
4	[varstring_4]	string
5	[varstring_5]	string
6	[varstring_6]	string
7	[varstring_7]	string
8	[varstring_8]	string
9	[varstring_9]	string

setvarstring

Sets the the specified ***User strings*** entry.

Syntax

[*Value*] [*i*] ***setvarstring***

getvarstring

Returns the current setting of the the specified ***User strings*** entry.

Syntax

[*i*] ***getvarstring***

Reply

[*Value*]

Manual operation

Manual device entry



Entry which allows for access to a specified parameter of a specified manual device. The target manual device is selected by the *control index*, whereas the *parameter index* allows for choice of one parameter out of the **Manual device parameters** (p. 79) set.

Commands

setmanpara.....	76
getmanpara.....	77

Properties

Name	Type	Description
[control index]	int	selection index of target manual device
[parameter index]	int	selection index of target parameter (see Manual device parameters , [i] column)
[parameter value]	double	value selected parameter is to be set to

setmanpara

Changes the current setting of one of the **Manual device parameters** (p. 79) .

Syntax

[parameter value] [parameter index] [control index] {device}
setmanpara

Examples

Example

	Command	Description
1:	100 1 1 1 setmanpara	Sets the <i>velocity</i> at the 1st manual device of axis 1 to 100 mm/s.
2:	2 6 1 2 setmanpara	Sets the <i>input function</i> at the 1st manual device of axis 2 to cubic progression.

getmanpara

Returns the current setting of one of the **Manual device parameters**.

Syntax

[parameter value] [parameter index] [control index] {device}
getmanpara

The *parameter value* entry is an ineffective dummy here; any value (e.g. 0) will be taken. If it is ommitted, though, proper execution is still granted, but the Venus interpreter will report an **Interpreter error** ^(p. 65) (code 1002). This is due to the specific parameter stack handling.

Reply

[parameter value]

Examples

Example

	Command	Description
1:	0 2 1 1 <i>getmanpara</i>	Returns the <i>acceleration</i> setting at the 1st manual device of axis 1.
2:	0 7 2 1 <i>getmanpara</i>	Returns the <i>mode</i> setting at the 2nd manual device of axis 1.

Manual device parameters



storable

Properties of specific manual device.



A programmed move unconditionally overrides manual motion.

As for the *mode*, there are 3 different settings:

- 0: disabled
- 1: enabled until next programmed move; disabled afterwards
- 2: enabled until next programmed move and afterwards

Properties

<i>i</i>	Name	Type	Unit	Description
1	[velocity]	double	mm/s	standard manual move velocity
2	[acceleration]	double	mm/s ²	manual move acceleration
3	[alt. velocity]	double	mm/s	manual move velocity valid when button pressed - void since firmware rev. 2.200
4	[resolution]	int	1/rev	handwheel - encoder steps per revolution
5	[ratio]	double	mm/rev	handwheel - distance covered per revolution
6	[input function]	int	-	joystick - elongation to velocity transfer function (0: linear, 1: square, 3: cubic, etc.)
7	[mode]	int	-	0: disabled, 1: conditionally enabled, 2: enabled
8	[threshold]	double	-	elongation threshold below which generated velocity will be 0; normalized to elongation range (1.0 => full elongation)
9	[direction]	int	-	effective direction (0, 1)

<i>i</i>	Name	Type	Unit	Description
10	[input driver]	int	-	0: joystick 1
11	[input channel]	int	-	joystick - 0: horizontal, 1: vertical

Manual motion control



storable

Integrated activation state of all manual devices assigned to axis device. Allows for bitwise enabling / disabling.

Commands

setmanctrl..... 81
getmanctrl..... 81

Properties

Type: `int`

0: disabled - 1: enabled

setmanctrl

Sets the **Manual motion control**.

Syntax

[enable state] {device} **setmanctrl**

getmanctrl

Returns the current setting of the **Manual motion control**.

Syntax

{device} **getmanctrl**

Reply

[enable state]

Mechanic

Pitch



storable

Move distance to be covered by one complete motor axis turn.



To operate the device in closed loop mode, the parameter setting has to provide that delivered move distances equal actually covered move distances. See also ***Motor pole pairs*** (p. 138)

Commands

getpitch.....	84
setpitch.....	85

Properties

Type: double

Unit: mm

getpitch

Returns the current setting of the ***Pitch***.

Syntax

{device} ***getpitch***

Reply

[pitch]

setpitch

Sets the **Pitch**.



Upon change of **Pitch**, the motor axis may leap to another position. This can be avoided by moving the device to its initial position origin before changing.

Syntax

[pitch] {device} **setpitch**

Examples

	Command	Description
1:	5 1 setpitch	Sets pitch at device 1 to 5 mm per turn.
2:	10 1 nr	Moves device 1 by 10 mm.

Causes device 1 motor axis to turn twice.

Mechanic setup

Calibration move

Composite move for the purpose of finding the lower motion range limit and defining the position origin. Partial operations in the order of execution:

- motion towards "Cal" end switch until touching
- backward motion until switch is released
- continuation of backward motion until **Calibration switch distance** (p. 88) is covered
- definition of actual position as new origin of the reference coordinate system, i.e nominal position is 0 afterwards (see **Device position** (p. 190))
- setting of **Hardware limits** (p. 92) to 0 (lower limit) and default (upper limit)

Commands

ncal (ncalibrate)87

ncal (ncalibrate)

Initiates a **Calibration move**.

Syntax

{device} **ncal**

Calibration switch distance



storable

Distance from "Cal" end switch at which **Calibration move** (p. 87) terminates.

Commands

getncalswdist..... 88
setncalswdist..... 88

Properties

Type: double
Unit: mm

getncalswdist

Returns the current setting of the **Calibration switch distance**.

Syntax

{device} **getncalswdist**

Reply

[dist from switch]

setncalswdist

Sets the **Calibration switch distance**.

Syntax

[dist from switch] {device} ***setncalswdist***

Calibration velocity



Velocity at which a **Calibration move** (p. 87) will run. Set separately for motion towards switch and backward motion, respectively.

Commands

getncalvel..... 90
setncalvel..... 91

Properties

<i>i</i>	Name	Type	Unit
1	[vel into switch]	double	mm/s
2	[vel out of switch]	double	mm/s

getncalvel

Returns the current setting of the **Calibration velocity**.

Syntax

[*i*] {device} **getncalvel**

Reply

[*Value*]

setncalvel

Sets the ***Calibration velocity***.

Syntax

[*Value*] [*i*] {device} ***setncalvel***

Hardware limits



Limits of available motion range, applying to all moves except **Calibration move** (p. 87) and **Range measure move** (p. 105). The effect is that if the move's end position exceeds the specified range, the respective range limit will be targetted instead.



Limits will be affected by each move touching either end switch.



For initialization of the limits with defined values after powerup, see **Initial limits** (p. 94) .

Commands

getnlimit.....	92
setnlimit.....	93

Properties

Name	Type	Unit
[upperlimit]	double	mm
[lowerlimit]	double	mm

getnlimit

Returns the current setting of the **Hardware limits**.

Syntax

{device} **getnlimit**

Reply

[lowerlimit] [upperlimit]

setnlimit

Sets the ***Hardware limits***.

Syntax

[lowerlimit] [upperlimit] {device} ***setnlimit***

Initial limits



Defines storable values for the initialization of the **Hardware limits** (p. 92) . The limits are valid after powerup until changed manually or by any hit of an end switch during execution of a move command except for **Calibration move** (p. 87) .



Regard that the initial limits will not be matched upon change of the **Position origin** (p. 100) .

Commands

getinilimit.....	94
setinilimit.....	95

Properties

Name	Type	Unit
[upperlimit]	double	mm
[lowerlimit]	double	mm

getinilimit

Returns the current setting of the **Initial limits**.

Syntax

{device} **getinilimit**

Reply

[lowerlimit] [upperlimit]

setinilimit

Sets the ***Initial limits***.

Syntax

[lowerlimit] [upperlimit] {device} ***setinilimit***

Motion direction



Defines the device's spatial orientation. When inverted, the motor's rotation/motion direction and the end switch assignment are being inverted simultaneously.



With the position decreasing, the device is always moving towards "Cal" switch. With the position increasing, the device is always moving towards "RM" switch. This does NOT depend on the parameter setting.



Regard that the setting has to be consistent with the count direction of the respective position sensor. Put the device into open loop mode before changing the parameter setting in order to avoid unwanted motion in either direction.

Commands

setmotiondir.....	96
getmotiondir.....	97

Properties

Type: [int](#)

setmotiondir

Sets the ***Motion direction***.

Syntax

[direction] {device} ***setmotiondir***

getmotiondir

Returns the current setting of the ***Motion direction***.

Syntax

{device} ***getmotiondir***

Reply

[direction]

Motion function



Defines the respective activation states of **Calibration move** (p. 87), **Range measure move** (p. 105) and **Reference move** (p. 117) by a bit-coded value. If the respective bit is low, each corresponding move request will be discarded.



Calibration move and **Range measure move** should be disabled if no corresponding end switch is connected. **Reference move** should be disabled if the measurement system connected does not provide a reference mark.

Bit number	description
0	Calibration move activation
1	Range measure move activation
2	Reference move activation

Commands

getmotionfunc.....	98
setmotionfunc.....	99

Properties

Type: `int`

getmotionfunc

Returns the current setting of the **Motion function**.

Syntax

{device} **getmotionfunc**

Reply

[mask]

setmotionfunc

Sets the *Motion function*.

Syntax

[mask] {device} *setmotionfunc*

Examples

Example 1

Task: Disable *Range measure move* (p. 105), but leave *Calibration move* (p. 87) and *Reference move* (p. 117) enabled.

	Command	Description
1:	5 1 <i>setmotionfunc</i>	Sets bit 2 and 0 and clears bit 1 in the register.

Result: Any *Calibration move* request will be ignored afterwards.

Position origin



storable

Defines location of position origin relative to its initial location.

Commands

getnpos..... 100
setnpos..... 101

Properties

Type: double

Unit: mm

getnpos

Returns current ***Position origin***.

Syntax

{device} ***getnpos***

Reply

[position]

Examples

Example 1

A sequence of commands (targeting device 1), showing the **setnpos** (p. 101)/**getnpos** mode of operation, assuming no **setnpos** command was executed since last powerup, and that the effective direction of the offset (see **Position origin configuration** (p. 103)) is set to default (0).

	Command	Description
1:	1 getnpos	Returns origin offset which is 0 by default.
2:	20 1 nm	Induces a 20 mm move into positive direction. So upon arrival, origin is located 20 mm from current nominal position in negative direction. Nominal position is now 20 mm.
3:	10 1 setnpos	Shifts origin to position which is located 10 mm from current nominal position (20 mm) in positive direction. So from its former position, origin is being shifted by (20 mm + 10 mm) = 30 mm into positive direction. Nominal position is now -10 mm.
4:	1 getnpos	Returns current origin offset which is now 30 mm.
5:	-20 1 setnpos	Shifts back origin to position which is located 20 mm from current nominal position in negative direction, i.e. to its initial position. Nominal position is 20 mm again.
6:	1 getnpos	Returns current origin offset which is 0 again.

setnpos

Redefines **Position origin**. Value has to be entered relative to current nominal position.

Syntax

[position] {device} **setnpos**

Examples

Example 1

	Command	Description
1:	50 1 setnpos	Shifts origin of device 1 to position located 50 mm from current nominal position in positive direction. Nominal position is -50 mm afterwards.

Example 2

	Command	Description
1:	-20 2 setnpos	Shifts origin of device 2 to position located 20 mm from current nominal position in negative direction. Nominal position is 20 mm afterwards.

Note: Examples 1 and 2 assuming that the effective direction of the offset (see **Position origin configuration**) is set to default (0).

Example 3

	Command	Description
1:	0 1 setnpos	Shifts origin of device 1 to current nominal position. Nominal position is 0 afterwards.

Position origin configuration



Configures the handling of the ***Position origin*** (p. 100) . The only parameter to be configured at the time is the effective direction, i.e. the sign of the origin.

Commands

getorgconfig.....	103
setorgconfig.....	104

Properties

<i>i</i>	Name	Type	Description
1	[sign]	int	0: <i>Position origin</i> defines offset of new user origin, measured from initial origin 1: <i>Position origin</i> defines offset of initial origin, measured from new user origin

getorgconfig

Returns current ***Position origin configuration***.

Syntax

[*i*] {device} ***getorgconfig***

Reply

[*Value*]

setorgconfig

Sets the ***Position origin configuration***.

Syntax

[*Value*] [*i*] {device} **setorgconfig**

Examples

Example

Precondition: Each axis is positioned at its initial origin.

Note: Unlike in the table below, all commands have to be entered *in one line*.

	Command	Description
1:	0 1 1 setorgconfig	Configure origin direction at axis 1.
2:	1 1 2 setorgconfig	Configure origin direction at axis 2.
3:	10 1 setnpos	Define new position origin at axis 1.
4:	10 2 setnpos	Define new position origin at axis 2.
5:	1 np	Returns -10.000000.
6:	2 np	Returns 10.000000.
7:	1 getnpos (p. 100)	Returns 10.000000.
8:	2 getnpos	Returns -10.000000.

Range measure move

Composite move for the purpose of finding the upper motion range limit. Partial operations in the order of execution:

- motion towards "RM" end switch until touching
- backward motion until switch is released
- setting of upper hardware limit (see *Hardware limits* (p. 92)) to actual position

Commands

nrm (nrangemeasure)	105
-----------------------------	-----

nrm (nrangemeasure)

Initiates a *Range measure move*.

Syntax

{device} *nrm*

Range measure velocity



Velocity at which a **Range measure move** (p. 105) will run. Set separately for motion towards switch and motion out of switch, respectively.

Commands

setnrmvel.....	106
getnrmvel.....	106

Properties

<i>i</i>	Name	Type	Unit
1	[vel into switch]	double	mm/s
2	[vel out of switch]	double	mm/s

setnrmvel

Sets the **Range measure velocity**.

Syntax

[*Value*] [*i*] {device} **setnrmvel**

getnrmvel

Returns the current setting of the **Range measure velocity**.

Syntax

[*i*] {device} ***getnrmvel***

Reply

[*Value*]

Reference velocity



Defines motion velocity for reference position mark detection. The setting takes effect upon execution of ***refmove*** (p. 112) and ***nrefmove*** (p. 117).

Commands

getnrefvel.....	108
setnrefvel.....	109

Properties

<i>i</i>	Name	Type
1	[forward velocity]	double
2	[backward velocity]	double

getnrefvel

Returns the current setting of the ***Reference velocity***.

Syntax

[*i*] {device} ***getnrefvel***

Reply

[*Value*]

setnrefvel

Sets the ***Reference velocity***.

Syntax

[*Value*] [*i*] {device} ***setnrefvel***



Motion

Absolute move

Moving the axis is controlled by this state. The parameter is the target position starting at the actual position.
If previous move action has not finished and a new move command is received, then the current motion will be interrupted and the new motion is initiated to the new target.
If the new move is in the same direction as the previous one, then no motion stop will be initiated. Only the acceleration and the velocity will be adapted to the new move command.
Actual a move must be in range of -+200 m.
The resolution is 1 nm if the default unit of mm is used.

Commands

nm (nmove) 111

Properties

Type: double

nm (nmove)

Syntax

[targetposition] {device} *nm*

Controller reference move

Extended version of **Reference move** (p. 117) ; same function, but run at all available axes simultaneously. All axes will cover the same given distance, but each one will conform its individual **Reference velocity** (p. 108) and **Reference configuration** (p. 194) .

Commands

refmove..... 112

Properties

Type: double

Unit: mm

refmove

Initiates a **Controller reference move**.

Syntax

[distance] **refmove**

Move abortion

Immediate stop of currently running move. **Stop deceleration** (p. 47) is used as stopping slope.

Commands

nabort..... 113

nabort

Executes **Move abortion**.

Syntax

{device} **nabort**

Parameterised absolute move



Absolute move which takes individual dynamic parameter settings (velocity, acceleration) instead of using the global ones.



The *acceleration* parameter also defines the deceleration at move termination. The *deceleration* parameter is a noneffective dummy at the time. It has to be entered with the command line nonetheless.

Commands

pm..... 114

Properties

Name	Type	Unit	Description
[targetposition]	double	mm	target position of move
[velocity]	double	mm/s	target velocity during move
[acceleration]	double	mm/s ²	acceleration / deceleration
[deceleration]	double	-	noneffective

pm

Initiates a ***Parameterised absolute move***.

Syntax

{device} ***pm***

Parameterised relative move



Relative move which takes individual dynamic parameter settings (velocity, acceleration) instead of using the global ones.



The *acceleration* parameter also defines the deceleration at move termination. The *deceleration* parameter is a noneffective dummy at the time. It has to be entered with the command line nonetheless.

Commands

pr..... 115

Properties

Name	Type	Unit	Description
[distance]	double	mm	move distance to be covered
[velocity]	double	mm/s	target velocity during move
[acceleration]	double	mm/s ²	acceleration / deceleration
[deceleration]	double	-	noneffective

pr

Initiates a ***Parameterised relative move.***

Syntax

{device} ***pr***

Random move

A sequence of moves targeting virtually random positions at virtually random velocities. The distance and velocity of each invidual move are calculated in a way it will not take more than about 8 seconds. Move velocity will be **Velocity**_(p. 49) at most, and move acceleration/deceleration will be **Acceleration**_(p. 45) . Upon execution of Ctrl+C or **nabort**_(p. 113), the device will halt immediately.



For move parameter calculation, valid move range limits are needed. Therefore execution of the move will fail unless the limits have been set before - either manually or by execution of **ncal**_(p. 87) and **nrm**_(p. 105) (in this order).

Commands

nrandmove..... 116

nrandmove

Executes **Random move**.

Syntax

{device} **nrandmove**

Reference move

Relative move covering the given distance. While moving, reference position mark detection is performed according to **Reference configuration** (p. 194). If the mark is detected before reaching the end position, the device will brake and return to the mark's location. See also **Reference velocity** (p. 108) and **Reference status** (p. 196) .



Decreasing **Reference velocity** setting helps increase the precision of reference detection. With the device moving too fast, one of the following may happen:

- reference detection fails though the mark is covered by move range
- with reference mark found, motion stops at its edge, so afterwards the reference signal may be alternating or inactive

Commands

nrefmove..... 117

Properties

Type: double
Unit: mm

nrefmove

Initiates a **Reference move**.

Syntax

[distance] {device} **nrefmove**

Relative move

Move covering the given distance. Uses **Velocity** (p. 49) and **Acceleration** (p. 45).



With firmware revisions older than 2.200, the distance always refers to the lastly calculated end position as the move starting point. That means if a running Relative move is cancelled by execution of another Relative move, the altogether covered distance will be the sum of the individual move distances. It also means that if a running manual or calibration move is cancelled by execution of a relative move, the axis will run into the respective hardware limit. With newer revisions, the distance always refers to the current nominal position in order to avoid this.

Commands

nr (nrmove)118

Properties

Type: double
Unit: mm

nr (nrmove)

Executes **Relative move**.



With firmware revisions older than 2.200, if the distance entered is zero, a currently running move will be stopped. With newer revisions, the same move request will be ignored.

Syntax

[distance] {device} *nr*

Vector absolute move

Commands

m.....	120
v2r.....	121
v2m.....	121
r.....	121

Properties

Name	Type
[y-value]	double
[x-value]	double
[status]	int

m

Syntax

[x-value] [y-value] ***m***

v2r

Syntax

[x-value] [y-value] **v2r**

Reply

[status]

v2m

Syntax

[x-value] [y-value] **v2m**

Reply

[status]

r

Syntax

[x-value] [y-value] **r**

Vector acceleration



storable

Commands

ga (getaccel)	122
sa (setaccel)	122

Properties

Type: [double](#)

ga (getaccel)

Returns the current setting of the **Vector acceleration**.

Syntax

ga

Reply

[acceleration]

sa (setaccel)

Sets the **Vector acceleration**.

Syntax

[acceleration] **sa**

Vector velocity



storable

Commands

sv (setvel)	124
gv (getvel)	124

Properties

Type: **double**

sv (setvel)

Sets the ***Vector velocity***.

Syntax

[velocity] **sv**

gv (getvel)

Returns the current setting of the ***Vector velocity***.

Syntax

gv

Reply

[velocity]



Motor

Absolute motor current



read-only

Absolute value of the overall motor current vector which is formed out of the phase current values (***Motor phase current*** (p. 135)).

Commands

gi (getcurrent) 127

Properties

Type: double

Unit: A

gi (getcurrent)

Returns the actual ***Absolute motor current***.

Syntax

{device} ***gi***

Reply

[absolutcurrent]

Auto commutation



Automatic commutation feature, on the purpose of detecting the initial axis or slide position before applying motor power. If enabled, it is executed once during powerup. Upon success (i.e. if the procedure leads to a definite result), the axis or slide movement caused by motor power application will be reduced to a minimum. Parameter settings vary according to motor type and load.



2500 μ s has emerged to be a **time** parameter value that works in most cases, whereas the voltage parameter value is motor type specific.

Commands

getamc.....	128
setamc.....	129

Properties

i	Name	Type	Unit	Description
1	[voltage]	double	V	Absolute motor vector voltage during procedure.
2	[time]	int	μ s	Application time of single angle step. To be set in steps of 250 μ s; otherwise rounded off or up, respectively. Disables procedure if 0 (or less than 125 μ s).

getamc

Returns the current setting of the **Auto commutation**.

Syntax

[*i*] {device} ***getamc***

Reply

[*Value*]

setamc

Configures the ***Auto commutation***.

Syntax

[*Value*] [*i*] {device} ***setamc***

Motor brake



Mechanical motor brake. It is possible to dedicate one of the digital controller outputs to a special function which is designed to control a mechanical motor brake, especially for the use with vertical axes to be held in position while the motor is without power. During powerup, the brake output will be kept at low level until the motor is powered, then go high to open the brake. In case of emergency power off, the output will switch to low level again and kept at this state until the motor is repowered by **Motor restart** (p. 145) .

output index	destination
0	controller TTL I/O 1 *
1	controller TTL I/O 2 *
2	controller open drain output

* hardware I/O, invariably configured as output



Neither does the brake control output function generally overrule the **Digital output level** (p. 55) function, nor vice versa. Any level settings will be executed. It is up to the user to avoid potential conflicts.

Commands

getbrakefunc.....	131
setbrakefunc.....	131

Properties

<i>i</i>	Name	Type	Description
0	[brake enable]	int	brake function (0: disabled 1: enabled)
1	[output]	int	brake control output index

getbrakefunc

Returns the current configuration of the **Motor brake** control function.

Syntax

[*i*] {device} **getbrakefunc**

Reply

[*Value*]

setbrakefunc

Configures the **Motor brake** control function.

Syntax

[*Value*] [*i*] {device} **setbrakefunc**

Examples

Example 1

	Command	Description
1:	2 1 <i>setbrakefunc</i>	Configure the open drain output to control the motor brake.
2:	1 0 <i>setbrakefunc</i>	Enable motor brake control function.

Motor current limit



Defines the motor current limit used for safety purposes. As soon as the actual **Absolute motor current** (p. 127) exceeds this limit during operation, the device will be put into emergency state; i.e. the motor will be powered down and kept shut down until **Motor restart** (p. 145) .

Commands

getmaxcurrent..... 133
setmaxcurrent.....133

Properties

Type: double
Unit: A

getmaxcurrent

Returns the current setting of the **Motor current limit**.

Syntax

{device} **getmaxcurrent**

Reply

[maximum_current]

setmaxcurrent

Sets the **Motor current limit**.

Syntax

[maximum_current] {device} ***setmaxcurrent***

Motor phase current



read-only

Measured current at 2 motor phases. See also ***Absolute motor current*** (p. 127) .

Commands

gc.....135

Properties

Name	Type	Unit
[current phase1]	double	A
[current phase2]	double	A

gc

Returns the actual ***Motor phase current***.

Syntax

{device} **gc**

Reply

[current phase1] [current phase2]

Motor phase number



storable

Number of motor phases. To be set to 2 or 3, depending on the used motor.



A mismatched setting will prevent proper motor operation.

Commands

setphases.....	136
getphases.....	136

Properties

Type: `int`

setphases

Sets the ***Motor phase number***.

Syntax

[phase] {device} ***setphases***

getphases

Returns the current setting of the ***Motor phase number***.

Syntax

{device} ***getphases***

Reply

[phase]

Motor pole pairs



storable

Number of motor polepairs. Normally set to 50 or 100 when the controller is used with a stepper motor. To be set to 1 when the controller is used as a linear motor drive.



A mismatched setting will lead to a mismatch between delivered and actually covered move distances.

Commands

setpolepairs..... 138
getpolepairs..... 138

Properties

Type: [int](#)

setpolepairs

Sets the ***Motor pole pairs***.

Syntax

[polepairs] {device} ***setpolepairs***

getpolepairs

Returns the current setting of the ***Motor pole pairs***.

Syntax

{device} ***getpolepairs***

Reply

[polepairs]

Motor voltage gradient



storable

Velocity gradient of motor phase voltage amplitude.



Caution - to be handled with care! In order to prevent motor and controller hardware from sustaining damage, the respective maximum current ratings have to be met. Use **gc** (p. 135) and **gi** (p. 127) for current observation.

Commands

setumotgrad.....	140
getumotgrad.....	140

Properties

Type: double

setumotgrad

Sets the **Motor voltage gradient**.

Syntax

[voltage_gradient] {device} **setumotgrad**

getumotgrad

Returns the current setting of the **Motor voltage gradient**.

Syntax

{device} ***getumotgrad***

Reply

[voltage_gradient]

Motor voltage minimum



storable

Base rate of motor phase voltage amplitude.



Caution - to be handled with care! In order to prevent motor and controller hardware from sustaining damage, the respective maximum current ratings have to be met. Use **gc** (p. 135) and **gi** (p. 127) for current observation.

Commands

getumotmin.....	142
setumotmin.....	143

Properties

Type: double

Unit: V

getumotmin

Returns the current setting of the **Motor voltage minimum**.

Syntax

{device} **getumotmin**

Reply

[minimum_voltage]

setumotmin

Sets the ***Motor voltage minimum***.

Syntax

[minimum_voltage] {device} ***setumotmin***

Safety functions

Motor restart

Motor restart feature. Allows for resuming full operation from emergency state without needing a controller reset or losing the position or the reference coordinate system.

Commands

init..... 145

init

Upon execution, the following will happen:

- Motor powerup according to actual motor parameters (***Motor voltage minimum*** (p. 142) , ***Motor voltage gradient*** (p. 140)). Unwanted motion is reduced to a minimum.
- Reactivation of positioning controller according to actual ***Positioning control mode*** setting.

Syntax


{device} ***init***




Sensoric

Position sensor routing



The Hydra controller features 3 Star interface ports which the Venus interpreter distinguishes by means of the Star sensor **device** index. Ports 1 and 2 provide connection of one external Star interface (i.e. any member of the Star interface family) each, using the Star interface 1 and 2 sockets. Access to Port 3, however, depends on the respective Hydra model. If your controller is equipped with a built-in Star interface, the latter is internally connected to Port 3, providing for direct external connection of matching position sensors at the encoder 1/2 sockets. Otherwise, Port 3 is accessible via the Star interface 3 socket.




Hydra controller with built-in Star interface



The number of position sensors connectable to a single Star interface is up to 2, varying with the model. The venus interpreter distinguishes the different sensors connected to one Star interface by means of the Star sensor **subdevice** index. The following diagrams depict the sensor connector to subdevice index association for each member of the Star family.



NanoStar interface



Normally, a position measurement system is linked to a motor axis for use with a position controller. Therefore each connected sensor has to be routed to the destination axis device, specifying Star sensor device and subdevice and axis device indexes. See **Sensor Assignment** on how sensor routing is done. After routing, sensor position and (if applicable) trigger functions can be accessed using the axis device index.

Scale period



not storable

Commands

getclperiod.....	151
setclperiod.....	151

Properties

Type: [double](#)

getclperiod

Returns the current setting of the ***Scale period***.

Syntax

{device} ***getclperiod***

Reply

[Period]

setclperiod

Sets the ***Scale period***.

Syntax

[Period] {device} ***setclperiod***

Sensor amplitudes



read-only

Commands

S.....	153
SC.....	154

Properties

Name	Type
[sin amplitude track 0]	int
[cos amplitude track 0]	int
[sin amplitude track 1]	int
[cos amplitude track 1]	int
[sin amplitude track 2]	int
[cos amplitude track 2]	int

S

This command returns the amplitudes of the sensor. i.e. sin and cos amplitudes of the 3 possible sensors

Syntax

{device} **S**

Reply

```
[ sin amplitude track 0 ] [ cos amplitude track 0 ]  
  [ sin amplitude track 1 ] [ cos amplitude track 1 ]  
  [ sin amplitude track 2 ] [ cos amplitude track 2 ]
```

Examples

GetAmplitude

1 S

SC

This command returns the corrected amplitudes of the sensor. i.e. sin and cos amplitudes of the 3 possible sensors

Syntax

{device} **SC**

Reply

```
[ sin amplitude track 0 ] [ cos amplitude track 0 ]  
  [ sin amplitude track 1 ] [ cos amplitude track 1 ]  
  [ sin amplitude track 2 ] [ cos amplitude track 2 ]
```

Sensor dependency



not storable

Commands

sddump.....	155
sdupdate.....	155

Properties

Type: [int](#)

sddump

Syntax

[eeprom update] {device} ***sddump***

Reply

[eeprom update]

sdupdate

Syntax

[eeprom update] {device} ***sdupdate***

Reply

[eeprom update]

Sensor temperature



read-only

Commands

gettemp..... 157

Properties

Type: [double](#)

gettemp

Returns the actual ***Sensor temperature***.

Syntax

{device} ***gettemp***

Reply

[temperature]




Servo

Adaptive positioning control



storable

Configuration parameters used for positioning control when dynamic regulator mode is selected. In dynamic mode, the user can have the effective factors of P, I, and D portions vary individually, depending on the current nominal velocity. There is a halt setting (P_0, I_0, D_0), a control point velocity ($P_{vcp1}, I_{vcp1}, D_{vcp1}$), and a terminal setting (P_1, I_1, D_1) for each of the three parameters. When nominal velocity is zero, the respective halt setting is taken as the effective value of each of the parameters. With increasing nominal velocity, the effective value varies linearly in a way that it equals the terminal setting when the nominal velocity reaches the respective control point velocity. With the nominal velocity exceeding the control point velocity, the respective terminal setting is effective.



Note that in dynamic mode, **Servo control** (p. 173) settings are still effective, except for the P, I and D factor settings being replaced by the values calculated here.

See **Positioning control mode** (p. 163) for positioning controller mode selection.

Commands

getadaptive..... 161

setadaptive..... 162

Properties

i	Name	Type	Unit
1	[P0]	double	-
2	[I0]	double	-
3	[D0]	double	-
4	[Pvcp1]	double	mm/s
5	[Ivcp1]	double	mm/s
6	[Dvcp1]	double	mm/s
7	[P1]	double	-
8	[I1]	double	-
9	[D1]	double	-

getadaptive

Returns the current setting of the **Adaptive positioning control**.

Syntax

[i] {device} **getadaptive**

Reply

[*Value*]

setadaptive

Sets the ***Adaptive positioning control***.

Syntax

[*Value*] [*i*] {device} ***setadaptive***

Positioning control mode



storable

Determines if the positioning regulator loop is closed and, if so, in which way the regulator works.

There are two modes of operation:

- In standard mode, **Servo control** (p. 173) settings are used for position control. The effective P, I, and D factors are taken directly from the respective parameter settings, thus constant throughout operation.
- In dynamic mode, **Servo control** settings are still effective, except for the P, I and D factor settings. The effective P, I, and D factors vary over nominal velocity. Their calculation is based on the parameter settings of **Adaptive positioning control** (p. 159).

value	description
0	regulator loop is open
1	standard regulator mode
2	dynamic regulator mode

Commands

setcloop.....	163
getcloop.....	164

Properties

Type: **int**

setcloop

Sets the **Positioning control mode**.

Syntax

[state] {device} **setcloop**

Examples

	Command	Description
1:	2 1 setcloop	Sets the device 1 closed loop mode at 2.

The positioning regulator will operate in dynamic mode.

getcloop

Returns the current setting of the **Positioning control mode**.

Syntax

{device} **getcloop**

Reply

[state]

Sensor assignment



Selection of relevant position sensor. There is exactly one position sensor assigned to each Axis device, specified by the sensor device (port to which the sensor interface is connected) and subdevice (sensor selection) indexes. We also refer to this assignment as "sensor mapping" or "sensor routing".



For proper operation of positioning control, make sure that

- sensor selections and connections made are consistent
- sensor properties and respective parameter settings are consistent



Note that if the sensor interface connected to the selected port supports trigger functionality, the setting also affects the mapping of the trigger hardware. This is important because the trigger function support may be tied to one particular subdevice by hardware specification.



There is no particular parameter setting for actually "unmapping" or disconnecting an Axis device from any position sensor physically available. To achieve this, any open/unused position sensor channel can be assigned.

Commands

setassignment.....	166
getassignment.....	170

Properties

Name	Type	Description
[sensor device]	int	position measurement device
[sensor subdevice]	int	position measurement subdevice

setassignment

Sets the **Sensor assignment**.



For changing the assignment,

- first, open the positioning control loop using **setcloop** (p. 163)
- make sure all trigger functions are deactivated
- then change the setting applying **setassignment**
- store the new setting with the position control loop still open using **save**
- apply **reset** (p. 34) and wait until axis is powered up again
- check for proper and consistent connections and parameterization, correct if need be
- close the positioning control loop using **setcloop**
- check if loop works properly, fix problems if necessary
- last, store the new setting with the position control loop now closed using **save**

Syntax


[sensor subdevice] [sensor device] {device} **setassignment**

Examples


Example 1

Preconditions: The Hydra controller is equipped with a built-in DeltaStar sensor interface to which two DeltaStar sensors A and B are connected as shown below.

Hydra controller with built-in Star interface



DeltaStar interface




Task: The sensor A is to be assigned to axis device 1, sensor B to axis device 2.

	Command	Description
1:	0 3 1 <i>setassignment</i>	Assign sensor A (subdevice 0, device 3) to axis 1.
2:	1 3 2 <i>setassignment</i>	Assign sensor B (subdevice 1, device 3) to axis 2.

Example 2

Preconditions: Two external NanoStar interfaces are connected to the Hydra controller, to which again two NanoStar sensors A and B are connected as shown below.



Task: The sensor A is to be assigned to axis device 1, sensor B to axis device 2.

	Command	Description
1:	0 1 1 <i>setassignment</i>	Assign sensor A (subdevice 0, device 1) to axis 1.
2:	0 2 2 <i>setassignment</i>	Assign sensor B (subdevice 0, device 2) to axis 2.

getassignment

Returns the current setting of the *Sensor assignment*.

Syntax

{device} *getassignment*

Reply

[sensor subdevice] [sensor device]

Sensor status



read-only

Commands

getsensorstatus.....	171
sensorreconnect.....	171

Properties

Type: [int](#)

getsensorstatus

Returns the actual **Sensor status**.

Syntax

{device} ***getsensorstatus***

Reply

[sensor status]

sensorreconnect

Syntax

{device} ***sensorreconnect***

Reply

[sensor status]

Servo control



storable

Standard PID positioning regulator (***P factor, I factor, D factor***) with some extra function for linear motor drive operation (***boost value, load distance***). Additionally, the regulator can be limited regarding the integral portion (***max I vel, I limit***). If nominal position and executive position deviate by more than what ***max pos error*** specifies, the device will run into emergency off state (see also ***Motor restart*** (p. 145)).



With either of the parameters ***boost value, load distance, max I vel, I limit***, and ***max pos error*** set to 0, the respective function is disabled.



Adaptive positioning control (p. 159) is an option to vary P, I and D factors dynamically depending on the nominal velocity.



The ***boost value*** and ***load distance*** parameters have to be handled with care. It is advised to use the ***Motor current limit*** (p. 133) option before changing these.



The change of ***P factor, I factor, max I vel*** and ***I limit*** parameters while active may lead to a temporary discontinuity in position control which results in a minor motor axis leap.



When operating as ***Adaptive positioning control*** with ***max I vel*** set, the effective velocity limitation will vary with the effective I factor as follows:

$$vI_{\text{Max}_{\text{eff}}} = \text{max I vel} * I_{\text{eff}} / I \text{ factor}$$



When driving a linear motor, having velocity limitation enabled (***max I vel*** other than 0) may lead to improper driving.

For activation and deactivation of position regulation in either mode (standard or adaptive), see ***Positioning control mode*** (p. 163).

Commands

setsp..... 175

getsp..... 176

Properties

<i>i</i>	Name	Type	Unit	Description
1	[P factor]	double	-	coefficient of proportional portion
2	[I factor]	double	-	coefficient of integral portion
3	[D factor]	double	-	coefficient of differential portion
4	[I limit]	double	mm*s	absolute integral portion limit
5	[boost value]	double	-	factor for load dependent voltage boost (linear motor drive only)
6	[load distance]	double	mm	motor load distance limit (linear motor drive only)
7	[max pos error]	double	mm	position deviation threshold for emergency function
8	[max I vel]	double	mm/s	absolute variation velocity limit of integral portion (stepper motor drive only)

setsp

Configures the **Servo control**.

Syntax

[*Value*] [*i*] {device} **setsp**

getsp

Returns the current setting of the **Servo control**.

Syntax

[*i*] {device} **getsp**

Reply

[*Value*]

Target window



Width of entrance and exit windows for the position settlement indication or in-window bit (see **Axis status** (p. 182) Bit 5). As soon as the absolute position aberration constantly remains below the specified entrance window width for a period of time specified by **Time on target** (p. 179), the in-window bit changes from inactive to active state to indicate that the position has settled. As soon as the absolute position aberration once exceeds the exit window width, the indication bit changes from active to inactive state. Useful for closed loop operation only. Inactive if any parameter is set to 0.

Commands

getclwindow.....	177
setclwindow.....	178

Properties

Name	Type	Unit
[exit width]	double	mm
[entrance width]	double	mm

getclwindow

Returns the current setting of the **Target window**.

Syntax

{device} **getclwindow**

Reply

[entrance width] [exit width]

setclwindow

Sets the ***Target window***.

Syntax

[entrance width] [exit width] {device} ***setclwindow***

Time on target



storable

Position settling time for the in-window indication feature (see ***Target window*** (p. 177)).

Commands

setclwintime.....	179
getclwintime.....	179

Properties

Type: double

Unit: s

setclwintime

Sets the ***Time on target***.

Syntax

[value] {device} ***setclwintime***

getclwintime

Returns the current setting of the ***Time on target***.

Syntax

{device} ***getclwintime***

Reply

[value]

Status and position

Axis status



read-only

Actual status of the axis device. The bits of the returned status word have the following meaning:

Bit number	description
0	axis moving
1	manual move running
2	one or more machine errors occurred *
3	reserved
4	reserved
5	actual position in defined window
6	reserved for optional motionlimits
7	emergency stopped
8	motor power disabled
9	emergency-off switch active *
10	device busy - move commands discarded
11...30	reserved
31	invalid status - reset required**

* status depends on controller, not on singular axis device

** usually occurs when the emergency off switch is engaged during powerup

If all machine errors are read off the machine error stack then bit 4 is 0, but the condition for the error may not be removed (emergency stop is active). In all those cases the bit 8 is active and shows this situation. As soon as the emergency condition is removed, the **Motor restart** (p. 145) feature can be utilized to reenale the power stage of the device without a complete hardware or software reset (as necessary with some other SMC controllers).



For watching the complete system without decoding each singular axis, see **Controller status** (p. 186) .

Commands

est..... 183

nst (nstatus) 183

ast..... 184

Properties

Type: [int](#)

est

Returns the actual **Axis status**.

Syntax

{device} **est**

Reply

[status]

nst (nstatus)

Returns the actual **Axis status**.

Syntax

{device} **nst**

Reply

[status]

ast

This command is an extended form of the **nst**. The lower 16 bits represents the status of the device. The next 10 bits represents the last machine error code and the next bits are for the device nr with caused the error. The transmission of the return value is delay until the last move stops in the opposite to the command **est** (p. 183) which delivers the status immediately. ^C CRLF (control C only on one line finish with CR and LF characters) aborts the move execution on one or both axes and this command **ast** delivers the status. (since Version 1.71)

Syntax

{device} **ast**

Reply

[status]

Controller position



read-only

Integrated **Device position** (p. 190) of both axis devices. The single positions displayed conform the respective **Position display selection** (p. 191) settings.

Commands

p..... 185

Properties

Name	Type
[position X]	double
[position Y]	double

p

Returns the actual **Controller position**.

Syntax

p

Reply

[position X] [position Y]

Controller status



read-only

Partially a controller device status indication, partially a bitwise linkage of all **Axis status** (p. 182) registers which varies from one flag to another.

Bit number	description	linkage
0	axis moving	axis disjunction
1	manual move running	axis disjunction
2	one or more machine errors occurred	controller
3	reserved	-
4	reserved	-
5	actual position in defined window	axis conjunction
6	reserved for optional motionlimits	-
7	emergency stopped	axis disjunction
8	motor power disabled	axis disjunction
9	emergency-off switch active	controller
10	device busy - move commands discarded	axis disjunction
11...30	reserved	-
31	invalid status - reset required*	axis disjunction

* usually occurs when the emergency off switch is engaged during powerup

- An **axis disjunction** means the controller status flag will be set if **at least one** of the corresponding **Axis status** flags is set.
- An **axis conjunction** means the controller status flag will be set if **all** corresponding **Axis status** flags are set.
- A **controller linkage** means the corresponding flag is global, i.e. the bit setting is always equal in both the **Axis status** and **Controller status** (p. 186) registers.

Commands

st (status) 188

Properties

Type: [int](#)

st (status)

Returns the actual **Controller status**.

Syntax

st

Reply

[status]

Examples

If **st** returns 1 it means that at least one of the axis devices is executing a programmed move, and that none of the other status bits is active at either device.

Device position



read-only

Actual device position, displayed selectively as the nominal or measured position (see ***Position display selection*** (p. 191)).

Commands

np..... 190

Properties

Type: double
Unit: mm

np

Returns the actual ***Device position***.

Syntax

{device} ***np***

Reply

[position]

Position display selection



storable

Selection of position displayed as **Device position** (p. 190) .

Commands

setselpos..... 191
getselpos..... 191

Properties

Type: [int](#)

value	selection
0	nominal position
1	measured position

setselpos

Sets the **Position display selection**.

Syntax

[position source] {device} **setselpos**

getselpos

Returns the current setting of the **Position display selection**.

Syntax

{device} ***getselpos***

Reply

[position source]

Switches and reference mark

Reference configuration



Defines the mode of operation for reference position mark detection. The setting takes effect upon execution of ***refmove*** (p. 112) and ***nrefmove*** (p. 117).

Commands

getref..... 194
setref..... 195

Properties

Type: [int](#)

value	mode
0	detection on rising edge
1	detection on falling edge
2	detection disabled

getref

Returns current setting of ***Reference configuration***.

Syntax

{device} ***getref***

Reply

[config]

setref

Sets *Reference configuration*.

Syntax

[config] {device} *setref*

Examples

	Command	Description
1:	1 1 <i>setref</i>	Enables device 1 reference position mark detection on falling edges.

Upon execution of *refmove* (p. 112) or 1 *nrefmove* (p. 117), device 1 will brake as soon as a reference signal high-to-low transition occurs, then return to respective position.

Reference status



read-only

Status of reference mark detection. Bits 0 and 1 are affected by **Reference move** (p. 117) only. Once set, they stay set until next execution of **Reference move**.

Commands

getrefst..... 196

Properties

Type: **int**

bit	value	description
0	1	reference detected if 1
1	2	end switch detected if 1
2	4	reference active if 1

getrefst

Returns **Reference status**.

Syntax

{device} **getrefst**

Reply

[status]

Switch configuration



storable

Configuration of end switches. Options are normally open (NO), normally closed (NC) or disabled.



The reference potential for each of the switches is selected by hardware (configuration plug).

Commands

setsw.....	197
getsw.....	198

Properties

<i>i</i>	Name	Type	Description
0	[calibration sw.]	int	0 = NO, 1 = NC, 2 = disabled
1	[range measure sw.]	int	0 = NO, 1 = NC, 2 = disabled

setsw

Sets the **Switch configuration**.

Syntax

[*Value*] [*i*] {device} **setsw**

getsw

Returns the current setting of the ***Switch configuration***.

Syntax

[*i*] {device} ***getsw***

Reply

[*Value*]

Switch status



not storable

States of end switches.

Commands

getswst..... 199

Properties

Name	Type	Description
[range measure sw.]	int	0 = inactive, 1 = active
[calibration sw.]	int	0 = inactive, 1 = active

getswst

Returns the actual **Switch status**.

Syntax

{device} **getswst**

Reply

[calibration sw.] [range measure sw.]



Trigger

If your Hydra controller is equipped with a DeltaStar position sensor interface (NOT the DeltaStar Eco model), trigger signal output and position capture function is available. Each single trigger unit is part of a particular DeltaStar subdevice. Just as with position query, the trigger unit is not directly accessed by index of the respective subdevice, but by index of the Hydra axis device it is assigned to. The overview on the following page depicts the standard and optional routings. If needed, the routing can be changed by **Sensor assignment** (p. 165) .


The DeltaStar subdevice 0 offers one trigger signal input (**trigger input A**) for position capture and two trigger signal outputs (**trigger output A 1**, **trigger output A 2**). Subdevice 1 offers one trigger signal input (**trigger input B**) only; subdevice 1 trigger outputs are physically available, but not driven.

1. Output trigger function

The Hydra output trigger concept distinguishes generation of trigger events from the generation of the actual signal output as shown below.

The **trigger event generator** puts out a single trigger event whenever certain conditions (mostly concerning the currently measured slide or rotor position) are met. **Trigger event setup** (p. 221) provides for definition of these conditions.

The trigger event generator simultaneously drives a suitable number of **trigger outputs** (up to 2 with the DeltaStar interface) which form trigger pulses out of each event, individually configurable regarding such parameters as **Trigger output polarity** (p. 232), **Trigger output pulse width** (p. 234), and **Trigger output delay** (p. 230). The overall result will be the output of several synchronized trigger output signals.



trigger overview




Note that

- whatever configuration options the Hydra firmware may offer, support is depending on the respective DeltaStar logic/firmware revision
- the DeltaStar interface features merely one trigger unit at subdevice 0, driving up to 2 trigger signal outputs

Trigger mode (p. 223), at last, allows for trigger activation and selection of different operation modes. It affects both the **trigger outputs** and the **trigger event generator**.

Venus interpreter



Example 1

Preconditions: The Hydra controller is equipped with a DeltaStar sensor interface. The subdevice 0 is assigned to axis device 1 (see **Sensor assignment**), so axis 1 is the position source. Current position at axis 1 is 0.

Task: Move axis 1 to 100 mm, trigger output 1 thereby generating 9 active high 5 μ s wide trigger pulses, starting at 10 mm, stopping at 90 mm, delayed by 8 μ s; direction signal at trigger output 2, start polarity high.

Note: Unlike in the table below, all commands have to be entered *in one line*.

	Command	Description
1:	5 1 1 settroutpw (p. 234)	Set trigger pulse width at output 1 at axis 1 to 5 μ s.
2:	8 1 1 settroutdelay (p. 230)	Set trigger delay at output 1 at axis 1 to 8 μ s.
3:	0 1 1 settroutpol (p. 233)	Specify trigger polarity at output 1 at axis 1 to be active high.
4:	1 2 1 settroutpol	Set start polarity at output 2 at axis 1 high.
5:	3 1 settr (p. 228)	Arm axis 1 trigger for generation of equidistant trigger pulses at output 1 and the direction signal at output 2.
6:	10 90 9 1 settrpara (p. 221)	Specify first and last trigger events to occur at axis 1 positions 10 mm and 90 mm, overall number of equidistant pulses being 9 (\Rightarrow trigger interval = 10 mm).
7:	100 1 nm	Move axis 1 to 100 mm.

Result: Trigger signals will be put out as specified while axis is moving.

Example 2

Preconditions: The Hydra controller is equipped with a DeltaStar sensor interface; the subdevice 0 is assigned to axis device 1 (see *Sensor assignment*).

Task: Put out a continuous 500 Hz signal at both trigger outputs, 3 μ s pulsewidth at both outputs, active high at output 1, inverted and delayed by 7 μ s at output 2.

	Command	Description
1:	3 1 1 <i>settroutpw</i>	Set trigger pulse width at output 1 at axis 1 to 3 μ s.
2:	3 2 1 <i>settroutpw</i>	Set trigger pulse width at output 2 at axis 1 to 3 μ s.
3:	7 2 1 <i>settroutdelay</i>	Set trigger delay at output 2 at axis 1 to 7 μ s.
4:	0 1 1 <i>settroutpol</i>	Specify trigger polarity at output 1 at axis 1 to be active high.
5:	1 2 1 <i>settroutpol</i>	Specify trigger polarity at output 2 at axis 1 to be active low.
6:	5 1 <i>settr</i>	Arm axis 1 trigger for continuous mode.

Result: Trigger signals will be put out immediately as specified.

2. Triggered position capture function

Each axis device of the Hydra controller holds a buffer of its own to take a number of captured position values from the DeltaStar subdevice assigned by **Sensor assignment**. The capture function can be enabled by **Trigger capture mode** (p. 212) for *one subdevice at a time*. An external trigger signal has to be provided at the selected subdevice's trigger input.

With the position capture function enabled at either subdevice, the DeltaStar interface watches the respective signal input. Whenever a trigger event (for definition of input trigger events see **Trigger capture polarity** (p. 214)) occurs at a specified DeltaStar signal input, the current position value at the associated DeltaStar subdevice is latched at the first free location of the associated Hydra axis device's position buffer. As soon as a capture sequence is complete, the position values can be read out via **Trigger capture position** (p. 216) .



Note that whenever the capture function is enabled at either subdevice, the measured position at subdevice 1 forwarded to the associated axis device's position controller will freeze for 500 µs duration with the occurrence of each single trigger input event. This may cause a discontinuity in positioning if that axis is moved simultaneously in closed loop mode. Therefore it is strongly recommended to either drive the axis in open loop mode or - if possible - keep the axis in standstill while a capture sequence is running.

Example 3

Preconditions: The Hydra controller is equipped with a DeltaStar sensor interface. The subdevice 0 is assigned to axis device 1 (see **Sensor assignment**). Current position at axis 1 is 0. Velocity and acceleration settings are 250 mm/s and 1000 mm/s², respectively. External active low trigger signal is provided at trigger input A. The trigger source is directly synchronized to any move

start. Controller IP address is 192.168.129.200. A TFTP command line tool is installed on the local host PC.

Task: Move axis 1 to 100 mm. Record the course of the slide/rotor by capturing the position values at time intervals of 0.1 s. A file of the record is to be stored in the local host file *record01.txt*.

Preparation: With the above settings, the move will take 0.6 s to execute. So - proper action provided - 7 position values will be captured. For security, we set the buffer size to 10. Trigger source is to be set to 10 pulses/s.

Note: Unlike in the table below, all commands have to be entered *in one line*.

	Command	Description
1:	0 1 settrinp <small>ol</small> (p. 215)	Match trigger input to the active low trigger source by making it sensitive to falling edges.
2:	10 1 settrins <small>ize</small> (p. 209)	Prepare capture buffer to record up to 10 position values.
3:	1 1 settrin (p. 212)	Arm trigger capture function.
4:	100 1 nm	Move axis 1 to 100 mm.

Result: Axis is moving, trigger pulses roll in at 0, 0.1 ... 0.6 s. Wait for finish. Then continue.

	Command	Description
1:	0 1 settrin	Disarm position capturing.
2:	1 gettrindex	Query number of captured position values. Should be 7 at least.

Query captured positions. We assume perfect action.

	Command	Description
1:	0 1 gettrinpos <small>(p. 216)</small>	Reply: 0.000000
2:	1 1 gettrinpos	Reply: 6.250000
3:	2 1 gettrinpos	Reply: 25.000000
4:	3 1 gettrinpos	Reply: 50.000000
5:	4 1 gettrinpos	Reply: 75.000000
6:	5 1 gettrinpos	Reply: 93.750000
7:	6 1 gettrinpos	Reply: 100.000000

To store the record as a text file on the host PC, firstly apply:

	Command	Description
1:	1 filetrinpos <small>(p. 217)</small>	Store text file of the above record.

Result: File captureposition.txt has been stored in Hydra RAM file system.

To store the record in a text file on the host PC, first open command line box and change to the target directory. Then type in (*one line*):

```
tftp -i 192.168.129.200 GET /ram/captureposition.txt
record01.txt
```

Result: File record01.txt has been stored in the local target directory. It contains a list of all positions captured.

Trigger capture buffer size



not storable

Maximum number of position values to be latched by trigger capture function.

Commands

settrinsize..... 209
gettrinsize..... 209

Properties

Type: [int](#)

settrinsize

Sets the ***Trigger capture buffer size***.

Syntax

[size] {device} ***settrinsize***

gettrinsize

Returns the current setting of the ***Trigger capture buffer size***.

Syntax

{device} ***gettrinsize***

Reply

[size]

Trigger capture index



not storable

Number of position values captured during last trigger capture sequence. If a trigger sequence is running at the time of query, number of positions captured so far.

Commands

gettrindex.....211

Properties

Type: [int](#)

gettrindex

Returns the current *Trigger capture index*.

Syntax

{device} **gettrindex**

Reply

[index]

Trigger capture mode



Enable state of the trigger capture function.

value	capture function
0	off
1	on

Commands

settrin.....	212
gettrin.....	212

Properties

Type: [int](#)

settrin

Sets the *Trigger capture mode*.

Syntax

[enabled] {device} **settrin**

gettrin

Returns the current setting of the *Trigger capture mode*.

Syntax

{device} **gettrin**

Reply

[enabled]

Trigger capture polarity



not storable

Defines the polarity of level transitions at the respective trigger input upon which position values will be captured.

value	capture event
0	rising edge (positive transition)
1	falling edge (negative transition)

Commands

gettrinpole.....	214
settrinpole.....	215

Properties

Type: [int](#)

gettrinpole

Returns the current setting of the *Trigger capture polarity*.

Syntax

{device} *gettrinpole*

Reply

[input polarity]

settrinpola

Sets the *Trigger capture polarity*.

Syntax

[input polarity] {device} *settrinpola*

Trigger capture position



not storable

Position value latched by trigger capture function at a given index.

Commands

gettrinpos.....216

Properties

Name	Type
[index]	int
[position]	double

gettrinpos

Returns the **Trigger capture position** stored at the specified index.

Syntax

[index] {device} **gettrinpos**

Reply

[position]

Trigger capture position file



Text file on the Hydra RAM file system containing a list of all position values recorded during the last position capture sequence, written upon **filetrnpos** (p. 217) command. With a TFTP command line tool installed on the host PC, the contents of the file can be downloaded and stored in a specified local text file as follows:

```
tftp -i ip GET /ram/captureposition.txt target
```

where

- **ip** is the IP address of the Hydra controller
- **target** is the name of the file on the local host

As opposed to using **gettrnpos** (p. 216), this saves communication time, and is particularly useful when a record contains a large number of captured values.

Commands

filetrnpos.....	217
-----------------	-----

Properties

Type: [int](#)

filetrnpos

Writes **Trigger capture position file**.

The error code returned can be decoded as follows:

value	error
0	no error - execution successful
-1	write error
-2	capture buffer empty
-3	trigger function not available
-4	no Star interface assigned

Syntax

{device} *filetrinfo*s

Reply

[error code]

Trigger delay



not storable

Delay of pulses at the second trigger signal output.



For compatibility purpose only - not for further use. Use ***Trigger output delay*** (p. 230) instead.

Commands

gettrdelay.....	219
settrdelay.....	220

Properties

Type: `int`
Unit: `0.5 µs ticks`

gettrdelay

Returns the current setting of the ***Trigger delay***.

Syntax

{device} ***gettrdelay***

Reply

[delay]

settrdelay

Sets the ***Trigger delay***.

Syntax

[delay] {device} ***settrdelay***

Trigger event setup



not storable

Trigger event generator setup, valid with **equidistant mode** (see **Trigger mode** (p. 223)).

Commands

settrpara.....	221
gettrpara.....	221

Properties

Name	Type	Unit	Description
[start position]	double	mm	first trigger position
[stop position]	double	mm	last trigger position
[number]	int	-	overall number of trigger pulses

settrpara

Sets the **Trigger event setup**. Additionally arms the trigger if it has not already been armed by the **settr** command.

Syntax

{device} **settrpara**

gettrpara

Returns the current setting of the **Trigger event setup**.

Syntax

{device} ***gettrpara***

Reply

[start position] [stop position] [number]

Trigger mode



not storable

General output trigger operation mode and activation state.

As for trigger event generation, there are 2 modes:

- the **equidistant mode**
- the **continuous mode**

As for the configuration of the second trigger output, there are 2 modes available as well:

- the **standard mode**
- the **direction mode**

Available mode combinations and parameterization:

value	trigger events	output 2 signal
0	none (off)	no output (off)
1	equidistant	standard
2	continuous	standard
3	equidistant	direction

With the **equidistant mode**, the occurrence of trigger events depends on the course of the slide or rotor position currently measured at the respective sensor subdevice. Each position meeting the trigger conditions at a time results in one single trigger event. With the trigger function enabled and the slide/rotor moving in a given direction, the trigger event generator

- gets active generating a trigger event as soon as the current nominal position reaches a given start position (trigger sequence start)
- generates further single trigger events at steps of a constant position interval **d**
- gets inactive generating a trigger event as soon as the current nominal position reaches a given stop position (trigger sequence termination)

The trigger event parameter set includes

- the overall number of trigger pulses n
- the start position s_1
- the stop position s_n

The absolute trigger position interval d and the appropriate moving direction are determined by n and the distance between s_n and s_1 . The trigger events are always processed in one direction from s_1 through s_n , as shown in the example s/t profile ($n = 3$) on the following page.



See **Trigger event setup** (p. 221) for equidistant trigger event configuration.




For query whether a trigger sequence is currently active (running), see **Trigger status** (p. 238).



Note that if the trigger function is being switched off while a trigger sequence is running, the latter will not finish, but the trigger pulse output will stop immediately.




Note that as soon as a trigger sequence has finished or been stopped before reaching the final trigger event, the trigger function has to be reenabled to start the next one.



Equidistant trigger mode principle


With the **continuous mode**, the trigger event generator puts out continuous asynchronous events at a constant frequency of approx. 500 Hz. It does not need further parameterization.

With the **standard mode**, both outputs operate equally, individually configurable regarding **Trigger output delay** (p. 230) , **Trigger output pulse width** (p. 234) and **Trigger output polarity** (p. 232) .



Standard mode principle

With the **direction mode**, output 1 operates as it does in standard mode, whereas output 2 level alternates with each single trigger event according to the scheme below. **Trigger output polarity** specifies the start polarity, while output 2 **Trigger output delay** and **Trigger output pulse width** are void.



Direction mode principle



Generation of trigger output signals requires connection to matching hardware with trigger function support.

Commands

settr.....	228
gettr.....	229

Properties

Type: [int](#)

settr

Sets the *Trigger mode*.

Syntax

[mode] {device} **settr**

gettr

Returns the current setting of the ***Trigger mode***.

Syntax

{device} ***gettr***

Reply

[mode]

Trigger output delay



not storable

Delay of trigger pulses - individual setting at the specified signal output.

Commands

settroutdelay.....	230
gettroutdelay.....	230

Properties

<i>i</i>	Name	Type	Unit
1	[output 1 delay]	double	µs
2	[output 2 delay]	double	µs

settroutdelay

Sets the *Trigger output delay*.

Syntax

[*Value*] [*i*] {device} **settroutdelay**

gettroutdelay

Returns the current setting of the *Trigger output delay*.

Syntax

[*i*] {device} ***gettroutdelay***

Reply

[*Value*]

Trigger output polarity



not storable

Polarity of trigger pulses - individual setting at the specified signal output.

value	standard mode	output 2 direction mode
0	active high	start low
1	active low	start high

Commands

gettroutpol.....	232
settroutpol.....	233

Properties

i	Name	Type
1	[output 1 polarity]	int
2	[output 2 polarity]	int

gettroutpol

Returns the current setting of the *Trigger output polarity*.

Syntax

[i] {device} *gettroutpol*

Reply

[*Value*]

settroutpol

Sets the ***Trigger output polarity***.

Syntax

[*Value*] [*i*] {device} ***settroutpol***

Trigger output pulse width



not storable

Width of trigger pulses - individual setting at the specified signal output.

Commands

settroutpw..... 234
gettroutpw..... 234

Properties

<i>i</i>	Name	Type	Unit
1	[output 1 width]	double	μs
2	[output 2 width]	double	μs

settroutpw

Sets the *Trigger output pulse width*.

Syntax

[*Value*] [*i*] {device} **settroutpw**

gettroutpw

Returns the current setting of the *Trigger output pulse width*.

Syntax

[*i*] {device} ***gettroutpw***

Reply

[*Value*]

Trigger pulse width



not storable

Unitary width of pulses at all trigger signal outputs.



For compatibility purpose only - not for further use. Use ***Trigger output pulse width*** (p. 234) instead.

Commands

settrwidth..... 236
gettrwidth..... 236

Properties

Type: `int`
Unit: `0.5 µs ticks`

settrwidth

Sets the ***Trigger pulse width***.

Syntax

[width] {device} ***settrwidth***

gettrwidth

Returns the current setting of the ***Trigger pulse width***.

Syntax

{device} ***gettrwidth***

Reply

[width]

Trigger status



Current trigger output status. When the output trigger function is active, goes 1 after first event of a trigger output sequence, and 0 after the last. For output trigger activation, see ***Trigger mode*** (p. 223) . For trigger event configuration, see ***Trigger event setup*** (p. 221) .

Commands

gettrst..... 238

Properties

Type: [int](#)

gettrst

Returns the actual ***Trigger status***.

Syntax

{device} ***gettrst***

Reply

[status]

State Reference

1. Absolute motor current.....	127	46. Parameter stack (Controller)	32
2. Absolute move.....	111	47. Parameter stack (Axis)	67
3. Acceleration.....	45	48. Parameterised absolute move.....	114
4. Adaptive positioning control.....	159	49. Parameterised relative move.....	115
5. Auto commutation.....	128	50. Pitch.....	84
6. Axis status.....	182	51. Position display selection.....	191
7. Calibration move.....	87	52. Position origin.....	100
8. Calibration switch distance.....	88	53. Position origin configuration.....	103
9. Calibration velocity.....	90	54. Positioning control mode.....	163
10. Configuration storage (Controller) ..	61	55. Random move.....	116
11. Configuration storage (Axis)	62	56. Range measure move.....	105
12. Controller identification.....	24	57. Range measure velocity.....	106
13. Controller name.....	25	58. Reference configuration.....	194
14. Controller position.....	185	59. Reference move.....	117
15. Controller reference move.....	112	60. Reference status.....	196
16. Controller status.....	186	61. Reference velocity.....	108
17. Controller version.....	26	62. Relative move.....	118
18. CPU temperature.....	27	63. Reset.....	34
19. Device class.....	28	64. Scale period.....	151
20. Device count.....	29	65. Sensor amplitudes.....	153
21. Device position.....	190	66. Sensor assignment.....	165
22. Digital input event command.....	52	67. Sensor dependency.....	155
23. Digital output level.....	55	68. Sensor status.....	171
24. Emergency switch.....	58	69. Sensor temperature.....	157
25. Error decoder.....	63	70. Serial communication.....	42
26. Hardware limits.....	92	71. Serial number.....	35
27. Initial limits.....	94	72. Servo control.....	173
28. Interpreter error (Controller)	65	73. Stop deceleration.....	47
29. Interpreter error (Axis)	66	74. Supply voltage.....	36
30. Machine error.....	30	75. Switch configuration.....	197
31. Manual device entry.....	76	76. Switch status.....	199
32. Manual device parameters.....	79	77. Target window.....	177
33. Manual motion control.....	81	78. Time of day.....	37
34. Motion direction.....	96	79. Time on target.....	179
35. Motion function.....	98	80. Trigger capture buffer size.....	209
36. Motor brake.....	130	81. Trigger capture index.....	211
37. Motor current limit.....	133	82. Trigger capture mode.....	212
38. Motor phase current.....	135	83. Trigger capture polarity.....	214
39. Motor phase number.....	136	84. Trigger capture position.....	216
40. Motor pole pairs.....	138	85. Trigger capture position file.....	217
41. Motor restart.....	145	86. Trigger delay.....	219
42. Motor voltage gradient.....	140	87. Trigger event setup.....	221
43. Motor voltage minimum.....	142	88. Trigger mode.....	223
44. Move abortion.....	113	89. Trigger output delay.....	230
45. Network.....	40	90. Trigger output polarity.....	232

91. Trigger output pulse width.....	234
92. Trigger pulse width.....	236
93. Trigger status.....	238
94. User doubles.....	69
95. User integers.....	71
96. User strings.....	73
97. Vector absolute move.....	120
98. Vector acceleration.....	122
99. Vector velocity.....	124
100. Velocity.....	49
101. Version.....	38

Command Reference

1. ast.....	184	46. getpitch.....	84
2. clear.....	33	47. getpolepairs.....	138
3. csave.....	61	48. getref.....	194
4. errordecode.....	63	49. getrefst.....	196
5. est.....	183	50. getselpos.....	191
6. filetrnpos.....	217	51. getsensorstatus.....	171
7. ga.....	122	52. getserialno.....	35
8. gc.....	135	53. getsp.....	176
9. ge.....	65	54. getstopdecel.....	47
10. getaccel.....	122	55. getsw.....	198
11. getadaptive.....	161	56. getswst.....	199
12. getamc.....	128	57. gettemp.....	157
13. getassignment.....	170	58. gettime.....	37
14. getaxc.....	29	59. gettr.....	229
15. getbaudrate.....	42	60. gettrdelay.....	219
16. getbrakefunc.....	131	61. gettrin.....	212
17. getcloop.....	164	62. gettrinindex.....	211
18. getclperiod.....	151	63. gettrinpol.....	214
19. getclwindow.....	177	64. gettrinpos.....	216
20. getclwintime.....	179	65. gettrinsize.....	209
21. getcputemp.....	27	66. gettroutdelay.....	230
22. getcurrent.....	127	67. gettroutpol.....	232
23. getdeviceclass.....	28	68. gettroutpw.....	234
24. getdincmd.....	52	69. gettrpara.....	221
25. getdout.....	56	70. gettrst.....	238
26. getemsw.....	58	71. gettrwidth.....	236
27. getinilimit.....	94	72. getumotgrad.....	140
28. getmanctrl.....	81	73. getumotmin.....	142
29. getmanpara.....	77	74. getusupply.....	36
30. getmaxcurrent.....	133	75. getvardbl.....	70
31. getmerror.....	30	76. getvariant.....	72
32. getmotiondir.....	97	77. getvarstring.....	74
33. getmotionfunc.....	98	78. getvel.....	124
34. getnaccel.....	45	79. getversion.....	26
35. getncalswdist.....	88	80. gi.....	127
36. getncalvel.....	90	81. gme.....	30
37. getnetpara.....	41	82. gna.....	45
38. getnlimit.....	92	83. gne.....	66
39. getnpos.....	100	84. gnv.....	49
40. getnrefvel.....	108	85. gsd.....	47
41. getnrmvel.....	106	86. gsp.....	32
42. getnvel.....	49	87. gv.....	124
43. getnversion.....	38	88. identify.....	24
44. getorgconfig.....	103	89. init.....	145
45. getphases.....	136	90. m.....	120

91. merrordecode.....	64	136. setdoutfreq.....	56
92. nabort.....	113	137. setemsw.....	59
93. ncal.....	87	138. setinilimit.....	95
94. ncalibrate.....	87	139. setmanctrl.....	81
95. nclear.....	67	140. setmanpara.....	76
96. ngsp.....	68	141. setmaxcurrent.....	133
97. nidentify.....	25	142. setmotiondir.....	96
98. nm.....	111	143. setmotionfunc.....	99
99. nmove.....	111	144. setnaccel.....	45
100. np.....	190	145. setncalswdist.....	88
101. nr.....	118	146. setncalvel.....	91
102. nrandmove.....	116	147. setnetpara.....	40
103. nrangeasure.....	105	148. setnlimit.....	93
104. nrefmove.....	117	149. setnpos.....	101
105. nrm.....	105	150. setnrefvel.....	109
106. nrmove.....	118	151. setnrmvel.....	106
107. nsave.....	62	152. setnvel.....	50
108. nst.....	183	153. setorgconfig.....	104
109. nstatus.....	183	154. setphases.....	136
110. nversion.....	38	155. setpitch.....	85
111. p.....	185	156. setpolepairs.....	138
112. pm.....	114	157. setref.....	195
113. pr.....	115	158. setselpos.....	191
114. r.....	121	159. setsp.....	175
115. refmove.....	112	160. setstopdecel.....	47
116. reset.....	34	161. setsw.....	197
117. S.....	153	162. settr.....	228
118. sa.....	122	163. settrdelay.....	220
119. save.....	61	164. settrin.....	212
120. SC.....	154	165. settrinpole.....	215
121. sddump.....	155	166. settrinsize.....	209
122. sdupdate.....	155	167. settroutdelay.....	230
123. sensorreconnect.....	171	168. settroutpol.....	233
124. setaccel.....	122	169. settroutpw.....	234
125. setadaptive.....	162	170. settrpara.....	221
126. setamc.....	129	171. settrwidth.....	236
127. setassignment.....	166	172. setumotgrad.....	140
128. setbaudrate.....	43	173. setumotmin.....	143
129. setbrakefunc.....	131	174. setvardbl.....	69
130. setcloop.....	163	175. setvarint.....	71
131. setclperiod.....	151	176. setvarstring.....	73
132. setclwindow.....	178	177. setvel.....	124
133. setclwintime.....	179	178. sna.....	45
134. setdincmd.....	53	179. snv.....	50
135. setdout.....	56	180. ssd.....	47

181. st.....	188
182. status.....	188
183. sv.....	124
184. v2m.....	121
185. v2r.....	121
186. version.....	26