

# Modula WMS

Think Vertical, Think Modula

## Modula-Link Communication Protocol Technical specifications document

Document version **2.0 REV 1**

Last change 02/07/2021

Owner **Beltrami Thomas**

# Index

<b>Software info</b> .....	4
<b>Introduction</b> .....	4
<b>Description</b> .....	4
<b>Dictionary</b> .....	5
<b>Commands structure</b> .....	5
Request ID .....	6
Prefix .....	6
Wrong commands management .....	6
<b>List of available commands</b> .....	6
PROTOCOL command .....	6
STATUS command .....	7
CALL command .....	9
CALLONEPICK command .....	10
RETURN command .....	16
LASER_ON command .....	17
LASER_OFF command .....	17
LASER_HOME command .....	18
LASER_GO command .....	19
LASER_STATUS command .....	20
DISPLAY_CLEAR command .....	22
DISPLAY_SHOW command .....	22
PTL_SHOW_QTA command .....	23
PTL_SHOW_MESSAGE command .....	24
PTL_CLEAR command .....	25
PTL_CLEAR_ALL command .....	26
PTL_STATUS command .....	27
EXCHANGE command .....	29
LEDBAR_LIGHT command .....	29
LEDBAR_LIGHT_OFF command .....	30
CALL_BIN command .....	31
STATUS_BIN command .....	31
END_BIN command .....	32
DOOR_OPEN command .....	32

DOOR_CLOSE command.....	32
RGB_CLEAR command.....	33
RGB_SHOW command .....	33
EXTRACTION command .....	34
ENDEXTRACTION command .....	35
INSERTION command .....	35
ENDINSERTION command .....	36
<b>Commands and WMS versions .....</b>	<b>37</b>

## Software info

### Current Protocol version: 2.0

#### WMS Licenses

- ☐ BASE
- ☐ PREMIUM ☐ REGISTRY ☐ PICKING ☐ MANUAL WAREHOUSE ☐ RF ☐ IDOC
- ☐ DRIVER ☒ LINK

## Introduction

This document explains protocol implemented by Modula Link software

## Description

*Modula Link is a software that allows a host system to drive a set of Modula (Only LIFT OS MODEL) machines and accessories using a set of commands through a TCP/IP socket channel.*

*Modula Link is the server of the communications: it opens a TCP port (configurable: by default it's port 11000) and starts to listen, waiting for incoming commands; when it receives a valid command from the host system, it manages it and then it answers to the host system*

*Modula Link can be configured to manage commands from a single client (Mono-Client Communication) and from multiple clients (Multi-Client Communication).*

*Mono-Client: WMS accepts only one incoming connection and rejects any other connections by other clients. In front of each command it is processed and provided the answer to the client. The protocol command allows for PREFIX field the value ALL to negotiate the protocol version.*

*Multi-Client: the commands will be queued and processed with FIFO logic. At the end of the processing of a single command will be given the answer to the requesting client. The protocol command must be called for each bay to negotiate the protocol version, the value ALL is not allowed for PREFIX field for concurrency reason.*

*\*\*In case of multiple-clients connected do not exist management restrictions Client <-> Machine so nothing avoid to multiple clients to ask the same command at the same time (i.e. the request of the same tray). In a case like this one the first request that is managed will have correct answer and the following ones (queued) will have an error.*

*Both connections Modula Link ↔ host system and Modula Link ↔ Modula machines are Ethernet connections*

## Dictionary

<i>Machine</i>	<i>A single Modula vertical warehouse</i>
<i>Tray</i>	<i>A single Modula loading unit where goods can be stored</i>
<i>Picking operation</i>	<i>A single physical operation that involves goods stored on a tray</i> <i>Common picking operation types are:</i> <ul style="list-style-type: none"> <li>- <i>Pick</i></li> <li>- <i>Deposit</i></li> <li>- <i>Inventory</i></li> </ul>
<i>Bay</i>	<i>Machine zone where picking operations are performed.</i> <i>Every machine can be provided with up to 3 bay<sup>1</sup>.</i> <i>Bays are numbered as 1, 2 or 3</i>
<i>Position</i>	<i>A single level of a bay where a tray can be moved to.</i> <i>Every bay can be provided with up to 2 positions<sup>2</sup>.</i> <i>Positions are numbered as</i> <ul style="list-style-type: none"> <li>- <i>1 (lower position)</i></li> <li>- <i>2 (upper position)</i></li> </ul>

## Commands structure

*Every command sent by host system or by Modula Link is a pipe – separated string using the form*

---

*1 It depends on machine model/structure*

*2 It depends on machine model/structure*

<PREFIX>|<REQUEST ID>|<COMMAND/ANSWER TYPE>|<PARAMETER 1>|...|<PARAMETER N>

Every message must end with CR (carriage return, 13 ASCII value).

### Request ID

Every message is uniquely identified by a <REQUEST ID>.

Note: the value of <REQUEST ID> could not be greater than 2147483647.

Modula Link answer returns same <REQUEST ID> value passed by command received from the host system (handshaking between the two systems)

### Prefix

<PREFIX> is a string where last character identifies bay number and remaining characters identify machine number. Its main function is to identify uniquely the machine/bay where the command is directed to

Examples:

- 11: machine 1, bay 1
- 52: machine 5, bay 2
- 101: machine 10, bay 1

### Wrong commands management

In case of a wrong command received from the host system, Modula Link answers to host system using one of following special strings

Cause	Message answer sent by Modula Link
Unknown command	BAD_COMMAND
<REQUEST_ID> not present	MISSING_ID
Bad number of parameters	BAD_PARAMETERS
Machine and/or bay not valid	BAD_PREFIX

## List of available commands

### PROTOCOL command

This command is used to set the communication protocol version. Every client can select the working protocol, but If this command is not used the protocol version is the 1.22.

**Host → Modula Link:** <PREFIX>|<REQUEST\_ID>|**PROTOCOL**|<PROTOCOLVERSION>

**Modula Link → Host:** <PREFIX>|<REQUEST\_ID>|**PROTOCOL**|<PROTOCOLVERSION>|<RESULT>

<PREFIX> not used for this command. It is always 0

<REQUEST\_ID> is message ID

< PROTOCOLVERSION> is the version of the protocol to be used to (es. "2.0"). The allowed values are reported in the title of all version of this document. All version before the 2.0 use the same protocol.

< RESULT> is the request response

- "0" = ok, the protocol is valid
- "-1" = Protocol version not supported

Examples

Host → Modula Link	Modula Link → Host
31 3454 PROTOCOL 2.0	31 3454 PROTOCOL 2.0 0
31 3454 PROTOCOL 2.5	31 3454 PROTOCOL 2.5 1

STATUS command

This command is used to know status of a bay (if bay is available or on error, if there is a tray on lower position or on upper position, ...)

**Host → Modula Link:**

<PREFIX>|<REQUEST\_ID>|STATUS

**Modula Link → Host:**

<PREFIX>|<REQUEST\_ID>|STATUS|<STATUS>|<POS1PICKTRAY>|<POS2PICKTRAY>|<POS1EXETRAY>|<POS2EXETRAY>|<ERRORCODE>|<POS1ONEPICKTRAY>|<POS2ONEPICKTRAY>

<PREFIX> is bay/machine identifier

<REQUEST\_ID> is message ID

<STATUS> is bay status

- "0" = bay ready (on-line, automatic mode active and user logged)
- "1" = bay in manual
- "2" = bay not ready (off-line or local)
- "3" = no operator logged in
- "4" = bay engaged

<POS1PICKTRAY> is number of the picking tray on position 1 (lower position). If no tray is on lower position its value is "0"

<POS2PICKTRAY> is number of the picking tray on position 2 (upper position). If no tray is on lower position its value is "0"

<POS1EXETRAY> is number of the execute tray on position 1 (lower position). If no tray is on lower position its value is "0"

<POS2EXETRAY> is number of the execute tray on position 2 (upper position). If no tray is on lower position its value is "0"

<ERRORCODE> is the actual machine error code, 0 means no errors.

<POS1ONEPICKTRAY> is the number of the tray on position 1 engaged by the OnePick gripper, when 0 the gripper has completed his task and the box is available in his final position.

<POS2ONEPICKTRAY> is the number of the tray on position 2 engaged by the OnePick gripper, when 0 the gripper has completed his task and the box is available in his final position. (NOT AVAILABLE FOR NOW)

It's not a real situation having a tray on lower position and another tray on upper position, so at least one of <TRAY1> or <TRAY2> value will be set to "0"

Examples for normal bay

Host → Modula Link	Modula Link → Host
31 3454 STATUS	31 3454 STATUS 0 3021 0 03021 0 0 0
21 123 STATUS	21 123 STATUS 1 0 0 3021 0 0 0
131 98 STATUS	131 98 STATUS 0 0 0 0 0 0 0
52 11123 STATUS	52 11123 STATUS 0 0 5002 0 5002 0 0
52 11123 STATUS	52 11123 STATUS 0 0 5002 0 5002 5002 0
13 23 STATUS	BAD_PREFIX
11 4576 STATUS INFO	BAD_PARAMETERS
22  STATUS	MISSING_ID



### Examples for One Pick bay

Host → Modula Link	Modula Link → Host
31 3454 STATUS	31 3454 STATUS 0 3021 0 03021 0 0 0
21 123 STATUS	21 123 STATUS 1 0 0 3021 0 0 0
131 98 STATUS	131 98 STATUS 0 0 0 0 0 0 0
52 11123 STATUS	52 11123 STATUS 0 0 5002 0 5002 0 0
13 23 STATUS	BAD_PREFIX
11 4576 STATUS INFO	BAD_PARAMETERS
22  STATUS	MISSING_ID

### CALL command

This command is used to move a tray to a specified position of an bay

**Host → Modula Link:** <PREFIX>|<REQUEST\_ID>|**CALL**|<TRAY>|<POSITION>

**Modula Link → Host:** <PREFIX>|<REQUEST\_ID>|**CALL**|<RESULT>

<PREFIX> is bay/machine identifier

<REQUEST\_ID> is message ID

<TRAY> is tray number

<POSITION> is position ("1" = lower position; "2" = upper position) where tray must exit

<RESULT> is result of the request. Possible values are:

- "0" = ok
- "-1" = tray number not valid
- "-2" = position not valid
- "-3" = position is busy
- "-4" = tray is busy

- "-5" = position disable or operator not logged in
- "-6" = machine not in automatic mode

#### Examples

Host → Modula Link	Modula Link → Host
31 8328 CALL 3001 1	31 8328 CALL 0
22 11123 CALL 4007 2	22 11123 CALL -1
62 9088 CALL 6005 4	62 9088 CALL -2
21 3 CALL 1002 1	21 3 CALL -4
20 1123 CALL 1008 1	BAD_PREFIX
11 77 CALL 12	BAD_PARAMETERS
22  CALL	MISSING_ID

#### CALLONEPICK command

This command is used to move a tray to a specified position of an bay and request a task to the OnePick grippers. Only one command per each bay can be sent and managed at the same time: is not possible to enqueue the requests

#### Host → Modula Link:

<PREFIX>|<REQUEST\_ID>|**CALLONEPICK**|<TRAY>|<POSITION>|<POSX\_C>|<POSY\_C>|<POSZ\_C>|<DIMX\_C>|<DIMY\_C>|<DIMZ\_C>|<POSX\_B>|<POSY\_B>|<POSZ\_B>|<POSID\_B>|<TIPOOP>|<GRIP\_VALUE>|<DIMX\_S>|<DIMY\_S>|<DIMZ\_S>|<DIMX\_B>|<DIMY\_B>|<DIMZ\_B>

#### Modula Link → Host:

<PREFIX>|<REQUEST\_ID>|**CALLONEPICK**|<RESULT>

<PREFIX> is bay/machine identifier

<REQUEST\_ID> is message ID

<TRAY> is tray number

<POSITION> is position ("1" = lower position; "2" = upper position) where tray must exit

<POSX\_C> X coordinate of the compartment from the upper left corner in mm (must be greater than zero)

<POSY\_C> Y coordinate of the compartment from the upper left corner in mm (must be greater than zero)

<POSZ\_C> Z coordinate of the compartment from the upper left corner in mm (can be zero)

<DIMX\_C> X dimension of the compartment in mm (must be greater than zero)

<DIMY\_C> Y dimension of the compartment in mm (must be greater than zero)

<DIMZ\_C> Z dimension of the compartment in mm (can be zero)

<POSX\_B> X coordinate of the location in bay from the upper left corner in mm  
(set to zero if the position id is used)

<POSY\_B> Y coordinate of the location in bay from the upper left corner in mm  
(set to zero if the position id is used)

<POSZ\_B> Z coordinate of the location in bay from the upper left corner in mm  
(set to zero if the position id is used)

<POSID\_B> position id in bay (set to zero if the coordinates are used)

<TIPOOP> operation type: "V" = replenishment, "P" = pick up

<GRIP\_VALUE> grip strength value in mm, it indicates the excursion of the grippers to tighten the box

<DIMX\_S> X dimension of the Item in mm (must be greater than zero)

<DIMY\_S> Y dimension of the Item in mm (must be greater than zero)

<DIMZ\_S> Z dimension of the Item in mm (must be greater than zero)



<DIMX\_B> X dimension of the Position Bay in mm (set to zero if the position id is used)

<DIMY\_B> Y dimension of the Position Bay in mm (set to zero if the position id is used)



<DIMZ\_B> Z dimension of the Position Bay in mm (set to zero if the position id is used)

<RESULT> is result of the request. Possible values are:


- "0" = ok
- "-1" = tray number not valid
- "-2" = position not valid
- "-3" = position is busy
- "-4" = tray is busy
- "-5" = position disabled or operator not logged in
- "-6" = one pick gripper is busy
- "-7" = compartment coordinates not valid (for example is less than 0)
- "-8" = compartment dimensions not valid (for example is less than 1)
- "-9" = coordinate of the box in bay not valid (for example is less than 0)
- "-10" = position id in bay not valid (for example is less than 0 or not existing position ID)
- "-11" = grip strength value not valid (for example is less than 0)
- "-12" = box dimension not valid (for example is less than 1)
- "-13" = position dimensions in bay not valid (for example is less than 0)
- "-14" = operation type not valid (is different from "V" or "P")



If  $DIMX\_ITEM = 0$  and  $DIMX\_POSBAY = 0$ :



## Examples



Host → Modula Link	Modula Link → Host
31 8328 CALLONEPICK 3001 1 100 200 0 620 420 0 800 50 0 0 V 8 600 400 73 700 500 0	31 8328 CALLONEPICK 0
31 8329 CALLONEPICK 3002 1 100 200 0 620 420 0 800 50 0 0 V 8 600 400 73 700 500 0	22 8329 CALLONEPICK -6
20 8330 CALLONEPICK 2000 1 100 200 0 620 420 0 800 50 0 0 V 8 600 400 73 700 500	BAD_PREFIX
11 77 CALLONEPICK 12	BAD_PARAMETERS
22   CALLONEPICK	MISSING_ID

## RETURN command

This command is used to move a tray out of a position and return it to its cell inside the machine.

NB: The RETURN command must be called every time that a tray change is needed. To do a call command without sending back the previous tray will cause the call failure.

**Host → Modula Link:** <PREFIX>|<REQUEST\_ID>|**RETURN**|<POSITION>

**Modula Link → Host:** <PREFIX>|<REQUEST\_ID>|**RETURN**|<RESULT>

<PREFIX> is bay/machine identifier

<REQUEST\_ID> is message ID

<POSITION> is position ("1" = lower position; "2" = upper position) from where the tray return to its cell

<RESULT> is result of the request. Possible values are:

- "0" = ok
- "-1" = empty position
- "-2" = position not valid
- "-100" = generic error (see the WMS logs)

## Examples

Host → Modula Link	Modula Link → Host
21 11 RETURN 1	21 11 RETURN 0
91 71217 RETURN 6	91 71217 RETURN -2
62 9 RETURN 2	62 9 RETURN -1
20 2 RETURN 1	BAD_PREFIX
11 666 RETURN	BAD_PARAMETERS
71  RETURN	MISSING_ID



## LASER\_ON command

*This command turns on laser pointer of a specified bay (if any)*

**Host → Modula Link:** <PREFIX>|<REQUEST\_ID>|**LASER\_ON**

**Modula Link → Host:** <PREFIX>|<REQUEST\_ID>|**LASER\_ON**|<RESULT>

<PREFIX> is bay/machine identifier

<REQUEST\_ID> is message ID

<RESULT> is result of the request. Possible values are:

- "0" = ok
- "-1" = laser not available or on error

### Examples

Host → Modula Link	Modula Link → Host
21 11 LASER_ON	21 11 LASER_ON -1
81 71217 LASER_ON	18 71217 LASER_ON 0
M2 2 LASER_ON	BAD_PREFIX
11 666 LASER_ON 1	BAD_PARAMETERS
11  LASER_ON	MISSING_ID

## LASER\_OFF command

*This command turns off laser pointer of a specified bay (if any)*

**Host → Modula Link:** <PREFIX>|<REQUEST\_ID>|**LASER\_OFF**

**Modula Link → Host:** <PREFIX>|<REQUEST\_ID>|**LASER\_OFF**|<RESULT>

<PREFIX> is bay/machine identifier

<REQUEST\_ID> is message ID

<RESULT> is result of the request. Possible values are:

- "0" = ok
- "-1" = laser not available or on error

### Examples

Host → Modula Link	Modula Link → Host
32 11 LASER_OFF	32 11 LASER_OFF 0
21 71217 LASER_OFF	21 71217 LASER_OFF -1
87 34 LASER_OFF	BAD_PREFIX
11 666 LASER_OFF 1 1 1	BAD_PARAMETERS
72  LASER_OFF	MISSING_ID

### LASER\_HOME command

*This command performs a homing of laser pointer of a specified bay and execute a device calibration (if any)*

**Host → Modula Link:** <PREFIX>|<REQUEST\_ID>|**LASER\_HOME**

**Modula Link → Host:** <PREFIX>|<REQUEST\_ID>|**LASER\_HOME**|<RESULT>

<PREFIX> is bay/machine identifier

<REQUEST\_ID> is message ID

<RESULT> is result of the request. Possible values are:

- "0" = ok
- "-1" = laser not available or on error

### Examples

Host → Modula Link	Modula Link → Host
51 1111 LASER_HOME	51 1111 LASER_HOME 0
31 71 LASER_HOME	31 71 LASER_HOME -1
30 1034 LASER_HOME	BAD_PREFIX
11 686 LASER_HOME 24	BAD_PARAMETERS
41  LASER_HOME	MISSING_ID

### LASER\_GO command

*This command moves laser pointer of a specified bay (if any) to a specified point (X, Y)*

**Host → Modula Link:** <PREFIX>|<REQUEST\_ID>|**LASER\_GO**|<POSITION>|<X>|<Y>

**Modula Link → Host:** <PREFIX>|<REQUEST\_ID>|**LASER\_GO**|<RESULT>

<PREFIX> is bay/machine identifier

<REQUEST\_ID> is message ID

<POSITION> is position ("1" = lower position; "2" = upper position) where laser cursor must be focused to

<X> is horizontal coordinate (millimeters)

<Y> is vertical coordinate (millimeters)

<RESULT> is result of the request. Possible values are:

- "0" = ok
- "-1" = laser not available or on error
- "-2" = wrong coordinates (X and/or Y set to wrong values)

### Examples

Host → Modula Link	Modula Link → Host
51 1111 LASER_GO 1 1502 230	51 1111 LASER_GO 0
31 71 LASER_GO 2 0 0	31 71 LASER_GO -1
31 71 LASER_GO 2 9000 -120	31 71 LASER_GO -2
30 1034 LASER_GO 1	BAD_PREFIX
11 686 LASER_GO 24	BAD_PARAMETERS
41  LASER_GO 2 100 100	MISSING_ID

*X and Y coordinates refer to upper/left corner of the tray*

*For example for Model MLD:*

*X=0, Y=0*

*X=4010, Y=0*



*X=0, Y=850*

*X=4010, Y=850*

*If you have configured UDC height the laser doesn't point to the tray bottom but on tray edge*

### LASER\_STATUS command

*This command is used to know status of laser*

**Host → Modula Link:** <PREFIX>|<REQUEST\_ID>|LASER\_STATUS

**Modula Link → Host:** <PREFIX>|<REQUEST\_ID>|LASER\_STATUS|<STATUS>|<POSITION>|<X>|<Y>

<PREFIX> is bay/machine identifier

<REQUEST\_ID> is message ID

<STATUS> Laser Status:

IDLE, (not initialized)

STOP, (stopped)

STOP\_ON, (stopped and light on)

STOP\_OFF, (stopped and light off)

MOVE, (in movement)

ERROR, (in error communication WMS<->Laser or Laser device)

NOT\_CONNECT (laser disconnect)

<POSITION> is position ("0" = no position; "1" = lower position; "2" = upper position) where laser cursor is focused to:

- <X> is horizontal coordinate (millimeters)
- <Y> is vertical coordinate (millimeters)

#### Examples

Host → Modula Link	Modula Link → Host
21 11 LASER_STATUS	21 11 LASER_STATUS IDLE 0 0 0
81 71217 LASER_STATUS	81 71217 LASER_STATUS MOVE 0 0 0
81 71217 LASER_STATUS	81 71217 LASER_STATUS STOP 1 -1000 200
81 71217 LASER_STATUS	81 71217 LASER_STATUS STOP_ON 1 -1000 200
99 71217 LASER_STATUS	BAD_PREFIX
11 666 LASER_STATUS 1	BAD_PARAMETERS
11  LASER_STATUS	MISSING_ID

## DISPLAY\_CLEAR command

*This command clears a specified alphanumeric display of a specified bay (if any)*

**Host → Modula Link:** <PREFIX>|<REQUEST\_ID>|**DISPLAY\_CLEAR**

**Modula Link → Host:** <PREFIX>|<REQUEST\_ID>|**DISPLAY\_CLEAR**|<RESULT>

<PREFIX> is bay/machine identifier

<REQUEST\_ID> is message ID

<RESULT> is result of the request. Possible values are:

- "0" = ok
- "-1" = display not available or error

### Examples

Host → Modula Link	Modula Link → Host
51 1111 DISPLAY_CLEAR	51 1111 DISPLAY_CLEAR 0
31 71 DISPLAY_CLEAR	31 71 DISPLAY_CLEAR -1
30 1034 DISPLAY_CLEAR	BAD_PREFIX
11 686 DISPLAY_CLEAR 0 0 0 0	BAD_PARAMETERS
41  DISPLAY_CLEAR	MISSING_ID

## DISPLAY\_SHOW command

*This command shows a message on an alphanumeric display of a specified bay (if any).*

**Host → Modula Link:** <PREFIX>|<REQUEST\_ID>|**DISPLAY\_SHOW**|<MESSAGE>|<COL>|<ARROW>

**Modula Link → Host:** <PREFIX>|<REQUEST\_ID>|**DISPLAY\_SHOW**|<MESSAGE>|<RESULT>

<PREFIX> is bay/machine identifier

<REQUEST\_ID> is message ID

<MESSAGE> is text message

<COL> is display starting led column

*On display are present 38 columns in 10 cm. So, on a display long 4000 mm (ML machine)  $38 \times 40 = 1520$  columns*

*<ARROW> is a parameter for enabling ("1") or disabling ("0") the display of an arrow*

*<RESULT> is result of the request. Possible values are:*

- "0" = ok
- "-1" = display not available or error

#### Examples

Host → Modula Link	Modula Link → Host
51 1111 DISPLAY_SHOW Hello 300 1	51 1111 DISPLAY_SHOW 0
31 71 DISPLAY_SHOW My message 140 0	31 71 DISPLAY_SHOW -1
30 1034 DISPLAY_SHOW Test 1 1	BAD_PREFIX
11 686 DISPLAY_SHOW Qty = 30	BAD_PARAMETERS
41   DISPLAY_SHOW Bye 400 1	MISSING_ID

#### PTL\_SHOW\_QTA command

*This command shows quantity and relative colour in a Put to Light's display.*

**Host → Modula Link:** <PREFIX>|<REQUEST\_ID>|**PTL\_SHOW\_QTA**|<ID\_DISPLAY>|<QTA>|<COLOR>

**Modula Link → Host:** <PREFIX>|<REQUEST\_ID>|**PTL\_SHOW\_QTA**|<RESULT>

*<PREFIX> in this message is not managed the bay and the machine so always insert '00'*

*<REQUEST\_ID> is message ID*

*<ID\_DISPLAY> display id*

*<QTA> Quantity to be displayed*

*<COLOR> Color (R:Red, O:Orange, G:Green)*

*<RESULT> is result of the request. Possible values are:*

- "0" = ok
- "-1" = PTL not available or error

### Examples

Host → Modula Link	Modula Link → Host
00 1111 PTL_SHOW_QTA 101 10 R	00 1111 PTL_SHOW_QTA 0
00 71 PTL_SHOW_QTA 102 10 Y	00 71 PTL_SHOW_QTA -1
99 1034 PTL_SHO_QTA 102 1 R	BAD_PREFIX
00 686 PTL_SHOW_QTA 102	BAD_PARAMETERS
00  PTL_SHOW_QTA 102 3 R	MISSING_ID

MODULA LINK MANAGE ONLY ONE PUT TO LIGHT GROUP

### PTL\_SHOW\_MESSAGE command

This command shows a message with relative color in a Put to Light's display.

#### Host → Modula Link:

<PREFIX>|<REQUEST\_ID>|**PTL\_SHOW\_MESSAGE**|<ID\_DISPLAY>|<MESSAGE>|<COLOR>

#### Modula Link → Host:

<PREFIX>|<REQUEST\_ID>|**PTL\_SHOW\_MESSAGE**|<RESULT>

<PREFIX> *in this message is not managed the bay and the machine so always insert '00'*

<REQUEST\_ID> is message ID

<ID\_DISPLAY> display id

<MESSAGE> Message to be displayed: for example 'F' (free), 'C' (complete), 'I' (incomplete)

\*(is possible to display only message compatible with a 7-segments display and long 4 chars at most)

<COLOR> Colour (R:Red, O:Orange, G:Green)

<RESULT> is result of the request. Possible values are:

- "0" = ok
- "-1" = PTL not available or error



### Examples

Host → Modula Link	Modula Link → Host
00 1111 PTL_SHOW_MESSAGE 101 F R	00 1111 PTL_SHOW_MESSAGE 0
00 71 PTL_SHOW_MESSAGE 102 F R	00 71 PTL_SHOW_MESSAGE -1
00 1034 PTL_SHO_MESSAG 102  F R	BAD_PREFIX
00 686 PTL_SHOW_MESSAGE	BAD_PARAMETERS
00  PTL_SHOW_MESSAGE 102 F R	MISSING_ID

MODULA LINK MANAGE ONLY ONE PUT TO LIGHT GROUP

### PTL\_CLEAR command

This command clear a Put to Light's display.

**Host → Modula Link:** <PREFIX>|<REQUEST\_ID>|**PLT\_CLEAR**|<ID\_DISPLAY>

**Modula Link → Host:** <PREFIX>|<REQUEST\_ID>|**PTL\_CLEAR**|<RESULT>

<PREFIX> *in this message is not managed the bay and the machine so always insert '00'*

<REQUEST\_ID> is message ID

<ID\_DISPLAY> display id

<RESULT> is result of the request. Possible values are:

- "0" = ok
- "-1" = PTL not available or error

### Examples

Host → Modula Link	Modula Link → Host
00 1111 PTL_CLEAR 101	00 1111 PTL_CLEAR 0
00 71 PTL_CLEAR 201	00 71 PTL_CLEAR -1
99 1034 PTL_CLEAR 201	BAD_PREFIX
00 686 PTL_CLEAR	BAD_PARAMETERS
00  PTL_CLEAR 201	MISSING_ID

MODULA LINK MANAGE ONLY ONE PUT TO LIGHT GROUP

### PTL\_CLEAR\_ALL command

This command clears all Put to Light's displays.

Host → Modula Link : <PREFIX>|<REQUEST\_ID>|**PTL\_CLEAR\_ALL**

Modula Link → Host : <PREFIX>|<REQUEST\_ID>|**PTL\_CLEAR\_ALL**|<RESULT>

<PREFIX> *in this message is not managed the bay and the machine so always insert '00'*

<REQUEST\_ID> is message ID

<RESULT> is result of the request. Possible values are:

- "0" = ok
- "-1" = PTL not available or error

### Examples

Host → Modula Link	Modula Link → Host
00 1111 PTL_CLEAR_ALL	00 1111 PTL_CLEAR_ALL 0
00 71 PTL_CLEAR_ALL	00 71 PTL_CLEAR_ALL -1
99 1034 PTL_CLEAR_ALL	BAD_PREFIX
00 686	BAD_PARAMETERS
00  PTL_CLEAR_ALL	MISSING_ID

MODULA LINK MANAGE ONLY ONE PUT TO LIGHT GROUP

### PTL\_STATUS command

This command is used to know status of a Put to Light's display

**Host → Modula Link:** <PREFIX>|<REQUEST\_ID>|**PTL\_STATUS**

**Modula Link → Host:** <PREFIX>|<REQUEST\_ID>|**PTL\_STATUS**|<STATUS>|<DISPLAY1\_STATUS>;<DISPLAY2\_STATUS>;<DISPLAY3\_STATUS>...

<PREFIX> *in this message is not managed the bay and the machine so always insert '00'*

<REQUEST\_ID> is message ID

<STATUS> Put to Light Status:

- OK (operative),
- KO (on error)

<DISPLAY1\_STATUS>,<DISPLAY2\_STATUS>,<DISPLAY3\_STATUS> status of PTL displays, formed by:

<Id Display>;<ActualStatus>;< ActualMessage >;<Color>;<Operation Confirm>:

- <Id Display> Display id
- <ActualStatus> Display Status (OK, or KO)
- <ActualMessage> Actual Quantity/Message shown on display
- <Color> Actual color shown on display (R:Red, Y:Yellow, G:Green)
- <Operation Confirm> 'true' if the Operator have confirmed the operation

- <Quantity Confirm> Last quantity confirmed

*\*The confirmed data are reset when new data are received or a clear display command is sent*

*\*\* When WMS is turned on the list of displays is empty. When a command message for a display is received if the display exists on the PTL it is added to the list of displays*

#### Examples

Host → Modula Link	Modula Link → Host
00 1111 PTL_STATUS	00 1111 PTL_STATUS KO
00 1112 PTL_STATUS	00 1112 PTL_STATUS OK 101;OK;4;R;true;3 102;OK;10;R; false;0
00 1112 PTL_STATUS	00 1112 PTL_STATUS OK 101;OK;4;R;true;3 102;OK;10;R; false;0
00 1113 PTL_STATUS	00 1113 PTL_STATUS OK 101;OK;C;R;false;0 102;OK;10;R;true;10 103;OK;10;R;false;0
00 1114 PTL_STATUS	00 1114 PTL_STATUS OK 101;OK;C;R;true;0 102;KO;C;R;false;0 103;OK;10;R; true;9
99 1034 PTL_STATUS	BAD_PREFIX
00 686	BAD_PARAMETERS
00  PTL_STATUS	MISSING_ID

MODULA LINK MANAGE ONLY ONE PUT TO LIGHT GROUP

## EXCHANGE command

*This command is used for the Load Unit exchange in the bay specified.*

**Host → Modula Link:** <PREFIX>|<REQUEST\_ID>|**EXCHANGE**

**Modula Link → Host:** <PREFIX>|<REQUEST\_ID>|**EXCHANGE**|<RESULT>

<PREFIX> is bay/machine identifier

<REQUEST\_ID> is message ID

<RESULT> is result of the request. Possible values are:

- "0" = ok
- "-1" = exchange LUs not possible

## Examples

Host → Modula Link	Modula Link → Host
31 8328 EXCHANGE	31 8328 EXCHANGE 0
62 9088 EXCHANGE	62 9088 EXCHANGE -1
20 2 EXCHANGE	BAD_PREFIX
11 666 2 EXCHANGE	BAD_PARAMETERS
71  EXCHANGE	MISSING_ID

## LEDBAR\_LIGHT command

*This command allows to lights on specified led on the simple led bar.*

**Host → Modula Link :** <PREFIX>|<REQUEST\_ID>|**LEDBAR\_LIGHT**|<LED NUMBER X>|

<LED NUMBER Y>|<LED NUMBER ORDER>

**Modula Link → Host :** <PREFIX>|<REQUEST\_ID>|**LEDBAR\_LIGHT**|<RESULT>

<PREFIX> is bay/machine identifier

<REQUEST\_ID> is message ID

<LED NUMBER X> is the led that has to be lighted on\* for horizontal bars (Note: number of available leds depends on machine model; for instance a bar of an ML machine has 400 leds)

<LED NUMBER Y> is the led that has to be lighted on\* for vertical bars (depth indication)

<LED NUMBER ORDER> is the led that has to be lighted on\* for orders bars

<RESULT> is result of the request. Possible values are:

- "0" = ok
- "-1" = generic error

\*passing 0 as led value means turn off all leds of the led bar.

#### Examples

Host → Modula Link	Modula Link → Host
51 1111 LEDBAR_LIGHT 128 0 0	51 1111 LEDBAR_LIGHT 0
31 71 LEDBAR_LIGHT 55 0 0	31 71 LEDBAR_LIGHT -1

#### LEDBAR\_LIGHT\_OFF command

This command allows to light off all led bars.

Host → Modula Link : <PREFIX>|<REQUEST\_ID>|LEDBAR\_LIGHT\_OFF

Modula Link → Host : <PREFIX>|<REQUEST\_ID>|LEDBAR\_LIGHT\_OFF|<RESULT>

<PREFIX> is bay/machine identifier

<REQUEST\_ID> is message ID

<RESULT> is result of the request. Possible values are:

- "0" = ok
- "-1" = generic error

#### Examples

Host → Modula Link	Modula Link → Host
51 1111 LEDBAR_LIGHT_OFF	51 1111 LEDBAR_LIGHT_OFF 0
31 71 LEDBAR_LIGHT_OFF	31 71 LEDBAR_LIGHT_OFF -1

## CALL\_BIN command

Request is to extend Modula Link CALL command functionality in order to giving host system possibility to activate carousel rotation for moving requested bin to exit bay as well as tray call feature already implemented for VLM machines:

**Host → Modula Link:** <POD\_ID>|<DEVICE\_ID>|<REQUEST\_ID>|**CALL\_BIN**|<BIN>

**Modula Link → Host:** <POD\_ID>|<DEVICE\_ID>|<REQUEST\_ID>| **CALL\_BIN** |<RESULT>

<POD\_ID> is the POD ID

<DEVICE\_ID> is the DEVICE\_ID for specific device that belongs to specified POD.

<REQUEST\_ID> is message ID

<BIN> is the bin number

<RESULT> is result of the request. Possible values are:

- "0" = ok
- "-1" = bin number not valid
- "-2" = generic error

## STATUS\_BIN command

Request is to extend Modula Link STATUS command functionality in order to giving host system possibility to get carousel/exit bay current status information:

**Host → Modula Link:** <POD\_ID>|<DEVICE\_ID>|<REQUEST\_ID>|**STATUS\_BIN**

**Modula Link → Host:**

<POD\_ID>|<DEVICE\_ID>|<REQUEST\_ID>|**STATUS\_BIN**|<STATUS>|<BINPICK>|<BINEXE>|<DOORSTATUS>

<POD\_ID> is the POD ID

<DEVICE\_ID> is the DEVICE\_ID for specific device that belongs to specified POD.

<REQUEST\_ID> is message ID

<STATUS> is exit group status:

- "0" = exit group ready (on-line, automatic mode active)
- "1" = exit group in manual
- "2" = exit group off-line

<BINPICK> is number of the bin on the picking/exit position. If no bin is on picking position, its value is "0"

<BINEXE> is number of the bin in execution

<DOORSTATUS> is exit door status used for HC PODs only (optional):

- "0" = door closed
- "1" = door opened
- "2" = door is closing
- "3" = door is opening
- "-1" = door in error

## END\_BIN command

*Request is to give host system possibility to close bin mission and automatically close exit door*

**Host → Modula Link:** <POD\_ID>|<DEVICE\_ID>|<REQUEST\_ID>|**END\_BIN**

**Modula Link → Host:** <POD\_ID>|<DEVICE\_ID>|<REQUEST\_ID>|**END\_BIN**|<RESULT>

<POD\_ID> is the POD ID

<DEVICE\_ID> is the DEVICE\_ID for specific device that belongs to specified POD.

<REQUEST\_ID> is message ID

<RESULT> is result of the request. Possible values are:

- "0" = ok
- "-1" = no bin at exit position
- "-2" = generic error

### **IMPORTANT**

*Door closing is automatic managed by HC machine when END\_BIN command is received*

## DOOR\_OPEN command

*Request is to give host system possibility to open doors of a carousel exit bay*

**Host → Modula Link:** <POD\_ID>|<DEVICE\_ID>|<REQUEST\_ID>|**DOOR\_OPEN**

**Modula Link → Host:** <POD\_ID>|<DEVICE\_ID>|<REQUEST\_ID>|**DOOR\_OPEN**|<RESULT>

<POD\_ID> is the POD ID

<DEVICE\_ID> is the DEVICE\_ID for specific device that belongs to specified POD.

<REQUEST\_ID> is message ID

<RESULT> is result of the request. Possible values are:

- "0" = ok
- "-1" = generic error

### **IMPORTANT**

*When requested bin reaches exit bay position, exit door won't ever open automatically (it's in charge of host system to open it using DOOR\_OPEN command)*

## DOOR\_CLOSE command

*Request is to give host system possibility to close doors of a carousel exit bay*

**Host → Modula Link:** <POD\_ID>|<DEVICE\_ID>|<REQUEST\_ID>|**DOOR\_CLOSE**

**Modula Link → Host:** <POD\_ID>|<DEVICE\_ID>|<REQUEST\_ID>|**DOOR\_CLOSE**|<RESULT>

<POD\_ID> is the POD ID



<DEVICE\_ID> is the DEVICE\_ID for specific device that belongs to specified POD.

<REQUEST\_ID> is message ID

<RESULT> is result of the request. Possible values are:

- "0" = ok
- "-1" = generic error

### **IMPORTANT**

Door closing is also automatic managed by HC machine while bins chain is rotating

RGB\_CLEAR command

Request is to give host system possibility to open doors of a carousel exit bay

**Host → Modula Link:** <POD\_ID>|<DEVICE\_ID>|<REQUEST\_ID>|**RGB\_CLEAR**|<SIDE>

**Modula Link → Host:** <POD\_ID>|<DEVICE\_ID>|<REQUEST\_ID>|**RGB\_CLEAR**|<RESULT>

<POD\_ID> is the POD ID

<DEVICE\_ID> is the DEVICE\_ID for specific device that belongs to specified POD.

<REQUEST\_ID> is message ID

<SIDE> refers to which bar should be cleared. Possible values are:

- "0" = both left/right bars
- "1" = first bar
- "2" = second bar

<RESULT> is result of the request. Possible values are:

- "0" = ok
- "-1" = RGB led bar not available or generic error

RGB\_SHOW command

Request is to give host system possibility to open doors of a carousel exit bay

**Host → Modula Link:**

<POD\_ID>|<DEVICE\_ID>|<REQUEST\_ID>|**RGB\_SHOW**|<COLOR>|<BLINK>|<FIRST\_LED>|<LAST\_LED>|<SIDE>

**Modula Link → Host:** <POD\_ID>|<DEVICE\_ID>|<REQUEST\_ID>| **RGB\_SHOW** |<RESULT>

<POD\_ID> is the POD ID

<DEVICE\_ID> is the DEVICE\_ID for specific device that belongs to specified POD.

<REQUEST\_ID> is message ID

<COLOR> is colour ID

<BLINK> is blinking mode

- "0" = no blink

- "1" = blink
- <COLOR> is color to switch on
- "0" = white
- "1" = yellow
- "2" = magenta
- "3" = red
- "4" = cyan
- "5" = green
- "6" = blue
- "7" = no colour

*<FIRST\_LED> is first led row to switch on*

*<LAST\_LED> is last led row to switch on*

*<SIDE> refers to which bar should be driven. Possible values are:*

- "0" = both left/right bars
- "1" = left bar
- "2" = right bar

*<RESULT> is result of the request. Possible values are:*

- "0" = ok
- "-1" = RGB led bar not available or generic error

## EXTRACTION command

*This command is used to start a tray extraction.*

*This command is strictly connected to trolley management.*

*Conditions:*

*The tray must be available on the exit group/machine provided, so generally this command follows the CALL command.*

*The trolley must be inserted in the exit bay (check trolley presence signal)*

### **Host → Modula Link:**

*<PREFIX>|<REQUEST\_ID>|**EXTRACTION**|<TRAY>|<POSITION>*

### **Modula Link → Host:**

*<PREFIX>|<REQUEST\_ID>|**EXTRACTION**|<RESULT>*

*<PREFIX> is exit group/machine identifier*

*<REQUEST\_ID> is message ID*

*<TRAY> is tray number*

*<POSITION> is position ("1" = lower position; "2" = upper position) where tray must exit*

*<RESULT> is result of the request. Possible values are:*

- "0": ok

- "-1": tray number not valid
- "-2": position not valid
- "-3": position is occupied by different tray
- "-4": position is free (the requested tray is not on exit position)
- "-5": position is disabled
- "-6": user not logged

### ENDEXTRACTION command

*This command is used to complete a tray extraction procedure.*

*This command is strictly connected to trolley management.*

*Conditions:*

*The exit position must be free (not occupied by the tray)*

#### **Host → Modula Link:**

`<PREFIX>|<REQUEST_ID>|ENDEXTRACTION|<TRAY>|<POSITION>`

#### **Modula Link → Host:**

`<PREFIX>|<REQUEST_ID>|ENDEXTRACTION|<RESULT>`

`<PREFIX>` is exit group/machine identifier

`<REQUEST_ID>` is message ID

`<TRAY>` is tray number

`<POSITION>` is position ("1" = lower position; "2" = upper position) where tray must exit

`<RESULT>` is result of the request. Possible values are:

- "0": ok
- "-1": tray number not valid
- "-2": position not valid
- "-3": position is occupied

### INSERTION command

*This command is used to start a tray insertion.*

*This command is strictly connected to trolley management.*

*Conditions:*

- The exit position must be free (not occupied by a tray)
- The trolley must be inserted in the exit bay (check trolley presence signal)

#### **Host → Modula Link:**

`<PREFIX>|<REQUEST_ID>|INSERTION|<TRAY>|<POSITION>`

#### **Modula Link → Host:**

`<PREFIX>|<REQUEST_ID>|INSERTION|<RESULT>`

`<PREFIX>` is exit group/machine identifier

<REQUEST\_ID> is message ID

<TRAY> is tray number

<POSITION> is position ("1" = lower position; "2" = upper position) where tray must exit

<RESULT> is result of the request. Possible values are:

- "0": ok
- "-1": tray number not valid
- "-2": position not valid
- "-3": position is occupied
- "-4": position is disabled

#### ENDINSERTION command

This command is used to complete a tray insertion procedure.

This command is strictly connected to trolley management.

Conditions:

The exit position must be occupied by the inserted tray

#### Host → Modula Link:

<PREFIX>|<REQUEST\_ID>|**ENDINSERTION**|<TRAY>|<POSITION>|<SIDE\_HEIGHT>

#### Modula Link → Host:

<PREFIX>|<REQUEST\_ID>|**ENDINSERTION**|<RESULT>

<PREFIX> is exit group/machine identifier

<REQUEST\_ID> is message ID

<TRAY> is tray number

<POSITION> is position ("1" = lower position; "2" = upper position) where tray must exit

<SIDE\_HEIGHT> is the height in millimeters of the raised part of the drawer

<RESULT> is result of the request. Possible values are:

- "0": ok
- "-1": tray number not valid
- "-2": position not valid
- "-3": position is occupied by different tray
- "-4": position is free (the requested tray is not on exit position)
- "-5": position is disabled

## Commands and WMS versions

Table summarize for each command the WMS version in which they were introduced.

Command	WMS version
STATUS	3.9.8.0
CALL	3.9.8.0
RETURN	3.9.8.0
LASER_ON	3.9.8.0
LASER_OFF	3.9.8.0
LASER_HOME	3.9.8.0
LASER_GO	3.9.8.0
LASER_STATUS	3.9.27.0
DISPLAY_CLEAR	3.9.8.0
DISPLAY_SHOW	3.9.8.0
PTL_SHOW_QTA	3.9.27.0
PTL_SHOW_MESSAGE	3.9.27.0
PTL_CLEAR	3.9.27.0
PTL_CLEAR_ALL	3.9.27.0
PTL_STATUS	3.9.27.0
EXCHANGE	3.10.4
LEDBAR_LIGHT	3.10.4
LEDBAR_LIGHT_OFF	3.10.4
CALL_BIN	3.10.10
STATUS_BIN	3.10.10
END_BIN	3.10.10
DOOR_OPEN	3.10.10

DOOR_CLOSE	3.10.10
RGB_CLEAR	3.10.10
RGB_SHOW	3.10.10
EXTRACTION	3.10.12
ENDEXTRACTION	3.10.12
INSERTION	3.10.12
ENDINSERTION	3.10.12