


5. Valve Body Unit

General


The valve body consists of the upper and lower valve bodies and 7 solenoid valves.



6


229LC161

► No.2 Upper Valve Body ◀




229LC163

► No. 1 Upper Valve Body ◀



229LC162

► Lower Valve Body ◀




229LC164


Solenoid Valve

1) Solenoid Valve S1, S2 and SR

- Solenoid valves S1 and SR use a 3-way solenoid valve.
- Solenoid valve S2 uses a 2-way solenoid valve.
- A filter has been provided at the tip of the solenoid valve to further improve operational reliability.




Solenoid Valve S1 OFF




Solenoid Valve S1 ON

229LC165



Solenoid Valve S2 OFF



Solenoid Valve S2 ON


229LC166

► Function of Solenoid Valve S1, S2 and SR ◀


Solenoid Valve	Type	Function
S1	3-way	Switches the 2-3 shift valve.
S2	2-way	<ul style="list-style-type: none"> • Switches the 1-2 shift valve. • Switches the 3-4 shift valve.
SR	3-way	Switches the clutch apply control valve.

2) Solenoid Valve SL1, SL2, SLT and SLU


- In order to provide a hydraulic pressure that is proportion to current that flows to the solenoid coil, the solenoid valve SL1, SL2, SLT, and SLU linearly controls the line pressure and clutch and brake engagement pressure based on the signals it receives from the engine & ECT ECU.
- The solenoid valves SL1, SL2, SLT, and SLU have the same basic structure.



Solenoid Valve SLT



Solenoid Valve SL1, SL2 and SLT



Solenoid Valve SLU

229LC181

► Function of Solenoid Valve SL1, SL2, SLT and SLU ◀

Solenoid Valve	Function
SL1	<ul style="list-style-type: none"> • C₁ clutch pressure control • Accumulator back pressure control
SL2	B ₁ , B ₂ and B ₄ clutch pressure control
SLT	<ul style="list-style-type: none"> • Line pressure control • Accumulator back pressure control
SLU	<ul style="list-style-type: none"> • Lock-up clutch pressure control • Accumulator back pressure control