

<b>DTC</b>	<b>C1252 / 52</b>	<b>Hydraulic brake booster Pump Motor ON Time Abnormally Long</b>
------------	-------------------	---


## CIRCUIT DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
C1252 / 52	After the ignition switch has been turned ON, when the power is supplied to the pump motor for more than 5 minutes.	<ul style="list-style-type: none"> <li>Hydraulic brake booster pump motor</li> <li>Hydraulic brake booster pump motor circuit</li> <li>Pressure switch (PH or PL)</li> </ul>

Fail safe function:


If trouble occurs in the pump motor, the ECU cuts off current to the ABS solenoid relay and prohibits ABS & TRC & VSC controls and the brake system becomes normal.

## WIRING DIAGRAM



F03312

RHD




(\*1) : Australia

(\*2) : Europe

F03313

## INSPECTION PROCEDURE

## 1 Check operation of hydraulic brake booster pump motor.

**PREPARATION:**

Disconnect the 2 connectors from hydraulic brake booster connector.

**CHECK:**

Connect positive  $\oplus$  lead to BM1 or BM2 terminal and negative  $\ominus$  lead to GND1 or GND2 terminal of the hydraulic brake booster (pump motor) connector.

**OK:**


The operation sound of the pump motor should be heard.

OK

Go to step 3.

NG

## 2 Check continuity between GND terminal of hydraulic brake booster (pump motor) connector and body ground.

**CHECK:**

Check continuity between GND1 or GND2 terminal of hydraulic brake booster (pump motor) connector and body ground.

**OK:**

Continuity

NG

Repair or replace harness or connector.

OK

Replace hydraulic brake booster pump motor.

3	Check for short circuit in harness and connector between hydraulic brake booster (pump motor) and ABS & TRC & VSC ECU (See page N-29).
---	--

NG

Repair or replace harness or connector.

OK

4	Check for short circuit (to B+) in harness and connector between MTT of hydraulic brake booster and ABS & TRC & VSC ECU ( See page).
---	--

OK

Check and replace ABS & TRC & VSC ECU.

NG

**5 Check pressure switch (PH).**

**In case of using the hand-held tester.**

**PREPARATION:**

- Connect the hand-held tester to the DLC3.
- Turn the ignition switch ON and push the hand-held tester main switch ON.
- Select the DATALIST mode on the hand-held tester.

**CHECK:**

Depress the brake pedal more than 40 times with the ignition switch OFF then turn the ignition switch ON and check the pressure switch (PH) condition.

**OK:**


"OFF" turns to "ON".

HINT:

OFF: Low pressure

ON: High pressure

**In case of not using the hand-held tester.**

**PREPARATION:**

- Disconnect the connector from the hydraulic brake booster.
- With ignition switch OFF, depress the brake pedal more than 40 times to decrease the accumulator pressure.

**CHECK:**

Measure resistance between terminals PH and PHG of hydraulic brake booster connector.

**OK:**

**Resistance: 1.0 k $\Omega$**

**PREPARATION:**

- Connect the connector to the hydraulic brake booster.
- Disconnect the connector after ignition switch has been ON and the pump motor has stopped.

**CHECK:**

Measure resistance between terminals PH and PHG of hydraulic brake booster connector.

**OK:**

**Resistance: 0  $\Omega$**

HINT:


After inspection, clear the DTC (See page DI-210).

**NG**

**Replace hydraulic brake booster.**

**OK**

## 6 Check pressure switch (PL).



### PREPARATION:

- Disconnect the connector from the hydraulic brake booster.
- With ignition switch OFF, depress the brake pedal more than 40 times to decrease the accumulator pressure.

### CHECK:

Measure resistance between terminals PL and PLG of hydraulic brake booster connector.

### OK:

**Resistance: 5.7 kΩ**

### PREPARATION:

- Connect the connector to the hydraulic brake booster.
- Disconnect the connector after ignition switch has been ON and the pump motor has been stopped.

### CHECK:

Measure resistance between terminals PL and PLG of hydraulic brake booster connector.

### OK:

**Resistance: 1.0 kΩ**

### HINT:

After inspection, clear the DTC (See page DI-210).

NG

Replace hydraulic brake booster.


OK

## 7 Check for open and short circuit in harness and connector between pressure switch and ABS & TRC & VSC ECU (See page IN-29).

NG

Repair or replace harness or connector.

OK

**8 Check ABS and TRC motor relay.****PREPARATION:**

Remove ABS and TRC motor relay from Engine Room R/B No.2.

**CHECK:**

Check continuity between each pair of terminal of motor relay.

**OK:**

Terminals 3 and 4	Continuity (Reference value <sup>*1</sup> )
Terminals 1 and 2	Open

\*1: ABS motor relay 62Ω

TRC motor relay 54Ω

**CHECK:**

(a) Apply battery voltage between terminals 3 and 4.

(b) Check continuity between terminals.

**OK:**

Terminals 1 and 2	Continuity
-------------------	------------

**NG****Replace ABS or TRC motor relay.****OK****9 Check for short circuit in harness and connector between ABS or TRC motor relay and ABS & TRC & VSC ECU (See page IN-29).****NG****Repair or replace harness or connector.****OK****Check and replace ABS & TRC & VSC ECU.**