

PROBLEM SYMPTOMS TABLE

• POWER WINDOW CONTROL SYSTEM

Symptom	Suspect Area	See page
All the power windows does not operate.	1. PWS circuit 2. Power window master switch circuit 3. Body No.1 ECU	DI-654 DI-710
Power window does not operate.	1. Power window switch circuit 2. Power window motor circuit 3. Driver door ECU	DI-710 DI-720
Auto up (or down) function does not operate.	1. Power window master switch circuit 2. Driver door ECU	DI-710
Jam protection function and auto up (or down) function does not operate.	1. Jam protection limit switch circuit 2. Jam protection pulse switch circuit 2. Driver door ECU	DI-722 DI-724

• POWER MIRROR CONTROL SYSTEM

Symptom	Suspect Area	See page
Both right and left mirror does not operate.	1. Mirror switch circuit 2. Body No.2 ECU	DI-673
Only one side of mirror does not operate.	1. Mirror motor circuit 2. Driver door ECU	DI-726
Mirror on the opposite side will be operated.	1. Mirror switch circuit	DI-673
Mirror will not be operated as indicated with switch.	2. Body No.2 ECU	

• OTHERS

Symptom	Suspect Area	See page
Parts of the door does not function.	1. Power source circuit 2. Driver door ECU	DI-707