













AUTOMATIC TRANSMISSION

SST (Special Service Tools)

PP0N4-05

	09032-00100 Oil Pan Seal Cutter	Oil pan
	09308-00010 Oil Seal Puller	Extension housing rear oil seal
	09309-37010 Transmission Bearing Replacer	Extension housing rear oil seal
	09350-30020 TOYOTA Automatic Transmission Tool Set	
	(09351-32020) Stator Stopper	
	09950-60010 Replacer Set	
	(09951-00350) Replacer 35	
	09950-70010 Handle Set	
	(09951-07100) Handle 100	
	09992-00095 Automatic Transmission Oil Pressure Gauge Set	
	(09992-00231) Adaptor C	
	(09992-00271) Gauge Assy	