

## 10. Sound of radio, cassette tape or CD only cannot be heard from speaker.

### INSPECTION PROCEDURE

1	Check the radio receiver assembly.
---	------------------------------------

#### PREPARATION:

Disconnect the radio receiver assembly connector.

#### CHECK:

Check voltage terminals +B.

#### OK:

+B: 10 – 14 V

#### CHECK:

Check voltage terminal ACC when turn ignition switch ACC or ON position.

#### OK:

ACC: 10 – 14 V

#### CHECK:

Check continuity terminal GND.

#### OK:

GND: Continuity

NG

Replace or repair wire harness or connector.

OK

Replace the radio receiver assembly.