

## CIRCUIT INSPECTION


<b>DTC</b>	<b>B1412/12</b>	<b>Ambient Temperature Sensor Circuit</b>
------------	-----------------	---

## CIRCUIT DESCRIPTION

This sensor detects the ambient temperature and sends the appropriate signals to the A/C control assembly.

DTC No.	Detection Item	Trouble Area
B1412/12	Open or short in ambient temperature sensor circuit.	<ul style="list-style-type: none"> <li>• Ambient temperature sensor.</li> <li>• Harness or connector between ambient temperature sensor and engine and ECT ECU</li> <li>• Harness or connector between engine and ECT ECU and A/C control assembly</li> <li>• Harness or connector between engine and airbag sensor assembly.</li> <li>• Harness or connector between airbag sensor assembly and A/C control assembly</li> <li>• Engine and ECT ECU</li> <li>• A/C control assembly</li> </ul>

## WIRING DIAGRAM



## INSPECTION PROCEDURE

### HINT:

In case of using the hard-held tester, start the inspection step 1 and in case of not using the hard-held tester, start from step 2.

### 1 Check ambient temp. sensor using hard-held tester.

#### PREPARATION:

Connect the hard-held tester to the DLC3.

#### CHECK:


Check the ambient temp. sensor using DATA LIST.

OK

Check and replace A/C control assembly.

NG

### 2 Check voltage between terminals TAM and ETAM of engine and ECT ECU.



#### PREPARATION:

Remove engine and ECT ECU with connectors still connected.

#### CHECK:

- Turn ignition switch ON.
- Measure voltage between terminals TAM and ETAM of engine and ECU ECU connector at each temperature.

#### OK:

Voltage :

at 25°C (77°F) : 1.35 – 1.75 V

at 40°C (104°F) : 0.85 – 1.25 V

#### HINT:


As the temperature increases, the voltage decreases.

NG

Go to step 3.

OK

Proceed to next circuit inspection shown on problem symptoms table (See page DI-930). However, if DTC B1412/12 is displayed, check and replace engine and ECT ECU and A/C control assembly.

**3 Check ambient temperature sensor.****PREPARATION:**

Disconnect ambient temperature sensor connector.

**CHECK:**

Measure resistance between terminals 1 and 2 of ambient temperature sensor connector at each temperature.

**OK:****Resistance :**

at 25°C (77°F) : 1.6 – 1.8 kΩ

at 50°C (122°F) : 0.5 – 0.7 kΩ

**HINT:**

As the temperature increases, the resistance decreases.

**NOTICE:**

**When installing the ambient temperature sensor, be sure to connect the sensor connector before connecting the battery.**

**NG****Replace ambient temperature sensor.****OK****4 Check harness and connector between engine and ECT ECU and ambient temperature sensor (See page IN-30).****NG****Repair or replace harness or connector.****OK**

- |          |  |
|----------|--|
| <b>5</b> | <b>Check harness and connector between engine and ECT ECU and A/C control assembly (See page IN-30).</b> |
|----------|--|

**NG**

**Repair or replace harness or connector.**

**OK**

**Check and replace engine and ECT ECU and A/C control assembly.**