

## SERVICE HINTS

### TURN SIGNAL FLASHER

- 4-GROUND : Always approx. **12** volts
- 1-GROUND : Approx. **12** volts with ignition SW at **ON** or **ST** position
- 7-GROUND : Always continuity

## : PARTS LOCATION

Code		See Page	Code	See Page	Code	See Page
B5		86 (RHD)	F5	82 (RHD)	J35	88 (RHD)
C11		86 (RHD)	F6	82 (RHD)	J37	88 (RHD)
C13	A	86 (RHD)	H20	86 (RHD)	J42	88 (RHD)
	B	86 (RHD)	J29	84 (RHD)	J44	90 (RHD)
F3		82 (RHD)	J32	88 (RHD)	R10	92 (RHD)
F4		82 (RHD)	J34	88 (RHD)	R12	92 (RHD)

## : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	54 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)
5	57 (RHD)	Driver Side R/B (Right Kick Panel)

## : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	58 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)
1C	58 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1D		
1F	58 (RHD)	Cowl Wire and Driver Side J/B (Right Kick Panel)
1G	59 (RHD)	
1H		
2E	60 (RHD)	Floor No.2 Wire and Passenger Side J/B (Left Kick Panel)
2H	61 (RHD)	Cowl Wire and Passenger Side J/B (Left Kick Panel)
3A	62	Instrument Panel Wire and Instrument Panel J/B (Instrument Panel Reinforcement Center)
3C		

## : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA1	108 (RHD)	Engine Room Main Wire and Cowl Wire (Near the Passenger Side R/B)
IC2	108 (RHD)	Floor No.2 Wire and Cowl Wire (Left Kick Panel)
ID3	108 (RHD)	Instrument Panel Wire and Cowl Wire (Right Side of the Blower Unit)
IJ2	110 (RHD)	Instrument Panel Wire and Cowl Wire (Right Side of the Steering Column)

## : GROUND POINTS

Code	See Page	Ground Points Location
EB	106 (RHD)	Left Fender
EE	106 (RHD)	Under the ABS & TRC & VSC Actuator
IF	108 (RHD)	Left Kick Panel
IG	108 (RHD)	Behind the Combination Meter
II	108 (RHD)	Cowl Side Panel RH
BK	112 (RHD)	Quarter Panel LH

## : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E4	106 (RHD)	Cowl Wire	B4	112 (RHD)	Floor No.2 Wire

TURN SIGNAL AND HAZARD WARNING LIGHT (RHD)

