


VSC Buzzer Circuit

CIRCUIT DESCRIPTION

The VSC buzzer sounds during VSC operation.

WIRING DIAGRAM



INSPECTION PROCEDURE

Start the inspection from step 1 in case of using the hand-held tester and start from step 2 in case of not using the hand-held tester.

1	Check operation of the VSC buzzer.
---	------------------------------------

PREPARATION:

- (a) Connect the hand-held tester to the DLC3.
- (b) Turn the ignition switch ON and push the hand-held tester main switch ON.
- (c) Select the ACTIVE TEST mode on the hand-held tester.


CHECK:

Check that VSC buzzer sounds "ON" and "OFF" with the hand-held tester.

OK

Check and replace ABS & TRC & VSC ECU.

NG

2 Check VSC buzzer.**PREPARATION:**

Disconnect the VSC buzzer connector.

CHECK:

Apply battery voltage to the terminals 1 and 2 of VSC buzzer connector, check that the VSC buzzer sounds.

NG**Replace VSC buzzer.****OK****3 Check for open and short circuit in harness and connector between ABS & TRC & VSC ECU and VSC buzzer (See page N-29).****NG****Repair or replace harness or connector.****OK****Check and replace ABS & TRC & VSC ECU.**