



INSPECTION

INSPECT WATER PUMP

Turn the pulley seat, and check that the water pump bearing is not rough or noisy.

If necessary, replace the water pump.