

# STOP LIGHT

## SYSTEM OUTLINE

The current always flows from the **STOP** fuse into **TERMINAL 2** of the stop light SW. If the brake pedal is depressed, the stop lights light up.

### STOP LIGHT DISCONNECTION WARNING

If any stop light wiring is faulty when the brake pedal is depressed with the ignition SW set at ON, the light failure sensor detects a voltage difference and inputs the signal to **TERMINAL 4** of the body ECU No.2. The body ECU No.2 controls the combination meter through the communication to turn on the rear light warning light to warn the driver. The warning light is remained lit until the ignition SW is turned to the **OFF** position.

## SERVICE HINTS

### S12 STOP LIGHT SW

1-2 : Closed with brake pedal depressed

### L4 LIGHT FAILURE SENSOR

9, 10-GROUND : Approx. **12** volts with stop light SW on

8-GROUND : Approx. **12** volts with Ignition SW at **ON** or **ST** position

11-GROUND : Always continuity

## : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
B6	72 (LHD)	J8	74 (LHD)	L4	78 (LHD)
	86 (RHD)	J18	74 (LHD)		90 (RHD)
C11	A	J20	78 (LHD)	R9	78 (LHD)
		J21	78 (LHD)	R10	78 (LHD)
C12	B	J32	88 (RHD)		92 (RHD)
		J35	88 (RHD)	R11	78 (LHD)
H25		J37	88 (RHD)	R12	78 (LHD)
		J39	88 (RHD)		92 (RHD)
H26		J42	88 (RHD)	S12	74 (LHD)
		J43	90 (RHD)		88 (RHD)
J7	74 (LHD)	J44	90 (RHD)		

## : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1D	58 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
	58 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1F	58 (LHD)	Cowl Wire and Driver Side J/B (Left Kick Panel)
	58 (RHD)	Cowl Wire and Driver Side J/B (Right Kick Panel)
1G	59 (LHD)	Cowl Wire and Driver Side J/B (Left Kick Panel)
	59 (RHD)	Cowl Wire and Driver Side J/B (Right Kick Panel)
1H	59 (LHD)	Cowl Wire and Driver Side J/B (Left Kick Panel)
	59 (RHD)	Cowl Wire and Driver Side J/B (Right Kick Panel)

## : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC1	98 (LHD)	Floor No.2 Wire and Cowl Wire (Left Kick Panel)
	108 (RHD)	
IC3	98 (LHD)	
	108 (RHD)	
IE1	98 (LHD)	
IJ1	110 (RHD)	Instrument Panel Wire and Cowl Wire (Right Side of the Steering Column)
IJ2	100 (LHD)	Instrument Panel Wire and Cowl Wire (Left Side of the Blower Unit)
	110 (RHD)	Instrument Panel Wire and Cowl Wire (Right Side of the Steering Column)


**: GROUND POINTS**

Code	See Page	Ground Points Location
IF	98 (LHD)	Left Kick Panel
	108 (RHD)	
II	98 (LHD)	Right Side of the Cowl Panel
	108 (RHD)	Cowl Side Panel RH
BK	102 (LHD)	Quarter Panel LH
	112 (RHD)	


**: SPLICE POINTS**

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
B4	102 (LHD)	Floor No.2 Wire	B5	102 (LHD)	Floor No.2 Wire
	112 (RHD)			112 (RHD)	


(LHD) B6




(RHD) B6



C11 (A)




C12 (B)




H25



H26




J7 GRAY



(Hint : See Page 7, 23, 39)

J8




(Hint : See Page 7, 23, 39)

J18




(Hint : See Page 7, 23, 39)

J20 BLUE




(Hint : See Page 7, 23, 39)

J21




(Hint : See Page 7, 23, 39)

J32



(Hint : See Page 7, 23, 39)

J35




(Hint : See Page 7, 23, 39)

J37




(Hint : See Page 7, 23, 39)

J39




(Hint : See Page 7, 23, 39)

J42




(Hint : See Page 7, 23, 39)

J43 BLUE




(Hint : See Page 7, 23, 39)

J44



(Hint : See Page 7, 23, 39)


L4



(G.C.C.) R9




R10



(G.C.C.) R11



R12



S12 BLUE

