



INSTALLATION

1. PLACE THERMOSTAT IN WATER INLET

- (a) Install a new gasket to the thermostat.
- (b) Align the jiggle valve of the thermostat with the protrusion of the water inlet.

2. INSTALL WATER INLET

Install the water inlet with the 2 nuts.

Torque: 9.0 N·m (90 kgf·cm, 80 in·lbf)

3. FILL WITH ENGINE COOLANT

4. START ENGINE AND CHECK FOR COOLANT LEAKS