

## INSTALLATION

Installation is in the reverse order of removal (See page BR-58).

AFTER INSTALLATION, CHECK SPEED SENSOR SIGNAL (See page DI-210)