

SYSTEM OUTLINE

With the ignition SW turned on, the current flows to **TERMINAL 17** of the front wiper and washer SW, and **TERMINAL 2** of the front wiper motor through the **WIPER** fuse, **TERMINAL 2** of washer motor through the **WASHER** fuse.

1. LOW SPEED POSITION

With wiper SW turned to **LO** position, the current flows from **TERMINAL 17** of the front wiper and washer SW to **TERMINAL 7** to **TERMINAL 5** of the front wiper motor to **TERMINAL 4** to **GROUND** and causes the front wiper motor to run at low speed.

2. HIGH SPEED POSITION

With wiper SW turned to **HI** position, the current flows from **TERMINAL 17** of the front wiper and washer SW to **TERMINAL 8** to **TERMINAL 3** of the front wiper motor to **TERMINAL 4** to **GROUND** and causes the front wiper motor to run at high speed.

3. INT POSITION

With wiper SW turned to **INT** position, the relay operates and the current which is connected by relay function flows from **TERMINAL 17** of the front wiper and washer SW to **TERMINAL 2** to **GROUND**. This flow of current operates the intermittent circuit and the current flows from **TERMINAL 17** of the front wiper and washer SW to **TERMINAL 7** to **TERMINAL 5** of the front wiper motor to **TERMINAL 4** to **GROUND** and operates the wiper.

The intermittent operation is controlled by the charge/discharge function of the condenser installed in the relay, and the intermittent time is controlled by a time control SW to change the charging time of the condenser.

4. MIST POSITION

With wiper SW turn **MIST** position, the current flows from **TERMINAL 17** of the front wiper and washer SW to **TERMINAL 7** to **TERMINAL 5** of the wiper motor to **TERMINAL 4** to **GROUND** and causes the wiper motor to run at low speed.

5. WASHER CONTINUOUS OPERATION

With washer SW turned to on, the current flows from **TERMINAL 2** of the washer motor to **TERMINAL 1** to **TERMINAL 11** of the front wiper and washer SW to **TERMINAL 2** to **GROUND** and causes to the washer motor to run, and the window washer emits a water spray. This causes the current to flow to washer continuous operation circuit in **TERMINAL 17** of the front wiper and washer SW to **TERMINAL 7** to **TERMINAL 5** of the front wiper motor to **TERMINAL 4** to **GROUND** and operates the wiper.

SERVICE HINTS

C16 (A), (B) FRONT WIPER AND WASHER SW [COMB. SW]

(A) 2, (B) 8-GROUND : Always continuity

(A)17, (B) 11-GROUND : Approx. **12** volts with the ignition SW at **ON** or **ST** position

(A) 7, (B) 3-GROUND : Approx. **12** volts with the front wiper and washer SW at **LO** position

Approx. **12** volts **2** to **12** seconds intermittently with the front wiper and washer SW at **INT** position

(A)16, (B) 12-GROUND : Approx. **12** volts with the ignition SW on unless the front wiper motor at **STOP** position

(A) 8, (B) 2-GROUND : Approx. **12** volts with the front wiper and washer SW at **HI** position

F7 (A), (B) FRONT WIPER MOTOR

(A) 2-(A) 1, (B) 2-(B) 3 : Closed unless the wiper motor at **STOP** position

○ : PARTS LOCATION

| Code | | See Page | Code | | See Page | Code | See Page |
|------|---|----------|------|----------|----------|----------|----------|
| C11 | A | 72 (LHD) | F7 | A | 68 (LHD) | J42 | 88 (RHD) |
| | | 86 (RHD) | | B | 82 (RHD) | W1 | 70 (LHD) |
| C12 | B | 72 (LHD) | J8 | 74 (LHD) | W2 | | 84 (RHD) |
| | | 86 (RHD) | J10 | 74 (LHD) | | 70 (LHD) | |
| C16 | A | 72 (LHD) | J12 | 74 (LHD) | | 84 (RHD) | |
| | | 86 (RHD) | J29 | 84 (RHD) | | | |
| | B | 86 (RHD) | J35 | 88 (RHD) | | | |

WIPER AND WASHER



: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

| Code | See Page | Junction Block and Wire Harness (Connector Location) |
|------|----------|--|
| 1B | 58 (LHD) | Cowl Wire and Driver Side J/B (Left Kick Panel) |
| | 58 (RHD) | Engine Room Main Wire and Driver Side J/B (Right Kick Panel) |
| 1D | 58 (LHD) | Instrument Panel Wire and Driver Side J/B (Left Kick Panel) |
| | 58 (RHD) | Instrument Panel Wire and Driver Side J/B (Right Kick Panel) |
| 1F | 58 (LHD) | Cowl Wire and Driver Side J/B (Left Kick Panel) |
| | 58 (RHD) | Cowl Wire and Driver Side J/B (Right Kick Panel) |






: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

| Code | See Page | Joining Wire Harness and Wire Harness (Connector Location) |
|------|-----------|---|
| ID1 | 98 (LHD) | Cowl Wire and Cowl Wire (Left Side of the Instrument Panel Reinforcement) |
| IE1 | 98 (LHD) | Instrument Panel Wire and Cowl Wire (Left Side of the Steering Column) |
| II1 | 110 (RHD) | Engine Room Main Wire and Cowl Wire (Near the Passenger Side R/B) |
| IJ1 | 110 (RHD) | Instrument Panel Wire and Cowl Wire (Left Side of the Blower Unit) |
| IK1 | 110 (RHD) | Front Door RH Wire and Cowl Wire (Right Kick Panel) |




: GROUND POINTS

| Code | See Page | Ground Points Location |
|------|-----------|------------------------------------|
| EB | 96 (LHD) | Left Fender |
| | 106 (RHD) | |
| EE | 106 (RHD) | Under the ABS & TRC & VSC Actuator |
| IF | 98 (LHD) | Left Kick Panel |
| II | 108 (RHD) | Cowl Side Panel RH |



(Australia) C16 (B) BLACK




(LHD) F7 (A) GRAY



(RHD) F7 (B) BLACK




J8




(Hint : See Page 7, 23, 39)

J10 ORANGE



(Hint : See Page 7, 23, 39)

J12 GRAY




(Hint : See Page 7, 23, 39)

J29 BLUE




(Hint : See Page 7, 23, 39)

J35




(Hint : See Page 7, 23, 39)

J42



(Hint : See Page 7, 23, 39)

W1 BLACK



W2 BLACK

