

# BODY

## INSPECTION

MA027-05

### 1. TIGHTEN BOLTS AND NUTS ON CHASSIS AND BODY

(a) Where necessary, tighten all parts of the chassis.

- Front axle and suspension
- Driven train
- Rear axle and suspension
- Steering system
- Brake system
- Engine mounting etc.

(b) Where necessary, tighten all parts of the body.

- Seat belt system
- Seats
- Doors and hood
- Body mountings
- Fuel tank
- Exhaust pipe system etc.

### 2. CHECK TIRES AND INFLATION PRESSURE

(a) Check tires for abnormal abrasion or cracks.

(b) Check and adjust the tires inflation pressure.

**Cold tire inflation pressure:**

**2JZ-GE: (See Pub. No. RM588E)**

**3UZ-FE: (See Pub. No. RM786E)**

### 3. CHECK LIGHTS, HORNS, WIPERS AND WASHERS

Check the function of lights, horns, wipers and washers.

#### 4. Australia and New Zealand:

**REPLACE AIR REFINER FILTER (See Pub. No. RM588E)**

#### 5. New Zealand and General:

**CHECK AIR CONDITIONER REFRIGERANT AMOUNT (See Pub. No. RM588E)**

### 6. ROAD TEST

- (a) Check the engine and chassis for abnormal noises.
- (b) Check that the vehicle does not wander or pull to one side.
- (c) Check that the brakes work properly and do not drag.
- (d) Do setting of the parking brake shoes and drum.

### 7. FINAL INSPECTION

(a) Check the operation of the body parts:

- Hood
  - Auxiliary catch operates properly
  - Hood locks securely when closed
- Front and rear doors
  - Door locks operate properly
  - Doors close properly
- Luggage compartment door
  - Door lock operates properly
- Seat adjusts easily and locks securely in any position
  - Front seat back locks securely in any position

- (b) Be sure to deliver a clean car. Especially check:
- Steering wheel
  - Shift lever knob
  - All switch knobs
  - Seats