

## INSPECTION

1. **INSPECT SOLAR SENSOR CIRCUIT**  
Driver Side: (See page DI-935)  
Passenger Side: (See page DI-926)
2. **INSPECT ROOM TEMPERATURE SENSOR CIRCUIT**  
(See page DI-914)
3. **INSPECT AMBIENT TEMPERATURE SENSOR CIRCUIT**  
(See page DI-917)
4. **INSPECT EVAPORATOR TEMPERATURE SENSOR**  
(See page DI-920)
5. **INSPECT SMOG VENTILATION SENSOR CIRCUIT**  
(See page DI-923)