


| | | |
|-----|----------|----------------------------------|
| DTC | B0110/43 | Short in Side Squib (RH) Circuit |
|-----|----------|----------------------------------|

CIRCUIT DESCRIPTION

The side squib (RH) circuit consists of the airbag sensor assembly and side airbag assembly (RH). It causes the SRS to deploy when the SRS deployment conditions are satisfied. For details of the function of each component, see OPERATION on [page RS-2](#). DTC B0110/43 is recorded when a short is detected in the side squib (RH) circuit.

| DTC No. | DTC Detecting Condition | Trouble Area |
|----------|---|---|
| B0110/43 | <ul style="list-style-type: none">• Short circuit between SFR+ wire harness and SFR- wire harness of squib• Side squib (RH) malfunction• Airbag sensor assembly malfunction | <ul style="list-style-type: none">• Side airbag assembly (RH)• Airbag sensor assembly• Wire harness |


WIRING DIAGRAM



INSPECTION PROCEDURE

1 Prepare for inspection. (See step 1 on page DI-503)

2 Check side squib (RH) circuit.

**PREPARATION:**

Release airbag activation prevention mechanism of the connector (on the airbag sensor assembly side) between the airbag sensor assembly and side airbag assembly (RH).

(See page DI-386)

CHECK:

For the connector (on the airbag sensor assembly side) between the side airbag assembly (RH) and airbag sensor assembly, measure the resistance between SFR+ and SFR-.

OK:


Resistance: 1 MΩ or Higher

NG

Repair or replace harness or connector between side airbag assembly (RH) and airbag sensor assembly.

OK

3 Check airbag sensor assembly.



PREPARATION:

- Connect the connector to the airbag sensor assembly.
- Connect negative (-) terminal cable to the battery, and wait at least for 2 seconds.
- Using a service wire, connect SFR+ and SFR- of the connector (on the side airbag assembly side) between the airbag sensor assembly and side airbag assembly (RH).

CHECK:

- Turn ignition switch to ACC or ON and wait at least for 20 seconds.
- Clear DTC stored in memory.
(See page DI-386)
- Turn ignition switch to LOCK, and wait at least for 20 seconds.
- Turn ignition switch to ACC or ON, and wait at least for 20 seconds.
- Check DTC.
(See page DI-386)

OK:

DTC B0110/43 is not output.

HINT:


Codes other than DTC B0110/43 may be output at this time, but they are not relevant to this check.

NG

Replace airbag sensor assembly.

OK

4 Check side squib (RH).



PREPARATION:

- Turn ignition switch to LOCK.
- Disconnect negative (-) terminal cable from the battery, and wait at least for 90 seconds.
- Connect the side airbag assembly (RH) connector.
- Connect negative (-) terminal cable to the battery, and wait at least for 2 seconds.

CHECK:

- Turn ignition switch to LOCK, and wait at least for 20 seconds.
- Turn ignition switch to ACC or ON, and wait at least for 20 seconds.
- Clear DTC stored in memory.
(See page DI-386)
- Turn ignition switch to LOCK, and wait at least for 20 seconds.
- Turn ignition switch to ACC or ON, and wait at least for 20 seconds.
- Check DTC.
(See page DI-386)

OK:

DTC B0110/43 is not output.

HINT:

Codes other than DTC B0110/43 may be output at this time, but they are not relevant to this check.

NG

Replace side airbag assembly (RH).

OK

From the results of the above inspection, the malfunctioning part can now be considered normal. To make sure of this, use the simulation method to check. If the malfunctioning part can not be detected by the simulation method, replace all SRS components including the wire harness.