

SERVICE HINTS

REAR FOG LIGHT RELAY

5-3 : Closed with rear fog light SW on, light control SW at **TAIL** or **HEAD** position

: PARTS LOCATION

Code		See Page	Code	See Page	Code	See Page
B6	A	86 (RHD)	J41	88 (RHD)	R6	88 (RHD)
J32		88 (RHD)	J42	88 (RHD)	R9	92 (RHD)
J37		88 (RHD)	J44	90 (RHD)	R11	92 (RHD)

: RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
5	57 (RHD)	Driver Side R/B (Right Kick Panel)

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1F	58 (RHD)	Cowl Wire and Driver Side J/B (Right Kick Panel)
1G	59 (RHD)	
2F	60 (RHD)	Cowl Wire and Passenger Side J/B (Left Kick Panel)

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC3	108 (RHD)	Floor No.2 Wire and Cowl Wire (Left Kick Panel)

: GROUND POINTS

Code	See Page	Ground Points Location
IF	108 (RHD)	Left Kick Panel
II	108 (RHD)	Cowl Side Panel RH
BK	112 (RHD)	Quarter Panel LH

: SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
B4	112 (RHD)	Floor No.2 Wire	B6	112 (RHD)	Floor No.2 Wire

REAR FOG LIGHT (RHD)

