


INSTALLATION

NOTICE:

- Never use SRS parts from another vehicle. When replacing parts, replace them with new parts.
- Never reuse the airbag sensor assembly involved in a collision when the airbag has deployed.
- Never repair a sensor in order to reuse it.



1. INSTALL AIRBAG SENSOR ASSEMBLY

- (a) Using a Torx wrench, install the airbag sensor assembly with 3 screws.

Torx wrench: T40 (Part No. 09042-00020 or locally manufactured tool)

Torque: 20 N·m (200 kgf·cm, 14 ft·lbf)

- (b) Connect the airbag sensor connectors.

NOTICE:

- Installation of the connector is done with the sensor assembly installed. Make sure the sensor assembly is installed to the specified torque.
- If the sensor assembly has been dropped, or there are cracks, dents or other defects in the case, bracket or connector, replace the sensor assembly with a new one.
- When installing the sensor assembly, take care that the SRS wiring does not interfere with other parts and is not pinched between other parts.
- After installing, shake the sensor assembly to check that there is no looseness.

2. INSTALL THESE PARTS: (See page BO-97)

- (a) No.1 console box duct
- (b) No.3 console box mounting bracket
- (c) Console box
- (d) Console box register
- (e) Rear console armrest
- (f) Lower rear console box
- (g) Accessory case
- (h) Accessory socket
- (i) Console box carpet
- (j) Cluster finish panel
- (k) Front ash receptacle
- (l) Glove compartment panel assembly
- (m) Glove compartment finish plate
- (n) No.2 under cover
- (o) No.1 safety pad
- (p) Hood lock release lever
- (q) No.1 under cover
- (r) End pad
- (s) Finish panel