


## WIRING DIAGRAM



If there is not the LEXUS hand-held tester, begin with STEP 2.

1	Check position sensor signal.
---	-------------------------------

- (a) Connect the LEXUS hand-held tester to the DLC3.
- (b) Turn ignition switch ON and LEXUS hand-held tester main switch ON.
- (c) Select the DATALIST mode on the LEXUS hand-held tester.

- (a) When operating each adjustment function of seat by turning the power seat control switch of the vehicle, check that "Position sensor" value changes on the screen of LEXUS hand-held tester.
- (b) When operating each adjustment function of seat by turning the power seat control switch of the vehicle, check that "Motor status" changes from OFF to ON on the screen of LEXUS hand-held tester.

When the seat is moved to the limit positions, "Lock" is displayed in the column of "Motor status" on the screen of LEXUS hand-held tester. At that time, if the power seat control switch is released, it turns OFF.

**OK:**


Both "Position sensor" value and "Motor status" are changing.

OK

Check and replace power seat position ECU  
(See page N-19).

NG

## 2 Check position sensor.

**PREPARATION:**

Disconnect the connector of the sensor and the connector of the motor leading to the sensor.

**CHECK:**

- Connect positive (+) lead to terminal 3 of sensor and negative (-) lead to terminal 2.
- Measure voltage between terminal 1 of sensor and body ground when battery positive voltage is applied between terminals 1 and 2 of motor connector.

**HINT:**

When the battery positive voltage is applied to the motor connector terminals, (+) and (-) are interchangeable.

**OK:**

Condition	Voltage
Motor stopped (Check several times with the motor in a different position each time.)	0V or battery positive voltage according to stop position
Motor running	Half of battery positive voltage

NG

Replace power seat motor.

OK

## 3 Check harness and connectors between power seat position ECU and position sensors (See page N-19).

NG

Repair or replace harness or connectors.

OK

Check and replace power seat position ECU  
([See page N-19](#)).