

## INSPECTION

1. REMOVE FUEL PUMP ECU
2.  INSPECT FUEL PUMP ECU (See page DI-210)
3. REINSTALL FUEL PUMP ECU