


Control switch circuit (Cruise control switch)

CIRCUIT DESCRIPTION

This circuit carries the SET/COAST, RESUME/ACCEL and CANCEL signals (each voltage) to the engine and ECT ECU.

WIRING DIAGRAM


2JZ-GE engine:



C

121084

3UZ-FE engine:




C

121085

INSPECTION PROCEDURE

1	Check voltage between terminals CCS of engine and ECT ECU connector and body ground.
---	--




PREPARATION:

- (a) Remove the engine and ECT ECU with connector still connected.
- (b) Turn ignition switch ON.


CHECK:

Measure voltage between terminals CCS of Engine and ECT ECU connector and body ground, when each of the SET/COAST, RESUME/ACCEL and CANCEL is turned ON.


Switch position	Resistance (V)
Neutral	10 - 16 V
RES/ACC	0.6 - 2.3 V
SET/COAST	1.9 - 4.7 V
CANCEL	3.4 - 7.2 V



NG	Proceed to next circuit inspection shown in problem symptoms table (See page DI-562)
----	--



2 Check control switch continuity.



PREPARATION:

- (a) Remove steering wheel pad (See page SR-9)
- (b) Disconnect the control switch connector.

CHECK:

Measure resistance between terminals 4 and 5 of control switch connector when control switch is operated.


Switch position	Resistance (Ω)
Neutral	∞ (No continuity)
RES/ACC	60 - 70
SET/COAST	180 - 220
CANCEL	380 - 460

NG

Replace control switch.

OK

3 Check main switch continuity.



PREPARATION:

- (a) Remove steering wheel center pad (See page SR-9)
- (b) Disconnect the control switch connector.

CHECK:

Check continuity between terminals 4 and 5 of control switch connector when main switch is held ON and OFF.

OK:

Switch position	Tester connection	Specified condition
OFF	-	No continuity
Hold ON	4 - 5	Continuity

NG

Replace control switch.

OK

4 Check harness and connector between engine and ECT ECU and cruise control switch, cruise control switch and body ground (See page IN-30).

NG

Repair or replace harness or connector.

OK

5 Check cruise control indicator light (See Pub. No. RM588E on page DI-584).

NG

Replace combination meter.

OK

Check and replace engine and ECT ECU (See page IN-30).