


DTC	P1755	Linear Solenoid for Lock-up Control Circuit Malfunction (SLU Solenoid Valve)
-----	-------	--




CIRCUIT DESCRIPTION

The amount of current flow to the solenoid is controlled by the (*) duty ratio of the Engine & ECT ECU output signal. The higher the duty ratio becomes, the higher the lock-up hydraulic pressure becomes during the lock-up operation.

(*) Duty Ratio

The duty ratio is the ratio of the period of continuity in one cycle. For example, if A is the period of continuity in one cycle, and B is the period of non-continuity, then



(*)


$$\text{Duty Ratio} = \frac{A}{A + B} \times 100 (\%)$$

BE4056

D00160


DTC No.	DTC detection condition	Trouble Area
P1755	The following condition is detected. (2-trip detection logic) Signal output from SLU is ON for 3.3 msec. or more and duty ratio is at least 95 % for 1 second.	<ul style="list-style-type: none">• Open or short in SLU solenoid valve circuit• SLU solenoid valve• Engine & ECT ECU• Automatic transmission assembly

WIRING DIAGRAM



INSPECTION PROCEDURE

1 Check SLU solenoid valve.

**PREPARATION:**

- (a) Jack up the vehicle.
- (b) Remove the oil pan.
- (c) Disconnect the solenoid connector.

CHECK:

Measure the resistance between terminals 1 and 2.

OK:

5.0 – 5.6 Ω at 20 °C (68 °F)



Check solenoid operation:**PREPARATION:**

- (a) Jack up the vehicle.
- (b) Remove the oil pan.
- (c) Remove the SLU solenoid valve.

CHECK:

Connect the positive (+) lead from the battery to terminal 2 and negative (-) lead to terminal 1.

OK:

When B ⁺ is applied.	Valve moves in  direction in the illustration on the left.
When B ⁺ is cut off.	Valve moves in  direction in the illustration on the left.

NG

Replace SLU solenoid valve.

OK

2 Check harness and connector between SLU solenoid valve and Engine & ECT ECU (See page N-30).

NG

Repair or replace the harness or connector.

OK

Check and replace the Engine & ECT ECU
(See page N-30).