

## REPLACEMENT

### REPLACEMENT REQUIREMENTS

In the following cases, replace the side and curtain shield airbag sensor assembly.

- If the side curtain shield airbag assembly has been deployed in a collision.
- If the side curtain shield airbag sensor assembly has been found to be faulty in troubleshooting.
- If the side curtain shield airbag sensor assembly has been dropped.

### CAUTION:

For removal and installation of the side and curtain shield airbag sensor assembly, see page RS-25 and RS-28. Be sure to follow the correct procedure.