

SERVICE HINTS

EFI RELAY

5-3 : Closed with the ignition SW at **ON** position

U1 UNLOCK WARNING SW

1-2 : Closed with ignition key in cylinder

: PARTS LOCATION

Code		See Page	Code		See Page	Code		See Page
E6	E	68 (LHD)	J10		74 (LHD)	J42		88 (RHD)
		82 (RHD)	J14		74 (LHD)	R8		74 (LHD)
E7	F	68 (LHD)	J15		74 (LHD)			88 (RHD)
		82 (RHD)	J29		84 (RHD)	T6		74 (LHD)
J5		70 (LHD)	J34		88 (RHD)			88 (RHD)
J8		74 (LHD)	J37		88 (RHD)	U1		74 (LHD)
J9	A	74 (LHD)	J40	B	88 (RHD)			88 (RHD)

: RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	54 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)
	54 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
2F	60 (LHD)	Cowl Wire and Passenger Side J/B (Right Kick Panel)
2G	61 (LHD)	

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA1	108 (RHD)	Engine Room Main Wire and Cowl Wire (Near the Passenger Side R/B)
IA2	98 (LHD)	Engine Room Main Wire and Cowl Wire (Near the Driver Side J/B)
	108 (RHD)	Engine Room Main Wire and Cowl Wire (Near the Passenger Side R/B)
IA3	108 (RHD)	Engine Room Main Wire and Cowl Wire (Near the Passenger Side R/B)
IE2	98 (LHD)	Instrument Panel Wire and Cowl Wire (Left Side of the Steering Column)
II1	100 (LHD)	Engine Room Main Wire and Cowl Wire (Near the Passenger Side R/B)
II4		
IJ2	110 (RHD)	Instrument Panel Wire and Cowl Wire (Right Side of the Steering Column)

: GROUND POINTS

Code	See Page	Ground Points Location
EE	96 (LHD)	Under the ABS & TRC & VSC Actuator
	106 (RHD)	
IF	98 (LHD)	Left Kick Panel
IG	108 (RHD)	Behind the Combination Meter
II	98 (LHD)	Right Side of the Cowl Panel
	108 (RHD)	Cowl Side Panel RH

: SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I1	100 (LHD)	Cowl Wire			

ENGINE IMMOBILISER SYSTEM

