

DTC	B1150/23	Occupant Detection Sensor Malfunction
-----	----------	---------------------------------------

CIRCUIT DESCRIPTION


The occupant detection sensor circuit consists of the airbag sensor assembly and occupant detection sensor.

For details of the function of each components, see OPERATION on page RS-2.

DTC B1150/23 is recorded when a malfunction is detected in the occupant detection sensor circuit.

DTC No.	DTC Detecting Condition	Trouble Area
B1150/23	• Occupant detection sensor malfunction	• Occupant detection sensor • Airbag sensor assembly • Wire harness


WIRING DIAGRAM



## INSPECTION PROCEDURE

1 Prepare for inspection (See step 1 on page DI-369).

2 Check wire harness (to ground).



### CHECK:

For the connector (on the airbag sensor assembly side) between the occupant detection sensor and the airbag sensor assembly, measure the resistance between body ground and each of FSL+ and FSL-.

### OK:


**Resistance: 0 MΩ or Higher**

NG

**Repair or replace wire harness.**

OK

3 Check wire harness (to B+).



### CHECK:

- Turn the ignition switch to ON.
- For the connector (on the airbag sensor assembly side) between the occupant detection sensor and the airbag sensor assembly, measure the voltage between body ground and each of FSL+ and FSL-.

### OK:


**Voltage: Below 1 V**

NG

**Repair or replace wire harness.**

OK

# 4 Check occupant detection sensor.



## **CHECK:**

Without passenger on a passenger seat:

For the connector of the occupant detection sensor, connect the positive (+) lead from the ohmmeter to terminal FSL+ and the negative (-) lead to terminal FSL-, measure the resistance between FSL+ and FSL-.

## **OK:**

**Resistance: 50 kΩ or Higher**

## **CHECK:**

With passenger on a passenger seat:

For the connector of the occupant detection sensor, connect the positive (+) lead from the ohmmeter to terminal FSL+ and the negative (-) lead to terminal FSL-, measure the resistance between FSL+ and FSL-.

## **OK:**


**Resistance: Below 50 kΩ**

**NG**

**Replace seat cushion cover.**

**OK**

## 5 Check airbag sensor assembly.



### PREPARATION:

- Turn the ignition switch to LOCK.
- Disconnect negative (-) terminal cable from the battery, and wait at least for 90 seconds.
- Connect the occupant detection sensor connector and airbag sensor assembly connector.
- Connect negative (-) terminal cable to the battery, and wait at least for 2 seconds.

### CHECK:

- Turn the ignition switch to ON, and wait at least for 20 seconds.
- Clear the DTC stored in memory (See step 5 on [page DI-369](#)).
- Turn the ignition switch to LOCK, and wait at least for 20 seconds.
- Turn the ignition switch to ON, and wait at least for 20 seconds.
- Check the DTC (See [page DI-369](#)).

### OK:

**DTC B1150/23 is not output.**

### HINT:

Codes other than code B1150/23 may be output at this time, but they are not relevant to this check.

**NG**

**Replace airbag sensor assembly.**

**OK**

**From the results of the above inspection, the malfunctioning part can now be considered normal. To make sure of this, use the simulation method to check.**