



INSTALLATION

1. CHECK TORQUE CONVERTER INSTALLATION

Using calipers and a straight edge, measure from the distance from the installed surface of the transmission housing to the installed surface of the torque converter.

Correct distance: More than 0.1 mm (0.004 in.)

If the distance is less than the standard, check for an improper installation.

2. INSTALL TRANSMISSION

Installation is in the reverse order of removal.

(See page AT-29)

HINT:

After installation, check and inspect items as follows.

- Adjust the shift lever range. (See page DI-144)
- Fill ATF and check fluid level. (See page DI-144)
- Do the road test. (See page DI-144)