



# REAR WHEEL HUB BOLT REPLACEMENT

## 1. REMOVE REAR WHEEL



## 2. REMOVE BRAKE CALIPER AND DISC


- Remove the 2 bolts and remove the brake caliper from the axle carrier.
- Support the brake caliper securely.
- Remove the disc.



## 3. REMOVE HUB BOLT

Using SST, remove the hub bolt.

SST 09628-10011



## 4. INSTALL HUB BOLT

- Install a washer and nut to the bolt, as shown in the illustration.
- Turn the wheel nut to pull the hub bolt until the underside of the hub bolt head touches the axle hub.

## 5. INSTALL DISC AND BRAKE CALIPER

- Install the disc.
- Install the brake caliper and 2 bolts to the axle carrier.

**Torque: 104 N·m (1,065 kgf·cm, 77 ft·lbf)**

## 6. INSTALL REAR WHEEL

**Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)**