



## INSPECTION

### INSPECT SHOCK ABSORBER

Compress and extend the shock absorber rod and check that there is no abnormal resistance or unusual operation sound. If there is any abnormality, replace the shock absorber with a new one.

#### NOTICE:

When disposing the shock absorber, see DISPOSAL on page SA-90.