


CIRCUIT INSPECTION

Power source circuit

CIRCUIT DESCRIPTION

This circuit provides power to operate the driver door ECU.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 Check MPXB, GAUGE and DOOR(FR) fuse.

CHECK:

Check continuity of MPXB, GAUGE and DOOR(FR) fuse.

OK:

Continuity

NG

Replace the failure fuse.

OK

2 Check voltage between terminals BDR, CPUB, SIG and GND of driver door ECU connector.

PREPARATION:

Turn ignition switch ON.

CHECK:

Measure voltage between terminals SIG, and GND.

OK:

Voltage: 10 – 14V

PREPARATION:

(a) Turn ignition switch OFF.

(b) Disconnect the driver door ECU connector.

CHECK:

Measure voltage between terminals BDR, CPUB and GND.

OK:

Voltage: 10 – 14V

OK

Proceed to next circuit inspection shown on problem symptoms table. (See page DI-706)

NG

3**Check wireharness and connector between ECU and body ground.****NG****Repair or replace wireharness or connector****OK****Check and repair wireharness and connector
between ECU and battery.**