


INSPECTION

1. **INSPECT FUEL LID OPENER SWITCH CONTINUITY**
- (a) Check that continuity exists between terminals with the switch ON (Lever pulled).
 - (b) Check that no continuity exists between terminals with the switch OFF (Lever free).

If continuity is not as specified, replace the switch assembly.




2. **INSPECT FUEL LID OPENER SWITCH CIRCUIT**

Disconnect the connector from the switch and inspect the connector on the wire harness side, as shown.


Tester connection	Condition	Specified condition
1 - Ground	Constant	Continuity
2 - Ground	Constant	Battery voltage

If circuit is not as specified, inspect the circuits connected to other parts.



3. **INSPECT FUEL LID OPENER SOLENOID OPERATION**

- (a) Connect the positive (+) lead from the battery to terminal 2 and negative (-) lead to terminal 3.
 - (b) Check that the solenoid operates in the fuel lid opening.
- If operation is not as specified, replace the solenoid.

Wire Harness Side

I04187

4. INSPECT FUEL LID OPENER MOTOR CIRCUIT

Disconnect the connector from the switch and inspect the connector on the wire harness side, as shown.

Tester connection	Condition	Specified condition
3 – Ground	Constant	Continuity
2 – Ground	Fuel lid opener switch ON (Lever pulled)	Battery voltage

If circuit is not as specified, inspect the circuits connected to other parts.