

INSTALLATION

Installation is in the reverse order of removal (See page SA-102).

AFTER INSTALLATION, CHECK REAR WHEEL ALIGNMENT (See page SA-7)