

INSPECTION

1. INSPECT AIR INLET DAMPER POSITION SENSOR CIRCUIT
(See page DI-941)
2. INSPECT AIR INLET SERVOMOTOR OPERATION
(See page DI-953)
3. INSPECT AIR MIX DAMPER POSITION SENSOR CIRCUIT
(See page DI-938)
4. INSPECT AIR MIX SERVOMOTOR OPERATION
(See page DI-950)
5. INSPECT AIR OUTLET DAMPER POSITION SENSOR CIRCUIT
(See page DI-944)
6. INSPECT AIR OUTLET SERVOMOTOR OPERATION
(See page DI-956)