

REMOTE CONTROL MIRROR (LHD)

SYSTEM OUTLINE

REMOTE CONTROL MIRROR OPERATION

When the ignition SW is turned to the **ACC** or **ON** position, the outer mirrors can be operated. When the remote control mirror SW is operated, the signal is input to body ECU No.2 and the outer mirror is adjusted to the desired position through communication control of the body ECU and door ECU etc.

In the remote control mirror system, the position sensor detects the number of rotations of each motor (Movement amount of each mirror) and inputs it to the ECU. This makes it possible to store and recall the outer mirror position using the position memory SW. The outer mirror position is stored and recalled through communication control of the body ECU and door ECU etc.

SERVICE HINTS

R7 REMOTE CONTROL MIRROR SW

- 8-9 : Continuity with select SW at right side
 - : Approx. **100** Ω with select SW at left side
- 7-9 : Approx. **100** Ω with operation SW at up side
 - : Approx. **250** Ω with operation SW at right side
 - : Approx. **470** Ω with operation SW at down side
 - : Approx. **800** Ω with operation SW at left side

: PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
A16	72 (LHD)	E5	68 (LHD)	J16	74 (LHD)
B5	A 72 (LHD)	F11	A 76 (LHD)	J18	74 (LHD)
B6	A 72 (LHD)	F12	B 76 (LHD)	M2	74 (LHD)
C12	72 (LHD)	F13	C 76 (LHD)	R7	74 (LHD)
D18	A 76 (LHD)	J7	74 (LHD)	R17	78 (LHD)
D19	B 76 (LHD)	J8	74 (LHD)	R18	78 (LHD)
D20	C 76 (LHD)	J10	74 (LHD)	T5	74 (LHD)
D21	76 (LHD)	J13	74 (LHD)		

: RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	54 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1F	58 (LHD)	Cowl Wire and Driver Side J/B (Left Kick Panel)
1G	59 (LHD)	
1H		
2B	60 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
2F	60 (LHD)	Cowl Wire and Passenger Side J/B (Right Kick Panel)
2G	61 (LHD)	
2H		

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IB1	98 (LHD)	Front Door LH Wire and Cowl Wire (Left Kick Panel)
IE1	98 (LHD)	Instrument Panel Wire and Cowl Wire (Left Side of the Steering Column)
IJ1	100 (LHD)	Instrument Panel Wire and Cowl Wire (Left Side of the Blower Unit)
IK1	100 (LHD)	Front Door RH Wire and Cowl Wire (Right Kick Panel)

: GROUND POINTS


Code	See Page	Ground Points Location
IF	98 (LHD)	Left Kick Panel
II	98 (LHD)	Right Side of the Cowl Panel




: SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I6	100 (LHD)	Cowl Wire			


A16




B5 (A)




B6 (A)




C12




D18 (A) GRAY




D19 (B) GRAY




D20 (C) GRAY




D21 BLUE




E5




F11 (A) GRAY




F12 (B) GRAY



F13 (C) GRAY




J7 GRAY




(Hint : See Page 7, 23, 39)

J8




(Hint : See Page 7, 23, 39)

J10 ORANGE



(Hint : See Page 7, 23, 39)


J13



(Hint : See Page 7, 23, 39)

REMOTE CONTROL MIRROR (LHD)

J16



(Hint : See Page 7, 23, 39)

J18



(Hint : See Page 7, 23, 39)

M2 BLUE

