


DTC	B1244 / 44	Light sensor circuit malfunction
-----	------------	----------------------------------

CIRCUIT DESCRIPTION

This DTC is output when failure of light sensor circuit is detected.

DTC No.	DTC Detecting Condition	Trouble Area
B1244/44	<ul style="list-style-type: none">• Malfunction of light sensor• Open or short of light sensor circuit	<ul style="list-style-type: none">• Light sensor• Wireharness• Body No.2 ECU

WIRING DIAGRAM



INSPECTION PROCEDURE**1 Check light sensor.**

Using LEXUS hand –held tester:

PREPARATION:

- (a) Connect the LEXUS hand–held tester to the DLC3.
- (b) Turn ignition switch ON and LEXUS hand–held tester main switch ON.

CHECK:

The value of the illumination rate should change in the following range when the light sensor is put in the light or covered by a hand.

OK:

0.8 ms ~ 22.0 ms

HINT:

- This is the time to be taken for the light sensor to generate one cycle of frequency according to the brightness.

When not using LEXUS hand–held tester. (See page BE-38)

NG**Replace the light sensor.****OK****2 Check wireharness and connector between light sensor and Body No.2 ECU.****NG****Repair or replace wireharness or connector.****OK****Replace the Body No.2 ECU.**