


## INSTALLATION

### 1. INSTALL ELECTRIC COOLING FAN TO RADIATOR

- (a) Install the electric cooling fan with the 6 bolts.

**Torque: 5.0 N·m (50 kgf·cm, 44 in·lbf)**

- (b) Connect the radiator reservoir hose to the radiator.



### 2. INSTALL RADIATOR AND ELECTRIC COOLING FAN ASSEMBLY

- (a) Install the 2 lower radiator supports to the radiator.  
 (b) Attach the 2 lower radiator supports on the radiator to the body bracket.  
 (c) Install the radiator and electric cooling fan assembly with the 2 upper radiator supports and 2 nuts.

**Torque: 13.5 N·m (135 kgf·cm, 10 ft·lbf)**

- (d) Connect these parts:
- Upper radiator hose to radiator
  - Lower radiator hose to radiator
  - ECU outlet duct to ECU box
  - Wire for electric cooling fan to clamp on electric cooling fan
  - 2 electric cooling fan connectors
  - Water temperature switch connector for electric cooling fan
  - 2 oil cooler hoses for A/T to radiator

### 3. INSTALL AIR CLEANER AND AIR FLOW METER ASSEMBLY

#### 4. INSTALL AIR CLEANER INLET

#### 5. FILL WITH ENGINE COOLANT

#### 6. START ENGINE AND CHECK FOR ENGINE COOLANT AND A/T FLUID LEAKS

#### 7. INSTALL ENGINE UNDER COVER