

## 12. Map DISC cannot be inserted.

### INSPECTION PROCEDURE

1 Check the MAP DISC.

NG

Replace the MAP DISC.

OK

2 Insert a MAP DISC without tilt.

OK

Normal.

NG

3 Check the navigation ECU.

#### PREPARATION:

Disconnect the navigation ECU connector.

#### CHECK:

Check voltage terminals +B.

#### OK:

+B: 10 – 14 V

#### CHECK:

Check voltage terminal ACC when turn ignition switch ACC or ON position.

#### OK:

ACC: 10 – 14 V

#### CHECK:

Check continuity terminal GND.

#### OK:

GND: Continuity

NG

Replace or repair wire harness.

OK

**Replace the navigation ECU.**