

CIRCUIT INSPECTION


DTC	B1411/11	Room Temperature Sensor Circuit
-----	----------	---------------------------------

CIRCUIT DESCRIPTION

This sensor detects the temperature inside the cabin and sends the appropriate signals to the A/C control assembly.

DTC No.	Detection Item	Trouble Area
B1411/11	Open or short in room temperature sensor circuit.	<ul style="list-style-type: none"><li>•Room temperature sensor.</li><li>•harness or connector between room temperature sensor and A/C control assembly.</li><li>•A/C control assembly.</li></ul>

WIRING DIAGRAM



I05981

## INSPECTION PROCEDURE

### HINT:

In case of using the LEXUS hand-held tester, start the inspection step 1 and in case of not using the LEXUS hand-held tester, start from step 2.

**1** Check room temp. sensor using LEXUS hand-held tester.

### PREPARATION:

Connect the LEXUS hand-held tester to the DLC3.

### CHECK:


Check the room temp. sensor using DATA LIST.

OK

Check and replace A/C control assembly.

NG

**2** Check voltage between terminals TR and SG-3 of A/C control assembly connector.



### PREPARATION:

Remove A/C control assembly with connectors still connected.

### CHECK:

- Turn ignition switch ON.
- Measure voltage between terminals TR and SG-3 of A/C control assembly connector at each temperature.

### OK:

#### Voltage

at 25°C (77°F) 1.8 – 2.2V

at 40°C (104°F) 1.2 – 1.6V

### HINT:


As the temperature increases, the voltage decreases.

NG

Go to step 3.

OK

Proceed to next circuit inspection shown on problem symptoms table (See page DI-912). However, if DTC B1411/11 is displayed, check and replace A/C control assembly.

**3 Check room temperature sensor.**

I05261

**PREPARATION:**

Disconnect room temperature sensor connector.

**CHECK:**

Measure resistance between terminals 1 and 2 of room temperature sensor connector at each temperature.

**OK:****Resistance**

at 25°C (77°F) 1.65 – 1.75V

at 50°C (122°F) 0.55 – 0.65V

**HINT:**

As the temperature increases, the resistance decreases.

**NG****Replace room temperature sensor.****OK****4 Check harness and connector between A/C control assembly and room temperature sensor (See page N-29).****NG****Repair or replace harness or connector.****OK****Check and replace A/C control assembly.**