

TROUBLESHOOTING

PROBLEM SYMPTOMS TABLE

BE11G-03

POWER MIRROR CONTROL SYSTEM:

Trouble	Parts name	See page
Mirror does not operate.	1. CIG Fuse (I/P J/B) 2. Mirror Swith 3. Mirror Motor 4. Wire Harness	- BE-3 *BE-192 -
Mirror operates abnormally.	1. Mirror Swith 2. Mirror Motor 3. Wire Harness	BE-3 *BE-192 -
Electrical retract system does not operate.	1. Retract Switch 2. Position Switch 3. Retract Motor 4. Wire Harness	BE-3 *BE-192 BE-3 -

*: See Pub. No. RM588E