

PROBLEM SYMPTOMS TABLE

Perform troubleshooting of the circuits for the applicable problem in the order given in the chart below. Proceed to the page located for each circuit.

HINT:

- If the instruction "Proceed to next circuit inspection shown problem symptoms table" is given in the flow chart for each circuit, proceed to the circuit with the next highest number in the table to continue the check.
- If the trouble still reappears even though there are no abnormalities in any of the other circuits, then check and replace the Power Seat Position ECU as the last step.

Symptom	Suspect Area	See page
All functions do not operate.	1. ECU Power Source Circuit 2. Power Seat Position ECU	DI-523 IN-29
"Slide operation" does not operate.	1. Slide Motor Circuit 2. Power Seat Switch Circuit 3. Power Seat Position ECU	DI-526 DI-528 IN-29
"Reclining operation" does not operate.	1. Reclining Motor Circuit 2. Power Seat Switch Circuit 3. Power Seat Position ECU	DI-526 DI-528 IN-29
"Front Vertical operation" does not operate.	1. Front Vertical Motor Circuit 2. Power Seat Switch Circuit 3. Power Seat Position ECU	DI-526 DI-528 IN-29
"Lifter operation" does not operate.	1. Lifter Motor Circuit 2. Power Seat Switch Circuit 3. Power Seat Position ECU	DI-526 DI-528 IN-29
Memory return function does not operate.	1. M1. M2 SET Switch Circuit 2. Power Seat Position ECU	DI-531 IN-29
Memory return function operates abnormally. (Power seat)	1. Seat Position Sensor Circuit 2. Power Seat Position ECU	DI-533 IN-29
Memory return function operates abnormally. (Mirror)	1. Mirror Position Sensor Circuit 2. Door ECU (Driver or Passenger)	DI-728 DI-700 DI-733