

DIAGNOSTIC TROUBLE CODE CHART

| DTC No. (See page) | Detection Item | Trouble Area |
|-----------------------|---|--|
| B2785 (DI-567) | Ignition switch ON malfunction | <ul style="list-style-type: none"> • Ignition switch • Main relay • Wireharness |
| B2786 (DI-567) | Ignition switch OFF malfunction | |
| B2791 (DI-571) | Key unlock warning switch OFF malfunction | <ul style="list-style-type: none"> • Key unlock warning switch • Main relay • Wireharness |
| B2795 (DI-573) | Unmatched key code | <ul style="list-style-type: none"> • Key • Unregistered key inserted before |
| B2796 (DI-574) | No communication in immobiliser system | <ul style="list-style-type: none"> • Key • Transponder key coil • Amplifier • Wireharness • Engine and ECT ECU |
| B2797 (DI-576) | Communication malfunction No.1 | <ul style="list-style-type: none"> • Communication contents • Unregistered key inserted before |
| B2798 (DI-578) | Communication malfunction No.2 | <ul style="list-style-type: none"> • Key • Transponder key coil • Amplifier • Wire harness • Engine and ECT ECU |

HINT:

To reduce the unnecessary exchange of Engine and ECT ECU, check that a trouble occurs with the original Engine and ECT ECU at the time of exchanging Engine and ECT ECU and the trouble will disappear with a new Engine and ECT ECU.