

## 6. Screen cannot be dimmed in night time.

### INSPECTION PROCEDURE

- |   |  |
|---|--|
| 1 | Check if the screen is dimmed at night. (With the light control switch ON), do all screens except the navigation screen appear in Night Mode?) |
|---|--|

NG

Check the light control switch.

OK

- |   |                          |
|---|--------------------------|
| 2 | Check the multi display. |
|---|--------------------------|

**CHECK:**

Check terminal TAIL.

**OK:**

TAIL: See "Multi display" of "TERMINAL OF ECU".

NG

Replace or repair wire harness.

OK

- |   |                          |
|---|--------------------------|
| 3 | Check the multi display. |
|---|--------------------------|

**PREPARATION:**

Disconnect the multi display connector.

**CHECK:**

Check voltage terminals +B.

**OK:**

+B: 10 – 14 V

**CHECK:**

Check voltage terminal ACC when turn ignition switch ACC or ON position.

**OK:**

ACC: 10 – 14 V

**CHECK:**

Check continuity terminal GND.

**OK:**

GND: Continuity

NG

Replace or repair wire harness.

A button with a shield-like shape, containing the text "OK".

OK

**Replace the multi display.**