



REMOVAL

REMOVE FRONT SEAT

- (a) Using a screwdriver, remove the cap.

HINT:

Tape the screwdriver tip before use.

- (b) Remove the front seat outer belt floor anchor bolts and seat belt anchor.

- (c) Using a screwdriver, remove the seat track covers.

HINT:

Tape the screwdriver tip before use.

- (d) Remove the 4 bolts.

- (e) Disconnect the connectors.

- (f) Remove the front seat.

NOTICE:

Be careful not to damage the body.