


# CIRCUIT INSPECTION

## Power source circuit


## CIRCUIT DESCRIPTION

This circuit provides power to operate the rear left door ECU.

## WIRING DIAGRAM



## Rear Left (RHD)



105629

## INSPECTION PROCEDURE

1	<b>Check MPXB, GAUGE and DOOR(RL) fuse.</b>
---	---------------------------------------------

### CHECK:

Check continuity of MPXB, GAUGE and DOOR(RL) fuse.

### OK:

Continuity

NG

Replace the failure fuse.

OK

2	<b>Check voltage between terminals BDR, CPUB, SIG and GND of rear left door ECU connector.</b>
---	------------------------------------------------------------------------------------------------

### PREPARATION:

Turn ignition switch ON.

### CHECK:

Measure voltage between terminals SIG, and GND.

### OK:

**Voltage: 10 – 14V**

### PREPARATION:

(a) Turn ignition switch OFF.

(b) Disconnect the rear left door ECU connector.

### CHECK:

Measure voltage between terminals BDR, CPUB and GND.

### OK:

**Voltage: 10 – 14V**

OK

Proceed to next circuit inspection shown on problem/symptoms table (See page DI-770).

NG

**3****Check wireharness and connector between ECU and body ground.****NG****Repair or replace wireharness or connector.****OK****Check and repair wireharness and connector  
between ECU and battery.**